


K.A.R. Reproduction



**CF-105 Arrow Mk. 1
Pilot's Operating Instructions**

Foreword

The Avro Arrow represents an important part of our Canadian heritage. It has become not only a significant symbol in Canadian history but it has become part of our myth and legend.....what might have been. There have been many descriptions of the Arrow and it's story; some fact and some pure fiction. These pilot operating instructions are, however, part of the real history of a significant aircraft. The instructions clearly document the level of sophistication and the degree of performance for the initial prototype aircraft and give a intriguing glimpse into the follow-on plans for the aircraft. Indeed, the prototype aircraft did exceed virtually all of the performance data contained in this manual and consequently, it would have needed significant amendment.

The original Avro Arrow Pilot Operating Instructions (classified Secret) were issued to company test pilots and to test pilots of the Royal Canadian Air Force (RCAF) who were assigned to the test program. Fortunately, several library copies survived including a copy sent to the RCAF's Central Experimental Proving Establishment (CEPE). This replica faithfully reproduces the information contained in these now unclassified manuals. While every effort has been taken to duplicate the exact content, format and original look of the document (including some mistakes and inconsistencies), some minor changes have been made to allow for the differences of modern computer fonts from their original typewriter counterparts. Additionally, the replica reproduces drawings in colour that are interpretations of the original black and white tone copy. Any subsequent omissions, or errors are solely those of Kestrel Aviation Research (K.A.R.).

Special thanks to R. Kyle Schmidt for his expert assistance in the preparation of this effort. If you would like further information on the Avro Arrow, be sure to investigate Kyle Schmidt's fantastic "Arrow" home page on the internet @ <http://www.totavia.com/arrow/>

January 1998

K.A.R.

Copyright © K.A.R. February 1997
All Rights Reserved

This manual may not be further reproduced in whole or in part by any means without the express written consent of the copyright holder

PRELIMINARY

PILOT'S OPERATING INSTRUCTIONS

ARROW 1

APRIL 1958

(This issue supersedes issue dated January 1958 due to the addition of Parts 1, 2 and 3 and revision to Part 4.)

AVRO AIRCRAFT LIMITED

MALTON - ONTARIO

LIST OF REVISIONS

DATE

PAGE NO.

DATE

PAGE NO.

TABLE OF CONTENTS (Cont'd)

PART	TITLE	PAGE
1	DESCRIPTION	
	INTRODUCTION	
	General.....	1
	Airframe.....	1
	Engine.....	1
	Dimensions.....	2
	FUEL SYSTEM	
	General.....	2
	Fuel Tank Capacities.....	2
	Fuel Flow to the Engines.....	4
	Fuel Tank Pressurization.....	5
	Fuel System Controls.....	5
	Engine Fuel System Emergencies.....	6
	Long Range Fuel Tank Supply.....	8
	Fuel Warning Lights.....	8
	Fuel Tank Contents Indicators.....	10
	OIL SYSTEM	
	General.....	10
	Oil Pressure Warning.....	10
	ELECTRICAL SYSTEM	
	General.....	10
	Master Electrical Switch.....	12
	Warning and Indicating Lights.....	12
	Master Warning Lights and System Warning Lights.....	14
	Master Warning Control Unit.....	16
	AC System.....	17
	DC System.....	17
	Engine Starting Services.....	19
	FLYING CONTROL SYSTEM	
	General.....	20
	Hydraulic System.....	21
	Ram Air Driven Turbine.....	21
	Damping System.....	22
	Damping Warning Lights.....	24

TABLE OF CONTENTS (Cont'd)

PART	TITLE	PAGE
1	PITCH AXIS	
	Pitch Command Control.....	25
	Trim Control.....	26
	Pilot Feel in the Normal Mode.....	26
	G Limits.....	27
	ROLL AXIS	
	Pilot Command Control.....	27
	Turn Co-ordination.....	27
	Trim Control.....	28
	Roll Rate Limits.....	28
	YAW AXIS	
	General.....	28
	Yaw Rate Limits.....	29
	Rudder Trim, Feel and Hinge Moment Limitation.....	29
	AUTOMATIC FLIGHT CONTROL SYSTEM.....	29
	AIR CONDITIONING SYSTEM	
	General.....	30
	Cabin Pressurization.....	31
	Cockpit Controls.....	31
	Safety Provisions in the System.....	34
	Single Engine Flying.....	34
	System Operation with Landing Gear Down.....	35
	COCKPIT CANOPIES	
	General.....	35
	Normal Operation.....	35
	Normal Operation from the Ground.....	36
	Emergency Opening from the Ground.....	36
	Emergency Opening in the Air.....	36
	LIGHTING EQUIPMENT	
	Cockpit Lights.....	37
	External Lights.....	38

TABLE OF CONTENTS (Cont'd)

PART	TITLE	PAGE
1	ENGINE CONTROLS	
	Engine Power Controls.....	38
	Afterburner Control.....	38
	Engine Starting Controls.....	39
	Engine Motoring.....	40
	ENGINE INSTRUMENTS	
	Pressure Ratio Indicator.....	40
	Engine RPM Indicator.....	41
	Turbine Outlet Temperature Guage.....	41
	LOW PRESSURE PNEUMATIC SYSTEM	
	General.....	42
	Anti-G Suit Controls.....	42
	Canopy Seals.....	42
	DE-ICING AND ANTI-ICING SYSTEMS	
	General.....	42
	Ice Detection.....	43
	Duct De-icing.....	43
	Engine Compressor Inlet Anti-icing.....	43
	Windscreen and Canopy Anti-icing.....	44
	Pitot-head and Vane Anti-icing.....	44
	OXYGEN SYSTEM	
	General.....	44
	Normal System.....	44
	Oxygen Regulator.....	45
	Emergency Oxygen Supply.....	45
	Composite Leads Disconnect.....	45
	UTILITY HYDRAULIC SYSTEM	
	General.....	46
	Landing Gear.....	46
	Landing Gear Controls.....	47
	Emergency Lowering Landing Gear.....	47
	Landing Gear Position Indicators.....	47
	Sequencing of Landing Gear and Doors.....	48
	Wheel Brakes.....	48
	Anti-Skid System.....	49

TABLE OF CONTENTS (Cont'd)

PART	TITLE	PAGE
1	UTILITY HYDRAULIC SYSTEM (Cont'd)	
	Brake Pressures.....	49
	Pressure Warning Lights.....	49
	Parking Brake.....	49
	Nose Wheel Steering.....	50
	Steering Angles.....	50
	Speed Brakes.....	50
	Selector Switch.....	50
	NAVIGATION EQUIPMENT	
	Radio Magnetic Indicator.....	51
	UHF Homer.....	51
	Radio Compass (AN/ARN-6 LF).....	51
	J4 Gryosyn Compass.....	52
	R-Theta Navigation Computer System.....	53
	COMMUNICATION EQUIPMENT	
	UHF Equipment (AN/ARC-34).....	54
	Intercommunication (AN/AIC-10).....	55
	OPERATIONAL EQUIPMENT AND CONTROLS	
	IFF (AN/APX-6X).....	57
	EJECTION SEATS	
	General.....	59
	Interconnected Firing System of the Canopy and Ejection Seat.....	59
	Manual Override Control.....	62
	Manual Leg Restraint Release.....	62
	Harness Release.....	62
	Seat Raising Handle.....	63
	EMERGENCY EQUIPMENT	
	Engine Fire Detection and Extinguishing Systems.....	63
	Bail Out Signaln.....	64
	Emergency Operations of the UHF and IFF on Seat.....	
	Ejection.....	64
	PARABRAKE.....	65

TABLE OF CONTENTS (Cont'd)

PART	TITLE	PAGE
1	FLIGHT INSTRUMENTS	
	Pitot Static System.....	65
	Mach/Airspeed Indicator.....	65
	Altimeter.....	66
	Skin Temperature Indicator.....	66
	Sideslip and Angle of Attack Indicator.....	66
2	HANDLING	
	PRELIMINARIES	
	Before Entering the Aircraft.....	73
	Solo Flying.....	73
	Before Entering the Cockpit.....	73
	After Entering the Cockpit.....	73
	STARTING PROCEDURE	
	Preliminaries.....	78
	Procedure for Starting.....	80
	Engine at Idle.....	81
	Wet Start.....	81
	Hot Start.....	82
	FLYING CONTROLS CHECK (To be issued later)	
	TAXYING PROCEDURE	
	General.....	82
	Nose Wheel Steering.....	83
	TAKE-OFF PROCEDURE)	
	ACTIONS AFTER TAKE-OFF) To be issued later)	
	FLYING CHARACTERISTICS)	
	LANDING PROCEDURE)	
	ENGINE HANDLING	
	Engine Pressure Ratio During Afterburning.....	83
	Low Pressure Cpmpressor Overspeed Warning Light.....	83
	Engine Fuel System Failure.....	84
	Thrust Overshoot.....	84

TABLE OF CONTENTS (Cont'd)

PART	TITLE	PAGE
2	END OF FLIGHT PROCEDURE	
	Stopping the Engines.....	84
	Action Before Leaving the Aircraft.....	84
3	EMERGENCY HANDLING	
	ENGINE FAILURE PROCEDURES	
	Engine Failure During Take-off (To be issued later)	
	One Engine Failure in Flight.....	87
	Two Engine Failure in Flight.....	87
	EMERGENCY RELIGHT IN THE AIR	
	General.....	89
	Relight Procedure.....	89
	LANDING WITH ASYMMETRIC POWER (To be issued later)	
	FLYING CONTROLS - EMERGENCY PROCEDURES.....	91
	ELECTRICAL SYSTEM - EMERGENCY PROCEDURES.....	94
	FUEL SYSTEM - EMERGENCY PROCEDURES.....	97
	AIR CONDITIONING AND PRESSURIZATION -	
	EMERGENCY PROCEDURES.....	100
	ENGINES - EMERGENCY PROCEDURES.....	102
	EMERGENCY LANDINGS.....	104
	LANDING GEAR EMERGENCY PROCEDURES.....	
	General.....	104
	Hydraulic Pressure Normal.....	104
	Insufficient Hydraulic Pressure.....	105
	BRAKE EMERGENCY PROCEDURES	
	Emergency Operation of the Brakes.....	105
	Engine Thrust at Idle RPM.....	105

TABLE OF CONTENTS (Cont'd)

PART	TITLE	PAGE
3	AIRFRAME AND ENGINE ICING	
	General.....	106
	Engine Anti-icing.....	106
	ACTION EVENT OF FIRE.....	106
	ABANDONING THE AIRCRAFT	
	General.....	107
	Pilot Preliminaries.....	107
	Navigator.....	107
	Pilot.....	107
	Manual Release.....	109
	EMERGENCY CANOPY OPENING ON THE GROUND	
	From Inside the Cockpit.....	109
	From Outside the Cockpit.....	109
4	OPERATING DATA	
	ENGINE LIMITATIONS	
	Principal Limitations.....	111
	FLYING LIMITATIONS.....	112

LIST OF ILLUSTRATIONS

FIGURE	TITLE	PAGE
	Frontispiece	
1-1	Fuel System Feeds.....	3
1-2	Fuel Flow (Engine).....	7
1-3	Electrical Power Supply System.....	11
1-4	Master Warning Panel.....	13
1-5	Pressurization Graph.....	32
1-6	Mk C5 Ejection Seat.....	60
1-7	Pilot's Cockpit Layout.....	68
1-8	Navigator's Cockpit Layout.....	70
2-1	Exterior Inspection.....	75
2-2	Jet Wake and Intake Danger Areas.....	79
3-1	J-75 Relight Chart.....	88
4-1	Flight Envelope - Sea Level.....	113
4-2	Flight Envelope - 30,000 feet.....	114
4-3	Flight Envelope - 50,000 feet.....	115
4-4	Recommended Take-off Speeds.....	116
4-5	Recommended Approach Speeds.....	117
4-6	Recommended Touchdown Speeds.....	117
4-7	Take-off Distance Chart.....	118
4-8	Climb Chart (NO A/B) - 60,000 lb.....	119
4-9	Climb Chart (NO A/B) - 68,765 lb.....	120
4-10	Climb Chart (with A/B) - 60,000 lb.....	121
4-11	Climb Chart (with A/B) - 68,765 lb.....	122
4-12	Fuel Flow Chart.....	123
4-13	Landing Distance Chart - With Parabrake.....	124
4-14	Landing Distance Chart - Without Parabrake.....	125

PRELIMINARY PILOT'S OPERATING INSTRUCTIONS

ARROW 1

PART I DESCRIPTION

INTRODUCTION

General

1. The ARROW 1 is a delta wing aircraft powered with two Pratt and Whitney J75 - P3 engines with afterburners.

Airframe

2. The fuselage, wings, vertical stabilizer and control surfaces are of all metal construction. The tandem bogey main wheels and legs are attached to the inner wing main torque box and retract inboard and forwards. The nose wheel is located beneath the pressurized cockpits and retracts forwards. The flying control surfaces are fully powered by two independent hydraulic systems. Speed brakes are fitted below the fuselage and a brake parachute is installed in the aft end of the fuselage. Space in the radar nose and armament bay is utilized for test equipment and instrumentation.

Engines

3. The J75-P3 engine is a continuous axial flow turbojet. Two tandem compressors, one low pressure and the other high pressure, with their respective turbines form two rotor systems which are mechanically independent but related as to airflow. A hydro-mechanical fuel control establishes the power output. The engine is provided with a low pressure compressor speed limiter which reduces fuel flow when a predetermined low pressure compressor rpm is exceeded. The engine has an installed military thrust on a standard day at sea level of approximately 12,500 lb.
4. The engine incorporates an afterburner, the operation of which is automatic after it has been selected by the pilot. The afterburner increases the available engine thrust by approximately 50%, giving a installed maximum thrust on a standard day at sea level of approximately 18,500 lb.
5. An anti-icing system prevents icing on the inlet section of the engine and a de-icing system is employed on the duct intakes.

Part 1

Dimensions

6. The dimensions of the aircraft are as follows:

- (a) Length - 73 ft 4 in. (To datum)
Length - 80 ft 10 in. (Including probe)
- (b) Wing Span - 50 ft 0 in.
- (c) Height - 21 ft 3 in. (To top of vertical stabilizer - unloaded aircraft)
Height - 14 ft 6 in. (To top of canopy)
- (d) Sweepback - 61° 27' (Leading edge)
11° 12' (Trailing edge)
- (e) Wheel Track - 30 ft 2-1/2 in.

FUEL SYSTEM

General

7. Fuel is carried in two bladder type tanks in the fuselage and six integral tanks in each wing. The forward fuselage tank and the six wing tanks in the right wing normally feed the RH engine, while the aft fuselage tank and the six wing tanks in the left wing normally feed the LH engine. The only interconnection between each sub-system is the crossfeed. One of the wing tanks in each sub-system functions as a collector tank. Each sub-system supplies fuel to its respective engines by means of a collector tank booster pump driven by a shaft from that engine. Each booster pump has sufficient capacity to supply the maximum fuel demand of its own engine and afterburner, or to supply the demand of both engines with partial afterburning. The fuel passes from the booster pump to an oil-to-fuel heat exchanger and a low pressure fuel cock before entering the engine compartment.

8. A long range fuel tank of 500 gals capacity may be fitted (in later aircraft) on the under side of the fuselage for ferry missions. Fuel from this tank feeds into the collector tanks.

Fuel Tank Capacities

9. The fuel capacities are give imperial gallons and are for usable fuel. Weights are for JP4 fuel, specific gravity .78.




FIG 1-1 FUEL SYSTEM FEEDS (Aircraft)

Part 1

	<u>Gal.</u>	<u>Lb.</u>
Tank No. 1	263	2051
Tank No. 2	259	2020
Tank No. 3 (151 gal - 1162.5 lb)	302	2355
Tank No. 4 (90 gal - 693 lb)	180	1404
Tank No. 5 (146 gal - 1124 lb)	292	2278
Tank No. 6 (154 gal - 1186 lb)	308	2402
Tank No. 7 (279 gal - 2148.5 lb)	558	4352
Tank No. 8 (173 gal - 1332 lb)	346	2699
TOTAL:	2508 gal	19561 lb
Long Range Tank	500 gal	3900 lb

Fuel Flow to the Engines

10. Fuel is supplied from the fuselage tanks and wing tanks to the respective sub-system fuel flow proportioner (para 11) by tank pressurization. An electric transfer pump at each fuselage tank outlet increases the delivery pressure from these tanks to equalize the difference in pressurization between the fuselage tank and wing tanks, so that fuel from all the tanks flows into the proportioner at 19 psia (25 psia in the first aircraft).

11. The fuel flow proportioner meters fuel from the tributary tanks to ensure that all tanks empty in the same elapsed time. Fuel flows from the proportioner by a single pipe into the sub-system collector tank. The collector tank is normally maintained full, except during negative 'g' conditions or during a sustained high rate of roll. Delivery from the collector tank is maintained under these conditions by having inlets at the fore and aft corners of the tank.

12. Normally, fuel is delivered from its sub-system collector tank by a booster pump, shaft driven from the engine accessories gearbox of the engine on that side. From the collector tank the fuel passes through a heat exchanger. Downstream of the heat exchanger the two sub-systems are interconnected by a crossfeed valve. The crossfeed valve is controlled by a switch in the pilot's cockpit, and remains closed

under normal conditions. A low pressure cock is fitted between the heat exchanger and each engine.

Fuel Tank Pressurization

13. All fuel tanks are pressurized by engine bleed air taken from the air conditioning system downstream of the ram air heat exchanger. The purpose of this is to achieve fuel transfer and also to prevent fuel boiling.

14. Pressure in all wing tanks is regulated to 19 psi absolute. (25 psia in the first aircraft). Pressure in the fuselage tanks is regulated to a 10 psi differential. Transfer from each fuselage tank, due to the difference in pressure between these tanks and the wing tanks, is assisted by an electrically driven transfer pump.

15. To prevent over-pressurization through failure of air regulator, an air pressure relief valve is fitted in the air system to the wing tanks. This valve is also used as a means of venting pressure from the tanks during ground pressure refuelling. A similar valve is fitted for the fuselage tanks and performs the same functions as the wing tank valve and, in addition, it prevents over-pressurization during rapid climbs by releasing air to limit the differential between tank pressure and atmospheric pressure.

Fuel System Controls

16. A high pressure cock is fitted for each engine at the engine side of engine fuel pumps and is operated during the aft portion of travel of the throttle levers. Moving the throttles up and back from the idle position closes the HP cocks and terminates the fuel supply to the engines.

17. The low pressure cocks are controlled by two switches on the fuel control panel, marked LP FUEL COCKS and are protected by guards.

18. A three-position CROSSFEED switch is fitted on the LH console immediately aft of the throttles and is marked LH ONLY-NORMAL-RH ONLY. In the NORMAL position the crossfeed valve is closed and the isolating valves are both open. During single engine flying, in order to maintain the weight of fuel on either side approximately equal, the switch is selected to the inoperative engine side alternately with the NORMAL selection, to balance the fuel. On the second and subsequent aircraft when crossfeeding from the inoperative engine side, the FUEL PRESS warning light of the operating engine will illuminate, as the booster pump on the failed side is not

Part 1

operating. When selected to LH ONLY, the crossfeed valve is opened and the RH isolating valve is closed. The LH isolating valve remains open; thus fuel is supplied from the aft fuselage tank and LH wing tanks only. To supply fuel from the front fuselage tank and RH wing tanks, the crossfeed switch is selected to RH ONLY. This opens the crossfeed valve, closes the LH isolating valve and opens the RH isolating valve. On the NORMAL selection, with the inoperative engine throttle lever at cut-off, the operative engine will obtain its fuel supply from its own side sub-system.

Engine Fuel System Emergencies

19. Two ENGINE FUEL toggle switches, protected by guards, are located on the fuel control panel on the LH console to allow selection of emergency fuel should failure of the flow control unit occur. The switches are of the three-position type, with EMERG and RESET positions marked. The switches are spring-loaded from RESET to the centre or normal fuel position. When guards are closed the switches are automatically set in the normal fuel position. In this position the engines are automatically controlled by speed, temperature and pressure sensing devices to obtain and hold the thrust selected by the pilot.
20. When a guard is raised and the switch is selected to EMERG, the automatic fuel flow control unit is by-passed and fuel flow, partially compensated for altitude, is then directly controlled by power lever movement. The ENG EMERG FUEL warning light will illuminate when the emergency fuel selector valve is fully open.

CAUTION

When operating in the EMERG fuel selection, the turbine discharge temperature must be closely monitored. Power must be reduced immediately if there is any tendency for the temperature to increase beyond limits. Rapid throttle movements must be avoided as the emergency system does not provide the automatic overspeed, overtemperature, flame-out or compressor stall prevention features of the normal fuel control system.

21. As the compressor inlet pressure decreases with altitude, fuel flow to the engine also decreases. The emergency system will provide at least 95% military thrust on a 100° F day at low altitudes and at least 80% of military thrust at altitudes up to 30,000 feet.




FIG 1-2 FUEL FLOW (Engine)

Part 1

22. The engine may be started on the emergency system, either in flight or on the ground. The afterburner may be operated on the emergency system, in which case the throttles must be operated carefully to prevent engine overspeed and over-temperature.

23. During training or testing, and with a properly functioning fuel control system, the transfer back from EMERG to the normal system may be made. The throttle control for the affected engine should be retarded to the idle position, and the appropriate engine fuel toggle switch moved and held in RESET for five seconds. This selection will open the selector valve to the normal position and the ENG EMERG FUEL warning light will go out. The switch, when released, will take up the centre position and the guard should then be closed.

CAUTION

The solenoid operated fuel selector valve will not be energized if the switch is only moved back to the normal or centre position. The solenoid is energized in the RESET position, and then de-energized when the switch is allowed to return to the centre position.

Long Range Fuel Tank Supply

24. To be issued later.

Fuel Warning Lights

25. Warning lights for the fuel system are located on the warning panel fitted to the forward RH console. The master red and amber warning lights are located on the main panel.

26. Individual amber warning lights for the fuel system are marked and indicate as follows:

(a) FUEL LOW - Two lights are fitted to indicate low level of fuel in the LH or RH collector tanks. The illumination of a FUEL LOW light should always be accompanied by the illumination of the FUEL PROP light as the low level switch also operates the flow proportioner by-pass. Provided the FUEL LOW light illuminated through failure of the fuel flow proportioner, the automatic opening of the proportioner by-pass will allow fuel to flow to the collector tank and the FUEL LOW light will then go out. If the light stays on it indicates approximately 740 lb of usable fuel is remaining on that side.

(b) FUEL PROP - One light is fitted and indicates one of four conditions, or a

combination of these conditions, as follows:

- (1) A fuel flow proportioner has failed and the by-pass has opened. The relevant FUEL LOW warning light will also illuminate and remain illuminated until that side collector tank fuel level exceeds the low level limit. It will inform the pilot that automatic control of the fuel centre of gravity has ceased and violent manoeuvres or sustained operation at high altitude must be avoided.
- (2) Failure of the LH or RH fuselage electric transfer pumps to deliver a differential pressure in excess of 3 psi, due either a pump failure, lack of fuel in a fuselage tank, or loss of prime of a fuselage pump. The pump by-pass will automatically open and allow fuel from the fuselage tank to flow to the proportioner, but at a decreased pressure. At high altitudes fuel from the fuselage tank will not be used in proportion to fuel from the other tanks.
- (3) Either the RH or LH refuelling access door (one in each main landing gear well) is open. On the second and subsequent aircraft the door will not close if the gate is closed, which is the position used only for refuelling. This ensures that a take-off is not carried out with the gate valve in the closed position. In this position, fuel is prevented from entering the collector tank from the fuel proportioner. Only collector tank fuel would be available on that side with the gate valve closed.

CAUTION

On the first aircraft it is possible for the door to be closed with gate valve in the closed position. The FUEL PROP light only indicates the door open condition. Therefore, on the first aircraft, the exterior inspection prior to flight must include a check of the gate valve position. The two positions are marked FLIGHT POSITION- VALVE OPEN, and VALVE CLOSED-REFUEL AND DEFUEL. The flight position of the gate valve on the RH side of the aircraft is 'up' while this position on the LH side is 'down'.

- (4) The refuelling master switch on the master refuelling panel located adjacent to the LH speed brake is ON. (The access door of this panel will not close if the switch is ON).

(c) ENG EMERG FUEL - One light is fitted which illuminates when either the LH or RH toggle switch marked ENGINE FUEL on the LH console is selected to EMERG. The light is extinguished when the toggle switch is held at RESET for five seconds and

Part 1

then allowed to return to the centre position.

(d) **ENG FUEL PRESS** - A light is fitted for each engine and illuminates when the fuel pressure at the engine inlet falls below 18 psi, and indicates failure of a booster pump. The pump by-pass will automatically open and allow fuel to be delivered by a combination of tank pressurization, engine pump suction and gravity, at rates adequate to supply that engine at military power. If fuel tank pressurization fails when operating above military rating, the light will also illuminate.

Fuel Tank Contents Indicators

27. Two indicators marked **FUEL QUANTITY LBS x 1000** are fitted on the pilot's main instrument panel. The left hand indicator registers the weight of fuel in the left hand tank sub-system, while the right hand indicator registers the weight of fuel in the right hand tank sub-system. The indicators register continuously while the master electrical switch is ON.

OIL SYSTEM

General

28. The oil system on each engine is entirely self-contained and automatic. An oil tank with a usable capacity of 2.9 Imp. gals. (3.5 U.S. gals) is fitted on each engine.


Oil Pressure Warning

29. Warning of a drop of oil pressure to below 25 psi is given by the illumination of the master amber warning light and an amber light for each engine oil system on the warning, marked **OIL PRESS**.

ELECTRICAL SYSTEM

General

30. The aircraft is equipped with two 30 KVA 120/208 volt, ram air cooled alternators. One alternator is fitted to and is driven by each engine through a constant speed unit for AC power supply. In addition to supplying the aircraft AC services, each alternator supplies a transformer rectifier unit. The TRUs operate in parallel and provide 27.5 volts DC for the DC services. A hydraulically driven emergency alternator is fitted and supplies essential AC services in case of complete electrical failure. The aircraft battery supplies essential DC service for a limited period during this emergency.



Part 1

Master Electrical Switch

31. The master electrical switch is located on the forward RH console below the warning panel and is marked MASTER ELEC ON-OFF. The switch controls the complete electrics of the aircraft with exception of the services taken from the battery bus which are as follows:


- (a) Engine and hydraulic bay fire extinguishers.
- (b) Canopy actuation.
- (c) Emergency alternator solenoid.
- (d) LP cock operation to closed position only. (OFF).

Warning and Indicating Lights

32. The warning and indicating light system in the pilot's cockpit consists of the following:

- (a) One red and one amber master warning indicator, located at the top centre of the main instrument panel. The indicators are fitted with double filament bulbs.
- (b) A warning panel on the RH forward console, consisting of 25 amber lights, a master warning light PRESS-TO-RESET switch, a PUSH-TO-TEST switch and a DAY/NIGHT dimmer toggle switch.
- (c) Two red ENG BLEED warning lights located on the RH console immediately below the warning panel.
- (d) Three red fire warning lights located on the LH console immediately behind the throttle levers, marked FIRE - LH/HYD/RH.
- (e) A warning light fitted in the landing gear selector lever. (See Hydraulics - Landing Gear).
- (f) A green NAV BAIL OUT indicating light on the top centre of the main instrument panel.

33. The warning light system in the navigator's cockpit consists of a red BAIL OUT warning light located on the main panel, directly in front of the navigator.



CF 1-1005-1

FIG 1-4 MASTER WARNING PANEL

Part 1

NOTE

When the red BAIL OUT light is illuminated, an audio oscillator is energized, giving audible warning for bail out in addition to the visual warning.

Master Warning Lights and System Warning Lights

34. The master warning lights are used in conjunction with the individual system warning lights and provide a master indication any fault. They may be turned off by operating a PRESS-TO-RESET switch on the warning light panel. The system warning light will remain on, however, until the fault has been cleared. The PRESS-TO-TEST switch on the warning light panel is used to test the filaments of the following lights:

- (a) Master Warning Lights.
- (b) System warning lights on the panel.
- (c) Fire indication warning lights.
- (d) Air conditioning engine bleed warning lights.
- (e) Warning light in the landing gear selector lever.
- (f) NAV BAIL OUT light in the pilot's cockpit.

35. The warning light panel has 25 lights covered by amber coloured lens caps, upon which is inscribed the system served. The lights function as follows:

- (a) FUEL LOW, LH and RH - indicates a low level of fuel in the LH or RH fuel collector tank. The FUEL PROP light will illuminate also.
- (b) FUEL PROP - Indicates any of the following four conditions:
 - (1) A fuel flow proportioner has failed.
 - (2) A LH or RH fuselage electric transfer pump has failed.
 - (3) The LH and/or RH refuelling adaptor door(s) are open.
 - (4) The master refuelling switch is ON.
- (c) ENG EMERG FUEL - Illuminates when the ENG FUEL switch is

selected to EMERG.

(d) ENG FUEL PRESS, LH and RH - Indicates that fuel delivery pressure to the LH or RH engine pumps is less than 17.3 psia. The light will go out if the pressure rises to 18.3 psia.

(e) OIL PRESS, LH and RH - Indicates that the oil pressure of the LH or RH engine is 25 psia or less.

(f) FLY CONT HYD - Two indicator lights are provided. The LH one serves the 'B' flying control hydraulic system and the RH one serves the 'A' flying control hydraulic system. They illuminate if the particular system pressure is less than 1000 psi.

(g) UTIL HYD - Indicates when the utility hydraulic system pressure is less than 1000 psi.

(h) EMERG BRAKE HYD - Indicates when the emergency brake accumulator pressure is less than 1600 psi, and is insufficient for the use of brakes upon landing.

(j) AC FAIL, LH and RH - Indicates a phase failure in the LH or RH AC system, and will be accompanied by the illumination of the single light marked DC FAIL, L or R.

(k) DC L or R FAIL - One light indicates for both T.R.Us. It will denote failure of both T.R.Us if the BATT USE light also illuminates. If the DC FAIL light illuminates on its own it will indicate that one TRU has failed.

(m) BATT USE - Indicates when the aircraft battery alone is supplying the DC power.

(n) ROTOR O'SPEED, LH and RH - Indicates when the LH or RH engine low pressure compressor is overspeeding.

(p) CABIN PRESS - Indicates when the cabin altitude exceeds 31,000 feet.

(q) AIR COND FAIL - Indicates when the air conditioning cooling turbine outlet temperature has exceeded 80°F. (On the first flights of the first aircraft the light will indicate a cockpit inlet temperature of more than 240°F).

(r) EQUIP O'HEAT - Indicates when the equipment air supply temperature has exceeded 100°F.

Part 1

- (s) ICE - Indicates icing conditions in either or both engine air intakes.
- (t) EMERG DAMP - Indicates that emergency damping on the rudder is in use. The R - P AXIS OUT light will also illuminate.
- (u) DAMP OUT - Indicates no damping system is operating.
- (v) R - P AXIS OUT - Indicates that the Roll and/or Pitch axis damping system is not operating.

Master Warning Control Unit

36. The master warning control unit is located in the LH side of the nose wheel well and operates the warning lights in the following manner:

- (a) On receipt of a fire signal, the master RED warning will illuminate together with the appropriate RED fire warning light.
- (b) On receipt of a signal from either the 'A' or 'B' flying control hydraulic system, the master AMBER warning light will illuminate together with the associated AMBER light on the warning panel. Should both 'A' and 'B' systems fail simultaneously or consecutively, both RED and AMBER master warning lights will illuminate together with both A and B system AMBER lights on the warning panel.
- (c) When the pilot selects Engine Emergency Fuel, the illumination of the appropriate AMBER light on the warning panel will remind the pilot that he is using this selection. No master warning light signal is given. In addition, the light will provide an indication to the pilot prior to take-off that an engine fuel system is energized to the emergency selection, coincident with an ENGINE FUEL selector switch being in the normal position. This would indicate that an engine had been shut down while operating on the emergency system, and that the selector switch had inadvertently been moved to the normal position without first being held in RESET for five seconds. The particular engine must be operating in order to make a selection of the ENGINE FUEL normal-emergency system.
- (d) Any of the remaining lights on the warning panel will be energized simultaneously with the master AMBER warning light on receipt of a warning signal.

NOTE

No master warning indication is given when the air conditioning ENG BLEED warning light or lights illuminate.

AC System

37. The engine driven alternators supplying AC power are controlled by two switches on the RH forward console, marked ALTERNATORS ON - RESET - OFF.
38. Failure of an alternator is indicated by the illumination the master amber warning light and the appropriate LH or RH AC FAIL light on the warning panel. This will also cause the DC FAIL light to illuminate. The alternator may be reset by moving the ALTERNATOR switch to RESET and back to ON. If the reset is successful the AC FAIL, DC FAIL and master amber lights will go out; alternatively, only the AC FAIL light may go out. In the latter case, the DC RESET button should be pressed, and a successful reset will be indicated by the DC FAIL and master amber light going out. If the fault has not cleared the AC FAIL will again illuminate, in which case the switch should be left in the off position.
39. Normally, the RH alternator supplies the AC power requirements. Should the RH alternator fail, the LH alternator assumes the load. Should the LH alternator fail, no change in power supply will be apparent. The operating alternator will supply, through its TRU, all DC services except the landing and taxi lights.
40. An emergency alternator is fitted to provide electrical power to essential services in the event of complete electrical failure by energizing a solenoid shut-off valve which diverts utility hydraulic fluid to a hydraulic motor which in turn drives the alternator. Sufficient power is supplied to operated the emergency damping system, artificial horizon, J4 compass and IFF until a relight is obtained. In case of a double engine flame out, one wind-milling engine will maintain sufficient utility hydraulic pressure to drive the motor.

DC System

41. The transformer rectifier units (TRU's) are fed from their respective main AC bus-bars, and the output is fed to the main DC bus.
42. Failure of a single transformer rectifier unit is indicated by the illumination of the master amber warning light and the DC L or R FAIL light on the warning panel. The operating TRU will provide all DC services except the landing and taxi light. Failure of both TRU's will be indicated by the illumination of the DC FAIL light and the BATT USE light on the warning panel. The illumination of the BATT USE light signifies that the DC supply to the emergency bus and battery bus is being taken from the aircraft battery. The main DC bus supply will be automatically

Part 1

shed.

43. A push button switch is fitted on the RH console in the front cockpit marked DC RESET. If the DC L or R FAIL warning light illuminates alone or in conjunction with the BATT USE warning light, either or both TRU's may be reset, provided the fault has been cleared, by pressing the DC RESET button.

44. The DC system maintains the battery charged, therefore if the BATT USE light illuminates, the battery is discharging. The following services will be available from the battery through the DC Emergency Flight Bus for approximately 20 minutes, depending on the original battery charge and the number of services operated:

- (a) Landing Gear Indication.
- (b) Fire Detection.
- (c) Canopy Seal.
- (d) Speed Brake Actuation.
- (e) Warning Light System.
- (f) Emergency Cockpit Lights (Emer. Flood Light).
- (g) Turn and Slip Indicator.
- (h) Ignition (Relight).
- (j) ARC/34 UHF
- (k) AIC/10 Intercommunication.
- (m) DC Damping (Yaw)
- (n) IFF (APX/6A)
- (p) Hinge Moment Limiter
- (q) Engine Emergency Fuel Selection
- (r) Bail Out Indication

NOTE

The landing gear selector valve is operated by the main DC supply. If the BATT USE light is illuminated, the landing gear cannot be unlocked by the normal selection. However, it can be unlocked by using the emergency extension procedure. (See Part 3, Para 7).

Engine Starting Services

45. The engines may be started individually or simultaneously by motoring of a ground starter cart which supplies compressed air to the turbine starters and a 28 volt DC supply for ignition. Leads from the cart to the aircraft comprise two air hoses and an electrical supply connector. Incorporated in the connector are intercommunication leads which allow the pilot to communicate with the ground control centre, the navigator, and the ground starting crew. These connections are automatically withdrawn from the aircraft by means of lanyard releases when the aircraft commences to taxi. When the aircraft is being towed, a lead from the towing vehicle to the aircraft receptacle enables intercommunication between the cockpit occupant and the driver of the towing vehicle.
46. When the supply connector from the ground starter cart is plugged into the aircraft receptacle, the aircraft battery supply is automatically cut-off, thus preventing any drain on the aircraft battery during starting. (Not applicable to the first aircraft).
47. The starting system consists essentially of an air turbine starter and an ignition system for each engine. The air supply to the air turbine starters is controlled by the ENGINE - START/OFF/RESET switches, one for each engine, which are spring loaded to OFF. The ignition supply is energized by a centrifugal switch operated when an engine speed of 700 rpm is attained. A second centrifugal switch is operated at 3020 rpm, to de-energize the ignition system.
48. An ENGINE START switch may be momentarily selected to RESET if it becomes necessary to interrupt the starting cycle. This de-energizes the 'locked' starting relay and resets the system for a further start. The RESET position is also used for motoring the engine without ignition.
49. An external supply socket is also provided for an external supply of AC current. This supply should be plugged into the aircraft prior to engine starting to enable AC instruments, particularly the turbine discharge temperature gauge, to

Part 1

operate. The supply is also used for ground servicing checks. On later aircraft, an AC supply from the starter cart will be available.

FLYING CONTROL SYSTEM

General

50. The ailerons, elevators and rudder are fully power operated, utilizing hydraulic pressure supplied by two pumps on each engine. The hydraulic components are controlled electrically or mechanically through cables and linkages; there being no direct mechanical control.

51. There are three modes of control of the aircraft in its final configuration, the normal mode, the automatic mode and the emergency mode. The automatic flight mode will not be installed in early aircraft.

52. In the normal mode, a damping system automatically stabilizes the aircraft in all three axes and co-ordinates rudder movement with movement of the ailerons and elevators. Control in the normal mode is by means of an electrical force transducer fitted in the control column handgrip.

53. In the automatic flight mode (when fitted), the damping system is operative as in the normal mode, but aileron and elevator position is controlled by an Automatic Flight Control Sub-system (AFCS). The AFCS allows the aircraft to be controlled from the ground for Automatic Ground Control Interception (AGGI) or for Automatic Ground Control Approach (AGCA). It also provides certain pilot assist functions by holding any set course or altitude, or it may hold any set Mach number by varying the aircrafts pitch attitude. It also provides for automatic navigation by controlling the aircraft according to information fed into a dead reckoning computer by the navigator. An AFCS disconnect push button switch is fitted on the control column handgrip. When the AFCS is disconnected by this switch, the damping system reverts to the normal mode.

54. In the emergency mode the hydraulic components for operating the ailerons and elevators are controlled mechanically. Yaw stabilization and rudder co-ordination are maintained by an emergency yaw damping system.

55. Pilot feel at the control column is provided by the damping system in the normal mode, and by spring feel in the emergency mode.

56. If certain flight limitations are exceeded, the system automatically changes over to the emergency mode.

57. Elevator and aileron trim is obtained by means of a four-way switch on the control column, while rudder trim is obtained by a toggle switch on the

pilot's LH console. Trimming alters the position of the entire control surface. A CONTROL SURFACE RESPONSE indicator is mounted on the LH console and shows the amount of movement of the control surfaces in relationship to the main surface. In the case of the rudder and elevator, movement of these control surfaces will be shown in the natural sense on the indicators. In the case of the aileron, movement of the ailerons will be indicated as the resultant wing movement from the trim action; i.e. LW DOWN and RW DOWN. In later aircraft to reduce elevator trim drag at altitude, the ailerons are automatically deflected upwards by means of a pressure switch, which operates at approximately 45,000 feet. The switch opens when the aircraft descends to 42,000 feet and the ailerons return to their normal position.

Hydraulic System.

58. Two independent hydraulic systems are employed, one pump on each engine supplies the 'A' system while the other pump on each engine supplies the 'B' system. The supply is 4000 psi; an accumulator in each system prevents fluctuations. The lowering or loss of pressure in a system to 1000 psi or less will illuminate the appropriate warning light on the warning panel. The lights are marked FLY CONT HYD and the LH light indicates for the 'B' system, while the RH light indicates for the 'A' system.

59. The 'B' system supplies the control surface actuators and damping servos for pitch, roll and yaw damping. The 'A' system supplies the control surface actuators and damping servo for emergency yaw damping.

60. In the event of loss of one engine or loss of one system, adequate control is still available. Rates of control movement may be slower with one engine failed. With either system failed, the available 'g' at high speeds will be restricted. With the 'B' system failed the aircraft will be in the emergency mode of flying control.

Ram Air Driven Turbine (Not fitted on the first flights of the first aircraft).

61. In later aircraft a ram air driven turbine is installed in the LH side of the fuselage for use in the event of a two-engine flame-out. When selected by the pilot, the turbine extends horizontally into the airstream thus driving a hydraulic pump. The pump is connected to the 'A' hydraulic flying control system and supplies sufficient hydraulic pressure to enable the flying controls to be operated at all speeds from 350 knots down to a landing speed of 140 knots.

Part 1

CAUTION

The maximum speed for extending the ram air turbine is 350 knots EAS. The aircraft must not be flown above this speed with the turbine extended.

62. The turbine is extended into the airstream by a jack operated from the utility hydraulic system, and controlled by a switch on the RH console marked RAM AIR TURBINE.

NOTE

Under a two-engine flame out condition, the utility hydraulic system maintains its pressure from the windmilling engines. Should one engine be seized, the single windmilling engine will maintain the pressure.

63. Under a two-engine flame out condition, emergency AC power is maintained by the emergency alternator driven by a motor through the utility hydraulic system, provided that at least one engine is windmilling.

Damping System

64. The damping system provides artificial stabilization in flight. Unstable tendencies are picked up by sensors and adjustments are made to the control surfaces. The pilot is unaware of the corrections being made. As the damping in the yaw axis is of major importance in the higher speed range, duplicated electrical and hydraulic supplies are installed for the rudder control. The damping system comprises three distinct channels, the pitch channel which controls the elevators, the roll channel which controls the ailerons and the yaw channel which controls the rudder.

65. Switches for controlling the damping system are located on the pilot's LH console, and on the control column. Eight DAMPING CIRCUIT BREAKERS are fitted outboard of the DAMPER control panel. The rear group of four are in the NORMAL damping circuit, while the forward group of four are in the EMERGENCY damping circuit. The breakers are a protection against excessive current drain and will not reset if the circuit is overloaded. They also provide a secondary means of switching should the

normal means of damper disengagement fail to operate. Mounted on the DAMPER panel are the following controls:

- (a) A POWER ON-OFF toggle switch protected by a guard. When selected "ON" power is supplied to the damping system and AFCS.
- (b) An ENGAGE push button switch for engaging the normal mode of operation, or for re-engaging the aileron or elevator damping if they have been automatically disconnected through excessive manoeuvring. Normal mode must be selected before the emergency mode can be selected.
- (c) An EMERG push button switch for selecting the emergency mode of damping (i.e. to disengage the normal mode). This switch will be deleted on later aircraft.

66. Two push button switches are fitted on the control column grip. One switch reverts the damping system to the emergency mode (i.e. it disengages the normal mode) acting the same as the EMERG switch on the DAMPER panel. The other switch disengages the AFCS system (if fitted), and leaves the damping system in the normal mode.

67. In the normal and AFCS modes, damping is effective on the elevators, ailerons and rudder. When the landing gear is selected down damping of all the control surfaces is modified as follows:

- (a) In the roll axis, sufficient damping is retained in order to help in counteracting "dutch roll", (in conjunction with the yaw axis).
- (b) In the yaw axis, the modified damping allows intentional sideslip to be introduced, although any transient yaw will be corrected.
- (c) In the pitch axis, damping is retained to a limited extent. Any excessive instability left uncorrected by the damper will be easily counteracted by the pilot.
- (d) Pilot "feel" at the controls changes. (See para 77).

68. In the emergency mode only rudder damping is effective.

NOTE

In order to test the damping system when the aircraft is on the ground and simulate landing gear UP conditions, a DAMPER TEST push button marked U/C UP MODE is fitted at the rear of the LH console in the pilot's cockpit.

Part 1

Depressing and holding the button will disengage the landing gear "down" micro-switch and allow damping system to be checked as in a landing gear "up" condition.

Damping System Warning Lights

69. Malfunction of the damping system is indicated by the illumination of the master amber warning light and the system warning light or lights on the warning panel. Three lights are fitted on the warning panel for the damping system. They are marked and function as follows:

(a) EMERG DAMP - Illuminates when emergency damping only is in operation, i.e. damping is operative on the rudder only, and can occur for the following reasons:

(1) By automatic reversion to the emergency mode by excessive sideslip or side acceleration. (See para 90). The R/P AXIS OUT light will also illuminate.

(2) By manually selecting EMERG on the DAMPING SYSTEM panel or the disengage switch on the control column. The R/P AXIS OUT light will also illuminate.

(b) R/P-AXIS OUT - Illuminates when either the elevator and/or aileron damper is cut out automatically by excessive pitch or roll. (Provisionally 4-1/2 to 5 g in pitch and 1590 per second in roll). It will also illuminate in conjunction with the EMERG DAMP light.

NOTE

After the manoeuvre the axis or axes may be re-engaged by pressing the ENGAGE switch on the damper panel.

(c) DAMP-OUT - Illuminates when all damping is inoperative and can occur for the following reasons:

(1) When the master electrics switch is turned on after entering the aircraft and the DAMPER POWER switch is either OFF, or ON with no mode selected.

(2) When a change over is made to emergency mode for any reason but the 'A' hydraulic system, supplying the emergency yaw damper, is unserviceable.

NOTE

An emergency alternator automatically supplies AC power to the emergency damping system (also to the artificial horizon, J4 Compass and IFF) in case of complete electrical failure.

PITCH AXIS

Pilot Command Control

70. In the normal mode of flying control, when the pilot exerts a force on the control column grip to move the elevators, a force transducer on the control column transmits an electrical signal. Similar signals are transmitted by ground control, when the AFCS mode, without pilot operation of the control column. In both cases the signals are fed to servos, which convert the electrical signals into a mechanical movement by means of hydraulic pressure. The servos are known as parallel (or command) servo and differential (or damping) servo. Additional signals enter the differential servo, depending upon outside forces acting on the aircraft, to maintain stability. These servo units alter the position of the elevator control valves through linkages and quadrants. The valve movement directs the hydraulic pressure to the appropriate side of a hydraulic jack, resulting in movement of the elevators.

71. In the normal mode, the electrical output at the transducer is directly proportional to the force exerted at the grip. The control column will move as the force is exerted, as with a conventional flying control system, but it is not moved directly by the pilot. Movement of the control column follows the positioning of the elevators by the command circuits, but as the response of the system is instantaneous, the control column will appear to be moved by the pilot.

72. In the normal and AFCS modes the hydraulic pressure in the parallel servo can be overpowered by a force of 70-90 lb. at the control column (the force depending upon flight conditions) although the immediate action for a malfunction in these modes would normally require disengagement of the particular flying control system in use at that time.

73. In the emergency mode the parallel servo is disengaged. Movement of the control column does not send electrical signals from the transducer to the parallel servo, but moves cables and a mechanical link

Part 1

system which operates the hydraulic actuator control valve. Thus the elevators are finally moved by hydraulic pressure as before.

Trim Control

74. In the normal and emergency modes, up and down movement of the trim button will result in movement of the elevator control surfaces. In the normal mode the control surface movement is achieved by the transmission of an electrical signal which moves the elevators in the same manner as would hand pressure on the control column.

75. In the emergency mode, a feel-and-trim unit is called into use. This unit is a spring-loaded assembly which supplies a feel on the control column during flight in the emergency mode. When the aircraft is trimmed, an electrically operator actuator changes the neutral length of the feel-and-trim unit, to move the elevators up or down as required. The unit also ensures that upon a change-over from the normal mode to the emergency mode there is no movement of the elevators and pilot feel remains unchanged. However, a change in feel will be noticeable upon moving the control column after the change-over. A 'g' bob-weight is fitted at the end of a lever in the elevator control system. The purpose of the weight is to induce a load on the control column under 'g' conditions, and so make the control column progressively more difficult to pull as 'g' is increased. When no 'g' is being imposed a balance spring counteracts this weight. In the normal mode of control the bob-weight is not felt at the control column due to the normal feel system.

76. The emergency mode trim unit is not called into use during the normal mode of control but rides freely, although any seizure of the unit or a runaway trim motor would, unless guarded against, affect movement of the elevators. A switch operated release mechanism is fitted. The switch, protected by a guard, is located on the pilot's forward LH console and is marked ELEV TRIM-DISENGAGE.

Pilot Feel in the Normal Mode

77. An electrical feel system is used for normal mode flight. The stick force required to move the elevators is made to feel proportional to the amount of 'g' pulled. For a particular 'g' the stick force requirement is constant irrespective of speed or altitude. With the landing gear selected down, feel is directly proportional to the degree of displacement of the elevator control surfaces, without regard to airspeed or altitude. (Pilot feel in the emergency mode - See para 75).

G Limits

78. The stick force transducer is set to limit pilot imposed 'g' to a value of 4-1/2 to 5 g, but if through component malfunctions this value is exceeded, the normal mode of control in the pitch axis disengages automatically and control reverts to emergency mode. Upon change-over the aircraft may require to be manually re-trimmed. In the emergency mode, the 'g' bob-weight is felt at the control column under 'g' conditions. G limiting is then under the control of the pilot.

79. The pitch axis will also disengage should the yaw axis monitor operate due to excessive skid, sideslip or transverse acceleration. (See para 90).

ROLL AXIS

Pilot Command Control

80. In all modes of flying control the operation of the ailerons by means of signals, or by cables, is identical to the operation of the elevators. (See para 70). Components in the system differ slightly - for instance in place of an accelerometer, the aileron system utilizes a roll rate gyro, but from the pilot's point of view, the systems operate in a similar manner.

81. In the medium speed range, the system is designed to produce a rate of roll in proportion to the force applied to the control column handgrip. At high or low speeds the force required for a given rate of roll is increased slightly.

82. When a turn is initiated and the required amount of bank angle is obtained, release of pressure at the control column grip will return the ailerons and the control column to the neutral setting. The turn will be maintained by elevator; "holding off bank" will be required but to a lesser extent than on conventional aircraft. Damping on the roll axis is in effect at all times.

83. When the landing gear is selected down, movement of the ailerons is directly proportional to control column movement. With the landing gear up airspeed is a governing factor in amount of aileron movement, within the limitation set by the maximum roll rate of 159° per second.

Turn Co-ordination

84. When force is applied to the control column to initiate a turn, signals are transmitted which effect the deflection of the rudder in a direction appropriate to turn the aircraft and overcome adverse yawing

Part 1

movement resulting from the aileron movement. When the aileron ceases its movement, the rudder is automatically returned to its neutral position. Any further yawing moment in the turn is counteracted through a transverse accelerometer affecting the yaw damper.

Trim Control

85. In the normal mode of control, lateral trim is obtained by operating the control column trim button in the appropriate direction until the ailerons have moved the desired amount. In the emergency mode of control the effect of moving the trim button is the same, although aileron movement is obtained by means of the trim actuator instead of through the command servo. Electronic feel of the ailerons is cut out during the emergency mode of control. The springs of the feel-and-trim unit have to be compressed when the control column is moved, thus providing feel. A pressure trim circuit ensures smooth re-engagement upon change-over from emergency mode to normal mode; however, the aircraft may require to be trimmed laterally for straight and level flight in the normal mode.

Roll Rate Limits

86. To prevent overstressing the aircraft structure, the roll axis damping system disengages if the roll rate exceeds 159° per second. The system will also disengage should the yaw axis monitor operate due to excessive skid, sideslip or transverse acceleration. (See para 90).

YAW AXIS

General

87. The yaw damping system provides directional damping and rudder turn co-ordination when in the normal mode of control. The system is duplicated in order to provide emergency yaw damping and turn co-ordination in the event of failure of the normal system, or should control of the aircraft be reverted to the emergency mode. Should failure of the electrical supply to the damping system occur, an emergency hydraulically driven alternator automatically supplies power for emergency yaw damping.

88. In all modes of control, rudder is automatically co-ordinated with aileron movement. In an emergency in the normal mode, the rudder may be moved by means of the rudder bar if sufficient force is used. A force-switch is incorporated which requires a force of thirty pounds to overcome.

89. When the landing gear is selected down, the yaw damping signal is

modified in order that a certain amount of intentional yaw may be applied by the pilot without opposition from the system. Although the pilot has this control if required, stability about the yaw axis is maintained.

Yaw Rate Limits

90. Automatic disengagement occurs if, due to a fault in the normal damper system, 10° of sideslip is exceeded or the aircraft exceeds a preset yaw acceleration. Control of all three axes is then in the emergency mode, i.e. only the emergency yaw damping is effective.

Rudder Trim, Feel and Hinge Moment Limitation

91. The rudder may be trimmed by a toggle switch located on the pilot's LH console marked RUDDER TRIM LEFT/RIGHT. Operating the trim switch moves an actuator, and through linkage alters the rudder hydraulic jack control valve. The movement of the rudder by the trim circuit changes the no-load position of the rudder bar.

92. Rudder 'feel' is provided by a feel unit and the system also incorporates a hinge moment limitation linkage. The system functions automatically, and its action is to decrease the amount of rudder movement for a given force on the rudder bar as the aerodynamic loading on the rudder increases. This limitation also is effective in the trim circuit.

AUTOMATIC FLIGHT CONTROL SYSTEM (When fitted)

93. In the AFCS mode, either pilot assist functions or fully automatic functions may be selected on the selector panel.

94. The pilot assist functions are normal AFCS, mach hold and altitude hold. The automatic functions are Automatic Ground Control Intercept (AGCI), Attack, Automatic Navigation and Automatic Ground Control Approach (AGCA).

95. In the normal AFCS mode heading hold, roll attitude and pitch attitude hold are maintained, provided certain attitude limits are not exceeded. Heading will be maintained provided the aircraft is not banked at an angle in excess of 7-1/2°. A change in heading is made by movement of the control column. This action will disconnect the heading reference when the bank angle exceeds 7-1/2°. The aircraft is then levelled at the new heading and the control column is released. This new heading will be maintained. If the control column is released during a turn, the turn will be maintained provided the bank angle is less than 76°. If the bank

Part 1

is more than 760 only stabilization in roll is provided. In the pitch axis, an angle of climb or dive will be maintained upon release of the control column, provided the climb or dive angle is less than 550.

96. Any malfunction occurring in the AFCS mode will call for immediate manual disengagement of the system, although in later aircraft this disengagement may be made automatic. In this case a warning that the AFCS had been automatically disengaged will be incorporated.

97. A failure of the system when the aircraft is performing a 'g' manoeuvre will, by means of the spring of the trim unit, automatically ensure that 'g' is reduced in the pitch axis to $\pm 1/2$ 'g' of 1 'g' flight, provided no force is applied to the control column.

AIR CONDITIONING SYSTEM

General

98. The air conditioning system is supplied with hot air bled from both engine compressors. A certain proportion of this hot air is cooled by means of three components; an air to air heat exchanger which cools engine bleed air by ram airstream, an air to water heat exchanger which cools conditioned air by heat transfer to distilled water, and a cooling turbine and fan. Various types of controllers and air valves served by thermostats and sensors are fitted which serve to maintain the selected conditions of air in the system during various airspeed and altitude conditions.

NOTE

The temperature and pressure of the engine bleed air varies according to flight conditions.

99. Ground equipment can be connected to the system for cooling the electronic equipment when the aircraft is on the ground.

100. The air conditioning system fulfills the following functions:

- (a) Supplies hot and cold air to maintain cockpit pressure and temperature within the required limits.
- (b) Maintains the required temperature levels in areas where heat is generated by electrical and electronic equipment.
- (c) Supplies air for fuel tank pressurization, windscreen rain repellent (if fitted), the low pressure pneumatic system and the liquid

oxygen converter. Discharged air from the cockpits is used to cool and scavenge the armament bay.

Cabin Pressurization

101. The cabin pressure remains the same as the outside air up to 10,000 feet. Above this altitude the differential between cabin pressure and aircraft pressure altitude increases linearly until a differential pressure of 4.5-5 psi would be reached at 60,000 feet. A safety valve is fitted in the rear cockpit which opens to release cabin pressure if at any time it reaches 5.25 psi, and closes when pressure returns to 4.5 psi.

102. Cabin pressure altitude is shown on a gauge fitted on the RH side of the instrument panel in the pilot's cockpit and is marked CABIN PRESSURE.

103. A CABIN PRESSURE amber warning light is fitted on the warning panel. The master amber warning and the CABIN PRESSURE warning will illuminate if at any time the cabin altitude reaches 31,000 feet (± 1800 feet) or higher.

Cockpit Controls

104. The air conditioning controls are grouped together on a panel at the rear of the RH console in the pilot's cockpit and comprise the following:


(a) A temperature setting rheostat switch marked TEMP/COOL-WARM.

Movement of the switch from COOL to WARM will result in an increase of cabin temperature within the range of approximately 40°F-80°F.

(b) A DEFOG switch with ON/OFF positions. In the case of fog forming in the cabin, selecting the switch to ON will rapidly raise the cabin temperature to approximately 90°F thus overriding the rheostat temperature selection. An automatic control prevents the cabin temperature from rising above 140°F in case of failure of a temperature control component.

(c) An AIR SUPPLY switch with NORM-OFF-EMERG positions which controls as follows:

(1) In the NORM position air is delivered to the cabin at a temperature determined by the setting of the TEMP/COOL-WARM rheostat. Outlets in the cockpits are located on either side of the seats and at floor level. During taxiing and take-off the amount of air supplied to the cockpits is reduced. When the landing gear is raised after take-off a micro-switch is actuated which fully opens the cockpit air shut-off valve and allows full



TMI-2705-3

FIG 1-5 PRESSURIZATION GRAPH

air supply to the cabin. Lowering the landing gear will reduce the air supply by nearly closing the valve. Pressurization of the cockpits commences when the aircraft reaches an altitude of 10,000 feet. During flight, the equipment areas comprising the nose radar, alternator control, oxygen converter, fuselage electronics, fire control, dorsal electronics and the aircraft battery are maintained at a temperature of between 80° - 90°F by air from the system. The armament bay is cooled by discharged air from the cockpits, and this air also scavenges the armament bay of fumes.

(2) In the OFF position, all valves in the system are closed; this selection is made under the following conditions, provided low engine rpm are not in use at the time.

a. Upon illumination of the master amber warning light and the EQUIP O'HEAT light on the warning panel.

b. Upon illumination of the master amber warning light and the AIR COND FAIL light on the warning panel.

c. Upon failure of the cooling air flow to the cabin. At high speeds this will result in high cockpit temperatures due to kinetic heating.

To lower the temperature under the above conditions, (provided that low engine rpm are not the cause), the OFF position must be selected and the aircraft speed reduced immediately to below Mach 1.2. This selection will close the main air shut-off valve, and the cockpit air inlet valve, thus shutting off all air supply to the cockpit. A signal will also be supplied to shut off the electronic equipment in the nose radar compartment. (When radar is fitted). When speed has been reduced the switch should then be selected to EMERG, which opens the ram air supply valves.

(3) In the EMERG position emergency ram air valves are opened and ram air is used to cool the same equipment areas that were previously cooled under normal operation except for the nose radar equipment which is automatically switched OFF. The cockpit air supply valve remains closed to altitude may have to be reduced as any further pressurization of the cabin will cease. Cabin pressure will fall at the natural leakage rate of the cabin.

(d) A two position switch marked CABIN PRESS and DUMP. The switch must be in the CABIN PRESS position for cabin pressurization to take place. In the DUMP position the cabin safety valve is opened and any pressure existing at the time is discharged through the valve; no further cabin

Part 1

pressurization will take place with the switch in this position. Air conditioning of the armament bay ceases when the DUMP selection is made.

(e) A toggle switch marked TEMP CONTROL-EMERG OFF. When selected to EMERG OFF this switch shuts off the supply of hot air to the cabin and the equipment areas. Cool air continues to flow to provide cabin pressurization and equipment cooling.

Safety Provisions in the System

105. Should the cooling turbine outlet temperature exceed 800°F, the AIR COND FAIL warning light will illuminate. (See para 104).

106. Should the temperature of the supply air to the equipment areas exceed 1000°F, the hot air supply in these areas is automatically cut off and the EQUIP O'HEAT warning light will illuminate. (See para 104).

107. The hot air valve of the cabin air supply will automatically close if the temperature of the air to the cockpits reaches 2400°F. The valve will open again when the temperature has decreased to 1000°F.

108. Two red warning lights are fitted above a three way toggle switch on the forward RH console. The lights are marked ENG BLEED, and arrows indicate their particular engine. The switch is marked ENG BLEED AIR, with three positions LH OFF-NORMAL-RH OFF. A particular ENG BLEED light will illuminate should a leakage of engine bleed hot air occur in the ducting to the air-to-air heat exchanger, or should the bleed air reach an excessive pressure through failure of a pressure reducing valve. Selecting the switch to the appropriate side indicated by the warning light (i.e. LH OFF or RH OFF), will close the shut-off valve in the engine bleed air supply duct on that side. If the condition is relieved, the warning light will go out.

NOTE

Red lights are used as no master warning light illuminates.

Single Engine Flying

109. If one engine is shut down, or a drop in pressure of the engine bleed air to the heat exchanger occurs for any reason, a pressure switch is operated and a signal shuts off the electronic equipment in the nose compartment. (Aircraft with radar fitted).

System Operation with Landing Gear Down

110. When the landing gear is lowered, a switch operated by the main door uplock is actuated. This action almost closes the cockpit air shut-off valve to conserve the air supply. Flaps in the ram air ducts are also opened when the landing gear is lowered to connect the turbine fan inlet with the ram air intakes.

COCKPIT CANOPIES

General

111. The front and rear cockpits each have an independently operated two-piece canopy. Each canopy is normally opened or closed by electrical actuators controlled by switches, and is locked or unlocked manually by a lever which operates latches.

112. Power for canopy actuation is supplied from the battery bus so that opening or closing can be carried out when the master electrical switch is off.

NOTE

The canopies should only be opened or closed once during a flight cycle when using the aircraft battery. If more than one operation is required and provided the engines have not been started, a starting cart or ground supply should be used. This will prevent excessive drain on the aircraft battery.

113. Provision is made to open the canopy in an emergency by means of gas generating cartridges which may be fired either from inside or outside the aircraft. In case of seat ejection, a canopy is opened and the seat is ejected by pulling a large overhead firing handle down over the face, or alternatively by pulling the alternative fire handle on the seat pan. (See para 216).

Normal Operation

114. A switch marked CANOPY/OPEN-OFF-CLOSE is located in each cockpit on the LH console and controls the operation of the canopy for that cockpit. The switches are spring loaded to OFF and must be held in the required position until the operation is completed. The canopy locking lever must be fully back before the canopy open-close switch is operative.

Part 1

115. When the canopy has been fully closed by the switch, it is locked by means of an overhead lever which is pushed fully forward manually by the cockpit occupant. Pulling down and moving the lever to the first detent will latch or lock the two halves of the canopy together. It must then be pulled down and moved fully forward. It will engage a switch and, provided the other canopy is closed and locked, will operate the canopy seal pressurization valve and inflate the seals of both canopies. When a canopy is locked, the canopy open-close switch is de-energized and is inoperative. The lever is held in the fully forward position by a spring loaded plunger.

116. The canopy is opened when the aircraft is on the ground by pulling the overhead lever down and fully to the rear. The first rearward movement of the lever will deflate the seal of both canopies. As the lever passes the first detent position it unlocks the two halves of the canopy. When the lever is fully back the canopy open-close switch is energized and holding this switch in the open position will fully open the canopy.

Normal Operation from the Ground

117. The canopies may be opened or closed from outside the aircraft by means of two switches, one for each canopy, fitted on the canopy arch. The switches are marked CANOPIES/OPEN-OFF-CLOSE and are spring loaded to OFF. If a canopy is locked, then that particular switch is de-energized and is non-operative.

Emergency Opening from the Ground

118. If the canopies are locked, the CANOPY OPEN-CLOSE switches outside the aircraft are inoperative. In an emergency the canopy locks can be released and the canopies opened by gas cartridge pressure.

119. An access door located on the RH side of the aircraft nose below the pilot's cockpit, marked EMERGENCY CANOPY OPENING must be opened. Located inside is a lanyard, which is attached to the canopy emergency opening lever in both front and rear cockpits. Pulling this lanyard down moves the emergency levers in both cockpits and fires gas generating cartridges. Gas pressure is released which first unlocks the canopy locking levers and then operates the emergency jacks, which open the canopies. When the emergency jacks are operated a shear pin on the electrically actuated jacks is sheared. When opened by this method the canopies open slightly more than for normal opening.

Emergency Opening in the Air

120. Each canopy may be opened individually in an emergency when in flight by operation of the emergency lever fitted on the RH side of each cockpit.

121. After an emergency canopy opening lever has been pulled, the operation of the gas generator and jacks is the same as in para 119.

NOTE

When a canopy is opened by the cartridge operated system the electrically operated jack is sheared, preventing closing of the canopy.

122. If the emergency canopy opening system fails to function, the canopies may be opened over a limited speed range by the normal operating jacks controlled by the CANOPY OPEN-CLOSE switches. Further information will be issued later.

LIGHTING EQUIPMENT

Cockpit Lights

123. A panel, marked COCKPIT LIGHTING, is located on the RH console in both front and rear cockpits. A toggle switch and three rheostat switches are fitted on each panel to control the lighting. An emergency flood and map light, powered from the DC emergency bus, is provided on the RH side of each cockpit and is controlled by a press switch on the light. The individual switches on the panel control are as follows:

- (a) A rheostat switch marked MAIN PANEL-OFF/BRIGHT, controls the main instrument panel red instrument lights. Power is taken from the main AC bus.
- (b) A rheostat switch marked CONSOLE PANELS-OFF/BRIGHT controls the red edge lights for the console panels and main instrument panel. Power is taken from the main AC bus.
- (c) A rheostat switch marked CONSOLE FLOOD-OFF/BRIGHT controls the red console flood lights. Power is taken from the main AC bus.
- (d) A toggle switch marked HIGH ALT LIGHTING-ON/OFF controls the amber flood lights for the main instrument panel and consoles. Power is taken from the main DC bus.

Part 1

External Lights

124. External lights comprise two landing/taxi lights, and the navigation lights. The landing lights are fitted on the nose landing gear. One is fitted on the steering portion for taxiing purposes and the other is fitted on the fixed portion of the leg. A switch, fitted on the LH console, in the front cockpit and marked LIGHTS, has three positions, LAND-TAXI-OFF. With the landing gear extended, selection of LAND will illuminate both lights while selection of TAXI will allow only the taxi light to illuminate. (Landing and taxi lights are not fitted for the first flights of the first aircraft).

125. The navigation lights consist of the right (green) and left (red) wing tip lights and two fin tip lights (white and red). They are controlled by a flasher unit through a switch located on the RH forward console in the front cockpit marked NAV LIGHTS/FLASH-OFF-STEADY. When selected to FLASH the two wing tip lights and the white fin tip light will be on together and will flash alternately with the red fin tip light. The lights will revert to 'steady' should the flasher unit fail.

ENGINE CONTROLS

Engine Power Controls

126. Two conventionally operated engine throttle levers are installed on the LH console. Movement of each lever operates the fuel flow control quadrant lever at the engine via a continuous cable. The cable is automatically maintained at correct tension by a tension regulating device.

127. Each lever has "gated" stops to enable a positive selection of the cut-off and idle positions. Lifting and pulling the levers aft of the idle position shuts off the HP fuel supply to the engines. To move the levers from the cut-off to the idle position they must be moved forwards and down.

Afterburner Control

128. Each throttle lever controls non-afterburning and afterburning engine operation as follows:

(a) Progressive forward movement of the lever up to the maximum stop position selects a range of engine thrust (without afterburning) from "idle" to "military" power.

(b) Progressive forward movement from "idle" to a position marked DOWN

FOR AFTERBURNER on the quadrant gives normal engine thrust. Depression of the lever within the afterburner range actuates a micro-switch and the afterburner lights. Engine and afterburner thrust increases progressively as the lever is moved forward to the maximum stop position.

129. Afterburning can be terminated immediately by lifting the lever to the original 'up' position within the quadrant. This relieves the pressure on the micro-switch which cuts off the afterburner.

130. Should a failure of the electrical system occur during afterburner operation, the afterburner may be shut down by retarding the throttle lever out of the afterburner range. This actuates a hydro-mechanical device within the flow-control unit. The afterburner cannot be used again until the electrical fault has been rectified.

Engine Starting Controls

131. The engine starting controls comprise:

- (a) An ENGINE START switch with START-OFF-RESET positions, located on the RH console.
- (b) A relight button on each throttle lever.
- (c) An LP FUEL cock switch for each engine, located on the LH console.
- (d) An HP fuel cock for each engine controlled by its respective throttle lever.

132. During the normal start procedure when the ENGINE START switch is pulsed to START and released, the following sequence of operations automatically take place:

- (a) A switch is operated in the air turbine starter motor when the engine reaches approximately 700 rpm which energizes the ignition circuit for "light-up".
- (b) A second switch in the air turbine starter motor is operated when the engine reaches approximately 3,000 rpm, and performs the following operations simultaneously:
 - (1) Switches off the ignition.
 - (2) Shuts off the air supply from the ground starter cart.

Part 1

Engine Motoring

133. The engines may be motored should a wet start occur, or in the case of an internal engine fire on the ground, as follows:

- (a) Move the throttle lever to the cut-off position.
- (b) Check that the LP cocks are in the ON Position.
- (c) Air starting power must be available from the ground starter unit.
- (d) Select the ENGINE START switch to the RESET position and hold for a maximum time limit of 30 seconds. Allow the switch to return to the OFF position. The engine will motor at approximately 1,200 rpm.

NOTE

Holding the ENGINE START switch to the RESET position immediately isolates the ignition circuit, opens the air supply valve in the ground starter unit and permits the engine to rotate. When the switch is released, the air supply valve in the ground starter unit is closed and the engine will gradually run down.

ENGINE INSTRUMENTS

Pressure Ratio Indicator

134. An Engine Pressure Ratio Indicator for each engine is fitted on the main instrument panel. Each indicator denotes the ratio of the turbine discharge total pressure to the compressor inlet total pressure and is an indication of the power being developed by each engine.

135. The ratio shown on the indicator for an engine developing military thrust at take-off will vary from day to day, according to the ambient temperature.

136. To compute the engine pressure ratio which is normally functioning engine may be expected to produce during a take-off thrust check, a curve as shown in the engine operating handbook may be used. This curve for the ARROW 1 installation will be issued later.

137. Curves may be used for determining the engine pressure ratio for a desired engine power setting, either for a climb or cruise condition, the

factors involved being altitude and compressor inlet total temperature (ambient temperature corrected for ram effect). This curve will also be issued later.

138. Once the desired power condition has been set up for climb or cruise, the fuel control will maintain an approximate constant percentage of thrust output with a fixed power lever position. As engine pressure ratio varies with compressor inlet temperature, the pressure ratio will increase as the temperature becomes lower at the higher altitudes.

Engine RPM Indicator

139. An rpm indicator (tachometer) graduated in percentage rpm, is fitted on the main instrument panel for each engine. On the indicator 100% rpm represents a high pressure compressor speed of 8732 rpm.

NOTE

The low pressure compressor rpm are not instrumented on this aircraft.

140. The 100% position is not the rpm at which Military Rated thrust will be developed by the engine. The rpm for military rated thrust on standard day sea level static conditions for different engines will vary, depending upon the engine trim speed which is stamped on the engine data plate. The rpm serves as an indication that compressor speed is within allowable limits. A red line on the indicator at 103.5% represents the overspeed limit.

CAUTION

Each case of rpm overspeed in excess of 103.5% should be noted in the engine log book.

141. The rpm indicators can be used for checking engine power output. In this case, temperature/rpm curves must be used and the result adjusted for the particular engine trim speed.

Turbine Outlet Temperature Gauge

142. One gauge is fitted for each engine, indicating the temperature immediately downstream from the turbine discharge and serving as a relative indication of the temperature at the turbine inlet. The instruments require AC power. Two flags are visible at windows on the face of the instrument. When electrical power is off, both flags show

Part 1

the word OFF. When electrical power is ON, the flags disappear. One flag is always visible in the event of the other flag being obscured by the indicating pointer.

LOW PRESSURE PNEUMATIC SYSTEM

General

143. The LP pneumatic system supplies low pressure air, tapped from the inlet side of the air conditioning cooling turbine, to the anti-g suits and the canopy seals.

Anti-g Suit Controls

144. An anti-g valve is located at the aft end of the RH console in each cockpit and controls the LP air supply to the anti-g suit. The valves are set to pressurize the suits at 1.5 g - 1.8 g. the pressurization will increase with the increase of "g" forces up to a maximum of approximately 10 psig which would be reached at 8 g. If 8 g is exceeded the suit will not pressurize above 10 psig. Connection between anti-g valve and anti-g suit is made through the crew member's composite leads disconnect on the RH side of the seat pan.

Canopy Seals

145. The pilot's and navigator's canopy seals are inflated by low pressure air at 18-22 psi through a control valve. The valve is operated electrically and the seals are inflated when both canopy handles are in the locked position. If either canopy is unlocked the seals will deflate and vent the pressure to atmosphere. The rear cockpit canopy locking handle may be operated from the front cockpit through an access door in the bulkhead, to enable the rear canopy to be locked if the aircraft is flown solo.

DE-ICING AND ANTI-ICING SYSTEMS

General

146. The aircraft anti-icing and de-icing systems are entirely automatic in operation. The engine systems may be divided as follows:

- (a) Ice detection.
- (b) De-icing of the duct intake ramps and lips. (Non-operative for the first flights of the first aircraft).
- (c) Engine compressor inlet anti-icing. (Non-operative for the

first flights of the aircraft).

147. The airframe systems are as follows:

- (a) Windscreen and canopy anti-icing.
- (b) Pitot head anti-icing.
- (c) Probe vane anti-icing.

Ice Detection

148. Two identical electrically heated ice detectors are fitted; one mounted on the lip of each engine intake duct.

149. Each detector has two probes, one of which is electrically heated whenever power is ON, and the other which is only heated when ice covers the forward holes. A pressure differential switch signals the ice controller when ice forms on the normally unheated probe. The signal also causes the master amber warning light and the light on the warning panel, marked ICE, to illuminate. The automatic heating of this probe melts the ice on the probe, restores the normal pressure, and the probe is then ready to send another signal to the ice controller. The signals continue as long as icing conditions exist, at a rate proportional to the rate of icing. The rate is indicated to the pilot by the ICE warning light and the master amber light, going on and off.

Duct De-icing

150. De-icing of the engine ducts is accomplished by electrically heated rubber ice protectors which are automatically controlled. The protectors are separated by parting strips which are heated at the first ice signal from the controller (para 149). The remainder of the protectors are heated after a pre-set number of ice signals are received and will shed the ice. The icing and de-icing cycle will be repeated according to the number of signals received by the controller.

Engine Compressor Inlet Anti-icing

151. Engine anti-icing is accomplished by the use of engine bleed air. The first icing signal from the controller automatically opens air supply valves and provides hot air to the compressor inlet section of the engine. The system functions continuously during icing conditions. The valves close automatically at the same time as the duct de-icing ceases.

152. The flow of hot air is regulated according to the compressor

Part 1

discharge temperature. Flow will be reduced as the temperature increases.

NOTE

During descent at high airspeeds and low power settings the heat supplied may be inadequate if the ice formation is severe. Increased thrust should be applied to provide more heat. An abnormal increase in turbine discharge temperature will be noted when the throttles are advanced if ice is still accumulating in the compressor inlet. Airspeed should be decreased until the icing region has been passed.

Windscreen and Canopy Anti-icing

153. The pilot's windscreen and canopy windows are continuously heated by electrical means when the aircraft master electrical switch is on. A conductive transparent coating is incorporated on the inner surface of the outer glass lamination of the panels and sensing elements control the maximum temperature to 110°F.

Pitot-head and Vane Anti-icing

154. The pitot-heads and probe vanes are continuously heated by electrical means when the aircraft master electrical switch is on.

OXYGEN SYSTEM

General

155. Two independent oxygen systems are installed in the aircraft, a normal supply and an emergency supply.

Normal System

156. The normal system is supplied from a converter containing liquid oxygen. The liquid oxygen is converted into gaseous oxygen for crew members breathing purposes and, on later aircraft, for inflation of the partial pressure suits.

157. The quantity of liquid oxygen contained in the converter is shown on two gauges in litres. One gauge is fitted on the forward RH console in the pilot's cockpit, while the other gauge is fitted on the navigator's main panel. The gauges are operated electrically and, on later aircraft, an OFF indicator flag on each gauge becomes visible when electrical power

to the quantity gauging system is terminated.

158. Oxygen flows from the converter, through the composite leads disconnect to a regulator which automatically compensates for altitude. From the regulator it flows back to the composite leads disconnect, from which leads are taken to the oxygen mask and pressure suit.

Oxygen Regulator

159. An automatic pressure demand oxygen regulator is fitted beneath each seat pan. A PRESS-TO-TEST button is fitted on the right of the seat pan and is used to test the mask prior to flight.

Emergency Oxygen Supply

160. Attached to the forward part of each seat pan is an emergency oxygen cylinder containing gaseous oxygen at a pressure of 180 psi when fully charged. The oxygen pressure is shown on a gauge attached to the cylinder. A fully charged cylinder provides a minimum of 20 minutes supply.

161. A combined automatic and manual trip valve is fitted to each cylinder. The automatic function operates upon seat ejection by means of a lanyard, which connects the valve to the floor of the aircraft. Should the normal oxygen supply fail, the emergency bottle supply may be used by operating the EMERGENCY OXYGEN MANUAL CONTROL located on the LH side of each seat pan. In both automatic or manual function, the trip valve connects the emergency cylinder to the regulator, and to the mask and pressure suit through the composite leads disconnect. Thus the regulator adjusts the emergency supply in the same manner as the normal supply is adjusted.

Composite Leads Disconnect

162. A composite leads disconnect fitting is located on the right of each ejection seat pan. Connections from the fitting are as follows:

- (a) Oxygen to mask and pressure to suit. (Not connected to the suit in the first aircraft).
- (b) Telecommunications.
- (c) Anti-g suit.

Part 1

163. The fitting is in three parts and when seat ejection takes place one part of the fitting remains with the aircraft while the other two parts are attached to the seat. This allows emergency oxygen to be used during the early part of the descent. When the occupant separates from the seat, the remaining two parts disconnect, leaving one on the seat and the other attached to the occupant.

UTILITY HYDRAULIC SYSTEM

General

164. The utility hydraulic system is separate from the flying control hydraulic system. The utility system is powered by two pumps, one mounted on each engine driven gear box. An operating pressure of 4000 psi is maintained by the pumps. Any one pump will supply the requirements of the utility hydraulic sub-systems.

165. A 5000 psi nitrogen charged storage bottle is provided for emergency extension of the landing gear. Two 4000 psi accumulators are included in the system for emergency braking.

166. The utility hydraulic system operates the following components:

- (a) Landing gear.
- (b) Wheel brakes.
- (c) Nose Wheel steering.
- (d) Speed brakes.
- (e) A hydraulic motor to drive the emergency alternator. Operation is automatic in case of complete electrical failure.
- (f) A hydraulic jack for extending a ram air driven turbine into the airstream to give flying control hydraulic pressure in an emergency. (If fitted).

Landing Gear

167. The tricycle landing gear consists of a forward retracting nose gear with dual wheels and main gears with two wheeled bogies which retract inboard and forward into the wing.

Landing Gear Controls

168. The landing gear is operated by means of a lever which has a wheel shaped handle containing a red light, located on the landing gear selector panel on the LH forward panel.

169. A solenoid operated micro-switch prevents raising of the landing gear while the weight of the aircraft is on the main wheels. No provision is made for emergency retraction of the landing gear.

Emergency Lowering Landing Gear

170. In the event of failure of the normal system, the landing gear may be lowered by means of pneumatic pressure from a 5000 psi nitrogen storage bottle. To operate the system a thumb latch marked EMERGENCY EXTENSION, under the landing gear lever is pressed down and the lever is moved fully downwards. The pneumatic pressure releases the uplocks of the doors and gears at approximately the same time, and each gear then falls in a manner similar to normal lowering.

Landing Gear Position Indicators

171. Three indicators marked GEAR POSITION are located on the LH side of the main instrument panel, and show the position of the two main gears and nose gear. In addition, a red light is fitted into the handle of the landing gear selector lever and illuminates steadily when any gear or gear doors are between locks. The red light flashes if either throttle lever is retarded below the minimum cruise position if the landing gear selector lever is not in the down position. When the throttle of a non-operating engine is placed in the cut-off position for one engine flight, the light will go out. However, the light will illuminate again when the throttle lever of the live engine is retarded if the landing gear lever has not been selected down.

172. With electrical power switched on, the three indicators on the main panel show landing gear position as follows:

<u>Position</u>	<u>Indication</u>	<u>Landing Gear Handle Warning Light</u>
Landing Gear and Doors Locked Up	UP	OFF
Landing Gear or Doors Between Locks	Black and White bars	ON
Landing Gear and Doors Locked Down	Wheel symbol	OFF

Sequencing of Landing Gear and Doors

173. When the landing gear lever is moved UP after take-off the individual indicators will show diagonal bars as the gear down-locks are released by hydraulic pressure. At the same time the red light in the handle of the gear lever will illuminate. As the individual gear nears its uplock position in the wheel bay, a valve is operated causing the door downlock to be released and the door to be closed. As each door closes a micro-switch is tripped, which causes an UP signal to show on the indicator for that particular gear. When all three doors are closed, the red warning light on the landing gear lever handle goes out. The selector valve (which is moved by electrical means whenever the landing gear lever is moved) is automatically returned to neutral. This allows the emergency extension system to be used in case an electrical failure causes the selector valve to be inoperative.

174. If one door becomes unlocked during flight and releases its micro-switch plunger, the red light will illuminate in the landing gear selector lever handle and the gear position indicator will show diagonal bars (gear unsafe). At the same time power will be applied to the UP solenoid of the selector valve, the door will be retracted, the indicator will show UP and the lever handle light will go out. The selector valve will again automatically return to neutral.

175. When the landing gear is selected DOWN, hydraulic pressure releases the door and gear uplocks in sequence and the gear falls by gravity aided by air loads. Its fall is restricted by a fixed orifice in the jack and is damped at the final portion of extension. The red light in the gear handle will illuminate and remain illuminated until the gears and doors are locked down. The indicator travels through the stages from up, unlocked to locked down.

Wheel Brakes

176. Toe pressure on the pilot's rudder brake pedals actuates control valves via cables and allows differential and proportional braking of the two pairs of main wheels. No anti-skid protection is provided on early aircraft, but later aircraft will be fitted with an anti-skid system which will release pressure on the brakes when a skid is imminent.

177. Brakes are applied automatically upon retraction of the landing gear to stop the wheels spinning. An emergency braking system automatically provides differential and proportional braking in the event of failure of the normal system.

Anti-skid System (Not fitted on early aircraft)

178. Detection of an imminent skid of a wheel and immediate release of pressure to that brake to prevent actual skidding, is provided on later aircraft. To prevent excessive differential braking being used when the pressure is cut off from one side, the other side brake is also released, thus preventing a yawing effect.

179. A locked-wheel touchdown is prevented by a micro-switch which prevents brakes being used until the weight of the aircraft is on the main wheels. Detectors are also fitted which prevent use of the brakes until the wheels are rotating at the aircraft landing speed.

180. In case of failure of an anti-skid unit, selecting the ANTI-SKID switch located on the LH console to EMERG OFF disconnects all anti-skid units.

Brake Pressures

181. The normal utility system pressure of 4000 psi is supplied to the master brake cylinder, where it is reduced to 2500 psi. Emergency pressure is supplied to the brake control valve at 1500 psi which is sufficient for adequate braking. The emergency accumulators are maintained at a pressure of 4000 psi by the main system.

Pressure Warning Lights

182. If the pressure in the normal utility system falls below 1000 psi, the master amber warning light and the UTIL HYD indicator light on the warning panel, will illuminate. This indicates that emergency extension of the landing gear will be necessary and that emergency brake pressure will be used for braking upon landing. Should the pressure in the emergency accumulators fall below 1600 psi, the EMERG BRAKE HYD indicator light on the warning panel will illuminate and indicate that emergency braking will be inoperative upon landing.

Parking Brake

183. A handle is fitted on the LH side of the main instrument panel and is marked PARKING. The brakes can be locked on for parking by depressing the rudder brake pedals, pulling the parking brake control and releasing the brakes. To release the parking brakes, the handle is pulled outwards and allowed to return fully inwards.

Part 1

184. The emergency accumulator provides hydraulic pressure for the brakes when towing the aircraft or for parking after engine shut-down.

Nose Wheel Steering

185. The nose wheels are steered hydraulically by the movement of the pilot's rudder pedals which are mechanically linked to the steering control valve. A solenoid valve is opened when the push button, located at the bottom left of the control column grip, is pressed. This allows high pressure hydraulic fluid to flow to the control valve which operates a jack and moves the nose wheel according to the pilot's rudder pedal movements. When the nose wheel reaches an angle corresponding to the position of the rudder pedals, the control valve spool returns to normal. The rudder pedal position must be synchronized with the nose wheel position when initiating steering. Normal castoring of the nose wheels is available when steering is not engaged. A micro-switch prevents turning of the nose wheels unless the weight of the aircraft is on the nose wheels.

Steering Angles

186. The nose wheels can be steered or castored through an angle of 55° on either side of the centre line, enabling the aircraft to be turned on a 21 foot radius.

Speed Brakes

187. Two speed brakes are fitted in the bottom of the fuselage immediately aft of the armament bay. They are hydraulically operated by the utilities system and are controlled by a thumb switch on the RH throttle lever. The switch opens or closes the electrical circuit to a solenoid operated hydraulic control valve. The speed brakes are designed to open and "hold" at speeds up to Mach 1.0. They will "blow in" to a new position if excessive air loads are imposed, until airloads balance the hydraulic jack load.

Selector Switch

188. The speed brake selector switch has three positions, fully forward - "OUT", central - "HOLD", and fully back - "IN". The switch should remain at the IN position when speed brakes are not in use and at the OUT position when using them fully down. The 'hold' position may be used to obtain intermediate selections, the speed brakes being hydraulically locked in the position existing at the time of selection.

NAVIGATION EQUIPMENT**Radio Magnetic Indicator**

189. The pilot and navigator are each supplied with a RADIO MAGNETIC INDICATOR, located on their respective main instrument panels. A selector switch, marked RMI NEEDLE - UHF HOMER/TACAN is fitted in both cockpits on the RH console. Provided an individual switch is selected to TACAN, (if TACAN is fitted) the double pointer of the radio magnetic indicator in that particular cockpit will show the relative bearing of the selected beacon station. With the switch selected to UHF HOMER the same pointer will indicate the relative bearing of the station selected on the ARC-34 receiver. The compass card of the RMI is controlled by the J4 compass and indicates the magnetic heading of the aircraft. (See J4 Compass). The single pointer is used, in conjunction with the radio compass, to obtain a bearing of a broadcast or radio range station. (See Radio Compass).

UHF Homer

190. This navigational aid utilizes the AN/ARC-34 main receiver (see Communication Equipment). Homing facilities are provided by selecting the OFF-MAIN-BOTH-ADF switch on the COMM control panel to ADF. Provided the RMI NEEDLE selector switch on the RH console is selected to UHF HOMER, the double pointer of the RMI will indicate the relative bearing of the selected radio signal source, and enable the aircraft to "home" on the signal. Signals must be in the 225 to 400 MC range for automatic direction finding to operate. Successful operation depends upon the power of the transmitting station, the altitude and the distance between the transmitting station and the aircraft. Results will not be dependable if the horizon appears between the transmitting station and the aircraft.

Radio Compass (AN/ARN-6 L.F)

191. The ARN-6 radio compass receiver provides a bearing on broadcast or radio range stations, and the relative bearing is shown by the single pointer on the radio magnetic indicators. A RADIO COMPASS control panel is fitted on the RH console in both cockpits, but only one panel is in control at a time. The tuning dial of the control panel in use is illuminated. Control may be gained by the other crew member by turning the selector switch to CONT (control) and then back to COMP. The bearing indication is shown on the single pointers of both radio magnetic indicators simultaneously. Audio signals are received through the AN/AIC 10 interphone system, provided the mixing switch on the interphone panel marked COMP, is ON.

Part 1

192. A station is tuned by means of a band selector switch and a tuning knob. Mode of operation is selected as follows:

- COMP - To obtain station bearing automatically.
- ANT - To operate as a communications receiver only.
- LOOP - To obtain bearing manually by means of a loop drive control on the panel.

J4 Gyrosyn Compass

193. A remote compass transmitter is installed in the right wing and magnetic heading information is transmitted to the cards of the radio magnetic indicators and the R-Theta computer system (if fitted). A J4 compass control panel is fitted on the RH console in the pilot's cockpit and the following controls are installed:

- (a) A function selector switch marked MAG-DG is used to select the mode of operation of the compass system. When the switch is in the MAG (magnetic) position, the system operates as a magnetic compass and can be synchronized with the remote transmitter. In the DG (directional gyro) position, the system operates as a directional gyro, which can be latitude corrected.
- (b) A synchronizer knob marked SET, which is spring loaded to the SET position. The knob may be moved to the left (marked DECR-) or to the right (marked INCR+) in order to line up the annunciator pointer with the centre index when the function selector is in the MAG position. When the selector is in the DG position the annunciator window is covered and the letters DG appear. The synchronizing knob may be moved to INCR or DECR to set the indicators to the desired position at either a fast or slow rate.
- (c) The latitude correction controller, marked LAT is manually set to the flight latitude to correct the system, when in the DG mode of operation, for the apparent drift of the gyro due to the earth's rotation.
- (d) A hemisphere screw adjustment marked N and S is normally set on the ground to the northern or southern hemisphere in which the gyro is operated. Setting it to "N" will effect a clockwise correction for gyro drift, while an "S" setting will effect a counter-clockwise correction; the rate of precession is determined by the setting of the latitude correction controller.
- (e) An annunciator which indicates synchronization to $\pm 15'$ between the compass system and the remote transmitter when in the magnetic mode of operation. When the system is not synchronized, the annunciator indicates

in which direction the synchronizer knob must be turned.

194. A J4 COMP NORMAL-AEROBATICS switch is fitted on a panel located below the radio compass control panel, on the pilot's RH console. If violent manoeuvres are to be carried out the switch should be selected to AEROBATICS to cage the compass gyro and prevent toppling. Selection back to NORMAL should be made after the aircraft has returned to normal flight.

R-Theta Navigation Computer System (Not fitted at the present time).

195. The R-Theta system is a dead reckoning method of navigation which supplies the aircraft's ground position in the form of range and bearing from base or destination. The aircraft's true track is also indicated. Interception steering information can also be shown.

196. True airspeed and magnetic heading enter the Ground Speed Computer as electrical signals and variation, wind speed and direction are fed in manually by the navigator. The Ground Speed Computer carries out a continuous solution of the triangle of velocities; that is, it performs the addition of air speed and wind speed vectors and taking into account magnetic variation, extracts ground speed and true track data. These are transmitted to the R-Theta computer as electrical signals. The R-Theta DR computer processes true track and ground speed data with respect to time so as to determine continuously the aircraft's ground position, and displays range, true bearing and true track. Controls for adding arbitrary vectors, and for resetting range and gearing are located on the face of the navigator's computer.

197. Instruments used by the pilot and navigator are as follows:

- (a) A Ground Speed and Interception Computer used by the navigator.
- (b) An R-Theta DR Computer used by the navigator.
- (c) An R-Theta DR Indicator used by the pilot, which is a repeater from the navigator's computer.

198. The G.S.I.C. enables the basic variables of magnetic or grid variation, windspeed and wind direction to be set by the three manual controls, with a corresponding indication on the dials and counters. The aircraft's true airspeed is automatically indicated on the cut out window. The above information when set on the G.S.I.C., plus information fed from the J4 gyro compass, enables the R-Theta computer to carry out the functions set out below.

Part 1

199. The R-Theta computer shows the true bearing of the aircraft from a chosen reference point, with the double arrows always pointing towards this point. The single pointer indicates the aircraft's true track. The range counter automatically indicates the aircraft's distance in nautical miles from a chosen reference point.

200. The pilot's repeater displays the same range, bearing and track data as the navigator's computer. A switch on the repeater instrument permits the selection of compass heading or true heading as alternatives to true track.

COMMUNICATION EQUIPMENT

UHF Equipment (AN/ARC-34)

201. An AN/ARC-34 receiver-transmitter is installed and permits short range voice transmission and reception, air-to-air or ground, on 20 preset channels. Any other channel within the operating range may be selected manually. Reception and transmission is made through the AIC/10 interphone system. The control panel, marked COMM, is located on the console in the pilot's cockpit and comprises:

(a) An OFF-MAIN-BOTH-ADF switch, which sets up the type of operation as follows:

- OFF.
- MAIN - Main transmitter/receiver is operative.
- BOTH - Main transmitter/receiver and the Guard receiver are both operative.
- ADF - The automatic direction finder (HOMER) is operative. (See NAVIGATION EQUIPMENT - UHF HOMER).

(b) A MANUAL/PRESET/GUARD switch which selects the type of frequency control for the transmitter and main receiver. When PRESET is selected, the large central knob is rotated to bring the required channel number in the centre window. The preset channel numbers are inscribed on a card at the base of the panel. When MANUAL is selected, four windows at the top of the panel open and expose digits, which may be altered to the frequency required by means of a knob located below each window. When GUARD is selected the windows are closed and the transmitter and main receiver operate on the GUARD frequency.

(c) A TONE button, which provides MCW transmission.

(d) A VOLUME control.

202. Two antennas are fitted for the UHF equipment, one in the fin and one in the equipment bay. They are known as upper and lower respectively, and may be selected at the pilot's discretion by means of a two position switch on the RH console in the front cockpit. The switch is marked UHF ANT-UPPER/LOWER.

Intercommunication (AN/AIC-10)

203. Intercommunication is provided by an AN/AIC-10 set. It provides interphone between aircrew, ground crew and operations room and also affords a means of selection of the aircraft's radio facilities.

204. Identical control boxes are fitted for the pilot and the navigator and are located on their respective RH consoles. A PRESS-TO-TALK button is fitted on the RH throttle lever in the front cockpit and on the panel forward of the AIC-10 panel in the rear cockpit. The control box comprises the following switches:

(a) A series of five mixing toggle switches which allow for listening simultaneously on all channels which are selected to the ON position.

Switch 1 marked INTER - For interphone between pilot and navigator.

Switch 2 marked COMP - Radio Compass AN/ARN-6 aural reception, used to tune and identify a particular station.

Switch 3 marked COMM - Command radio, gives UHF reception to other aircraft or ground stations.

Switch 4 marked TACAN - AN/ARN-21 radio set aural reception used to tune and identify a particular station.

Switch 5 marked TEL - For telescrumble information reception when the aircraft is on the ground.

(b) A six position rotary switch giving talk facilities by means of the following selections:

Position 1 - (Fully counter-clockwise) - Spare.

Position 2 - Spare.

Position 3 - Marked TEL, provides transmission facilities through the telescrumble line when the aircraft is on the ground by operating on "Press to Transmit" button.

Part 1

Position 4 - Marked COMM. Provides a "live" microphone for interphone without interrupting command radio listening, provided the INTER mixing switch is ON. When the "Press to Talk" button is pressed, it permits transmission of command radio.

Position 5 - Marked INTER. Provides "Press to Talk" interphone operation.

Position 6 - Marked CALL. Spring loaded in the fully clockwise position and returns to position 5 (INTER) when released. When held in the CALL position it overrides all other functions irrespective of switch positions and gives interphone without the use of the "Press to Talk" button.

205. The "Press to Talk" button is used when the selector switch is in the COMM position and it is desired to transmit on command radio or in the TEL position when transmitting on the telescrumble line. When the selector switch is in the INTER position "Press to Talk" interphone facilities are available regardless of the mixing switch positions. A volume control is fitted and adjusts volume on all incoming channels.

206. A toggle switch marked NORMAL-AUX. LISTEN is wire-locked in the NORMAL position, but if reception at the station fails a quick test of the amplifier may be made by breaking the locking wire and listening with the switch on AUX. LISTEN; this cuts out the amplifier. This facility is available for emergency listening in flight, and when used, the mixing is inoperative and one channel only is available for listening, as selected by a toggle switch. If more than one switch is on, the only audible channel will be that given by the first (from the left) of the row of mixing switches that are on. If none are ON, the only audible channel will be the one to which the rotary selector switch is set.

207. Inadvertent rotation of the selector switch past the TEL position will result in interruption of the talk facility.

208. Numerous combinations of switch positions are possible. One example is given below:

- (a) Mixing switches on INTER and COMM.
- (b) Rotary switch on COMM.
- (c) Volume control with the white line at approximately the mid position.

209. Under the above arrangement interphone, both with navigator and

ground crew, is available at all times without any other operation, command radio is available for listening; and by pressing the "Press to Talk" button, transmission on command radio is available.

NOTE

The above position of the volume control will provide maximum efficiency. Movement past this position may be used for reception during abnormal atmospheric conditions or weak signal strength. The volume of the UHF and radio compass should then be adjusted individually as desired.

OPERATIONAL EQUIPMENT AND CONTROLS

IFF (AN/APX-6A)

210. The purpose of the IFF equipment is to enable the aircraft in which it is installed to identify itself when interrogated by coded transmissions from ground or airborne radar sets. The coded interrogation transmissions can be transmitted in any one of three modes classified as Modes 1, 2 and 3. Each mode of interrogation initiates the transmission of a corresponding mode of reply from the IFF transmitter-receiver (transponder). The reply is presented on the interrogator's radar display adjacent to the target pip.

211. Mode 1 interrogation serves for general identification of any aircraft detected by a ground or airborne radar set. Modes 2 and 3 permit specific aircraft to be identified and distinguished from other aircraft. Normally, Modes 2 and 3 are used only when requested by radio or prior to take-off.

212. An emergency reply, which overrides the three normal modes can be selected. This reply will be transmitted when the aircraft is interrogated irrespective of the mode of interrogation.

213. The control panel is located on the LH console in the pilot's cockpit and comprises the following control switches:

(a) MASTER switch - A five position rotary switch used to control power supplies to the equipment and to select EMERGENCY operation. The switch positions are as follows:

(1) OFF: All power supplies are disconnected from the equipment, but this does not affect the lighting of the control panel.

Part 1

- (2) STDBY: All power supplies are switched ON, but the receiver is rendered inoperative.
- (3) LOW: The receiver is ON but is sensitive only to strong interrogation signals from nearby stations.
- (4) NORM: The receiver is at maximum sensitivity and the equipment responds to interrogation from distant stations.
- (5) EMERGENCY: The receiver is at maximum sensitivity and the equipment responds to interrogation in any mode with the emergency reply.

NOTE

To select EMERGENCY, spring loaded button adjacent to the rotary selector must be depressed. This button prevents accidental selection of the emergency operation.

- (b) MODE 2 switch: Is a two position switch controlling operation of the equipment on Mode 2, with switch positions as follows:
 - (1) OUT: The equipment will respond to normal Mode 1 interrogations. It will not respond to Mode 2 except to transmit the emergency response if the master switch is selected to EMERGENCY.
 - (2) MODE 2: The equipment will respond to MODE 1 and MODE 2 interrogations.
- (c) MODE 3 switch: Is a two position switch for controlling Mode 3 operation, with switch positions as follows:
 - (1) OUT: The equipment will respond to Mode 1 interrogations. It will not respond to MODE 3 except to transmit the emergency response if the master switch is set to EMERGENCY.
 - (2) MODE 3: The equipment will respond to MODE 1 and MODE 3 interrogations.
- (d) I/P-OUT-MIC switch is a three position switch for special operation of the system on Mode 2, with switch positions as follows:
 - (1) I/P: Switch position is inoperative.
 - (2) OUT: Will respond to interrogations normally.

(3) MIC: Will respond to Mode 2 interrogations whenever the UHF transmitter is energized.

214. For automatic operation of the IFF upon seat ejection, see para 240.

215. The IFF system shares two antennas with the TACAN system (if the TACAN system is fitted). They are the upper and lower "L" band antennas. A two position "L" band antenna transfer switch is mounted on the navigator's RH console, marked IFF UP/TACAN LOW and IFF LOW/TACAN UP. The switch allows the antennas to be connected to the systems as selected.

EJECTION SEATS

General

216. The pilot and navigator are each provided with a MK C5 automatic ejection seat to enable them to abandon the aircraft. Ejection from ground level at aircraft speeds as low as 80 knots IAS, is made possible by the high ejection velocity and the rapid deployment of the parachute.

217. The ejection seats are made safe when the aircraft is at rest by installing safety pins at the following locations:

(a) The seat firing gear and the canopy cartridge firing mechanism sear. These two safety pins are attached to a common chain with a warning plate. Alternatively, the canopy sear pin of this assembly may be used to lock the overhead firing handle. In this case, the seat firing sear pin is not used.

(b) The drogue gun safety lock.

(c) The alternative firing handle.

Interconnected Firing System of the Canopy and Ejection Seat

218. The emergency opening of the canopy and ejection of the seat is achieved by means of cartridges. The canopy is forced open by a single cartridge, while the seat is fired by an ejection gun containing a primary and two secondary cartridges.

219. The canopy cartridge and ejection gun cartridge are fired by pulling a large horizontal firing handle fitted immediately above the headrest. The firing handle is attached to a canvas face blind which is pulled over the occupant's face. Alternatively, the canopy and ejection gun can be fired by pulling upwards on the alternative firing handle located on the seat pan between the occupant's knees. This firing handle is for use should the seat occupant find it impossible to reach or




FIG 1-6 Mk C5 EJECTION SEAT

operate the overhead firing handle.

220. The operation of either of these firing handles withdraws two sears, one sear for the canopy cartridge firing mechanism and one sear for the ejection gun. The cartridge of the canopy firing mechanism is detonated immediately but the firing of the ejection gun does not take place until the canopy is in its emergency open position.

221. When the canopy cartridge is fired the gas generated unlocks the canopy latches and, through uncovered ports, passes to the actuating mechanism jack. Through linkage, the canopy is forced open and is retained open by a spring-loaded hook.

222. During the canopy opening process the firing pin of the ejection gun is prevented from moving by a release rod, but as soon as the canopy passes its normal open position the release rod begins to withdraw from the firing pin. When the canopy has opened sufficiently to give clearance for the path of the seat, the release rod is fully withdrawn and allows the spring-loaded firing pin to detonate the primary cartridge of the ejection gun. The firing of the secondary cartridges is then caused by flame from the primary cartridge.

223. As the seat leaves the aircraft, the occupant's legs are pulled to the rear and held against the front of the seat pan by means of a leg restraint cord. They are held in this position until separation from the seat takes place. Movement of the seat also breaks the quick disconnect between the seat and the aircraft, primes the drogue gun and the time release mechanism by removing their respective sears, and operates the emergency oxygen bottle by means of a lanyard.

224. Approximately one-half second after the seat and occupant have been ejected the cartridge operated drogue gun withdraws a controller drogue from a container behind the headrest. This drogue tilts the seat into a horizontal attitude and then withdraws the main 5 foot drogue from the container. The main drogue further decelerates and steadies the seat.

225. A barostatic and 'g' controlled time-delay mechanism is fitted to the top of the RH side beam. Provided ejection takes place below 5000 metres (16,400 feet), and that the forward deceleration of the seat is less than 4 g, the time-delay mechanism will operate after 1.3 seconds. If ejection occurs at a higher altitude, a barostat attached to the time-release mechanism prevents the release from functioning until the seat and occupant have fallen to 5000 metres (16,400 feet). The barostat in the first aircraft is set to 10,000 feet.

Part 1

226. When the time-delay mechanism operates it releases the parachute harness from its attachments to the seat at three points and disconnects the seat portion from the crew member portion of the composite leads disconnect. It also releases the leg restraining cords and the drogue line from the seat. The drogue line now pulls on a lifting line which extracts the parachute pack pin and withdraws the main parachute from the pack. The seat is allowed to fall free.

Manual Override Control

227. Provision is made to manually disconnect the parachute withdrawal line from the parachute static line by means of the parachute override 'D' ring. A separate lever control is fitted to manually release the parachute and parachute harness from the seat. These manually operated controls enable the seat occupant to separate himself from the seat should the seat fail to eject or, after ejection, if the automatic separation mechanism fails to function.

228. The override 'D' ring is a conventional ring partly covered by a small flap secured by press-studs. When the flap is removed and the override 'D' ring is pulled, the parachute withdrawal line is disconnected from the parachute static line. This action also uncovers the inner rip-cord 'D' ring. The manual override lever is fitted on the RH side of the seat pan and is normally locked in the fully forward position by a spring catch under the head of the lever engaging in a slot of the lever quadrant. Releasing the spring catch and moving the lever fully to the rear until the catch engages in the rear slot of the quadrant will perform the following operations automatically:

- (a) Release the parachute and parachute harness from the seat.
- (b) Release the leg restraint cords from the seat.
- (c) Release the crew member portion of the composite leads disconnect from the seat portion.

Manual Leg Restraint Release

229. A small handwheel is fitted at the front of the RH side of the seat pan. Turning the handwheel will operate the release on the front of the seat pan and free the leg restraint cords from the seat.

Harness Release

230. A lever is fitted on the forward LH side of the seat pan. Movement of the lever to the rear allows the seat occupant to lean forward against

the pull of a spring-loaded harness reel. As the occupant leans back the harness will be snubbed at all positions and the lever must be operated to lean forward again.

Seat Raising Handle

231. A lever is fitted on the LH side of the seat. By depressing a spring-loaded plunger in the end of the lever, and moving the lever up or down, the seat pan will raise or lower. When the plunger is released it will engage in one of several locating holes and lock the seat pan in position.

232. Further information on the ejection seat is contained in Arrow 1 Service Data - Section 31 - Ejection Seat, Mk C5.

EMERGENCY EQUIPMENT

Engine Fire Detection and Extinguishing System

233. A system of cable type fire detectors are located in three potential fire areas. These areas are the RH engine compartment, the LH engine compartment and the hydraulic and equipment bay. The detectors sense a fire or an overheat condition existing in these areas and cause the illumination of warning lights. Two container bottles of fire extinguishing chemical are carried. For the first flights three additional bottles are fitted in the armament bay. These are operated by the existing switches.

234. The fire warning and extinguishing panel marked FIRE is mounted on the LH console in the pilot's cockpit. The panel contains three red lights marked LH, HYD, RH; the lights are provided with transparent covers. A toggle switch protected by a guard is marked SECOND SHOT. A second toggle switch protected by a guard is marked CRASH FIRE.

235. Fire indication is given by the illumination of the master red warning light on the main instrument panel. At the same time a red warning light will illuminate on the FIRE warning/extinguishing panel. The particular light that illuminates will indicate the location of the fire.

236. The extinguisher is operated by lifting the cover and pressing the illuminated bulb on the FIRE panel. This action will release one bottle of extinguishing chemical into the appropriate fire area. The remaining bottle of extinguishing chemical may be discharged into the same fire area if the warning light does not go out, by lifting the cover and selecting the SECOND SHOT switch. Alternatively, should a fire occur in either of the other two areas, the second bottle may be used by pressing

Part 1

the appropriate warning light. (On the first aircraft operating either engine fire extinguisher will discharge two bottles into the affected area. Operating the HYD bay extinguisher will discharge one bottle into that bay).

CAUTION

Should a fire occur in either the LH or RH engine compartments, the appropriate HP and LP fuel cocks should be selected off before operating the fire extinguisher. (See part 3 of para 15.)

237. The CRASH FIRE switch distributes the contents of the fire extinguisher bottles in the event of a crash landing. The switch should be operated after the throttles have been placed in the "cut-off" position and the LP FUEL COCKS have been switched off. Operating the switch will discharge the contents of one bottle into the hydraulic and equipment bay and the contents of the other bottle will be divided between the LH and RH engine bays. (On the first aircraft, when the three additional bottles are fitted, the crash switch will discharge two bottles into the hydraulic and equipment bay and one and one-half bottles into each engine bay).

238. Power for the fire extinguishing system is taken from the emergency bus and therefore the system will operate regardless of the position of the master electrical switch.

Bail-out Signal

239. A switch, protected by a guard and marked NAV BAIL OUT is located on the LH console, aft of the power controls. Operating the switch will illuminate a red warning light on the navigator's panel marked BAIL OUT and a signal horn will be energized to warn the navigator to eject. A green light on the pilot's main instrument panel, marked NAV BAIL OUT, will also illuminate. The green light will go out when the navigator ejects. Power is supplied from the emergency bus.

Emergency Operation of the UHF and IFF on Seat Ejection

240. Upon the ejection of either seat from the aircraft, a switch located on the seat bulkhead is actuated and causes emergency operation of the IFF. At the same time the emergency channel of the UHF set is energized and causes an MCW signal to be transmitted. Provided the IFF and UHF had previously been selected on, the signals transmitted will enable ground stations to obtain a fix on the aircraft's position.

241. A test push button switch marked PRESS-TO-TEST - UHF/IFF EMERG, is located on the pilot's RH console. Testing should be carried out according to Telecommunication Confidential Orders.

Parabrake

242. A brake parachute is fitted in the rear end of the fuselage and is mechanically controlled through cables by a lever which has STREAM and JETTISON positions. The lever is located in the pilot's cockpit, aft of the engine power controls. The parachute is released through two doors above the stinger by moving the lever downwards to the STREAM position. The action of the parachute when released slows the aircraft after landing. A shear pin is fitted which will shear if the parachute is released during flight. The parachute may be jettisoned after completing the landing run, or in an emergency, by moving the control lever inwards and downwards to the JETTISON position. An indicator is fitted below the tail cone and is visible when a parachute is not installed. The installation of a parachute raises the indicator flush with the skin.

FLIGHT INSTRUMENTS

Pitot-Static System

243. Three pressure heads are fitted to the aircraft and supply pitot and static air pressure to the various instruments, controllers and transducers. One pressure head is installed on the forward end of the air data probe at the aircraft nose, while two are fitted to the leading edge of the fin. The lower pressure head on the fin is used for flight test instrumentation only, while the upper is utilized by the flying control emergency damping system transducer.

244. The pitot and static pressure from the nose pressure head is transmitted to the Mach/airspeed indicator and the flying control normal damping system transducer. The static pressure, in addition, serves the altimeters, rate of climb indicator, cabin pressure regulator and safety pressure valve controllers.

Mach/Airspeed Indicator

245. The Mach/Airspeed Indicator is mounted on the pilot's main instrument panel. Indicated airspeed and mach number are displayed on a single dial, and a striped pointer provides a constant indication of the maximum allowable airspeed at any altitude. An adjustable index allows a landing speed to be pre-set. The split airspeed pointer indicates mach number on the inner scale, with the corresponding IAS on the outer scale.

Part 1

Altimeter

246. An altimeter is mounted on the main instrument panel in both cockpits. The instrument has three pointers and incorporates a cut-out window. The largest pointer registers hundreds of feet, the intermediate pointer registers thousands of feet while the small pointer indicates tens of thousands of feet. A striped area is progressively covered during a climb and is uncovered again upon descending. During descent, the striped area commences to uncover at 16,7000 feet, and is fully uncovered at zero feet. This warning provides an additional indication, during a rapid descent, that the aircraft is approaching the lower altitudes.

Skin Temperature Indicator

247. A skin temperature indicator is mounted on the LH side of the pilot's main instrument panel. During flight the instrument registers the temperature of the aircraft skin taken from the underside of the radar nose. When the aircraft is on the ground the indicator registers the outside air temperature.

Sideslip and Angle of Attack Indicators

248. A sideslip indicator and an angle of attack indicator are mounted on the pilot's main instrument panel. Vanes, fitted to the air data probe, sense any change in direction of the relative airflow to the aircraft datum, both in the lateral and vertical axes. Movement of the vanes is transmitted to the indicators and the angle of sideslip and/or the angle of attack of the aircraft are shown on the appropriate indicators in degrees.

(This page intentionally left Blank)




FIG 1-7 PILOT'S COCKPIT LAYOUT

1	U/C UP MODE - DAMPER TEST	33	Accelerometer	68	RAIN REPELLENT ON-OFF Switch (TEMP CONTROL/EMERG OFF. First aircraft)
2	IFF Control Panel	34	Sideslip Indicator	69	CABIN PRESS DUMP Switch
3	DAMPING SYSTEM Circuit Breaker Panel	35	Angle of Attack Indicator	70	AIR SUPPLY NORM-OFF EMERG Switch
4	DAMPER, POWER ON-OFF Switch	36	NAV BAIL OUT Indicator	71	DEFOG ON-OFF Switch
5	DAMPER, EMERGENCY Push Button Switch	37	Red Master Warning Light	72	TEMP COOL-WARM Selector
6	DAMPER, ENGAGE Push Button Switch	38	Amber Master Warning Light	73	Anti-g Valve Manual Override Button
7	Control Surface Response Indicator	39	Standby Magnetic Compass	74	INTER Control Panel
8	COMM, Radio Control Panel - ARC-34	40	RADIO MAGNETIC INDICATOR	75	UHF/IFF EMERG, PRESS TO TEST Button
9	High Altitude Flood Light	41	FUEL QUANTITY Gauges	76	J4 COMP, AEROBATICS - NORMAL Switch
10	Console Flood Light	42	CHECK LIST TAKE OFF	77	UHF ANT, UPPER-LOWER Switch
11	RUDDER TRIM, LEFT-RIGHT Switch	43	Artificial Horizon Indicator	78	RMI NEEDLE, TACAN-UHF HOMER Switch
12	FIRE Extinguisher, SECOND SHOT Switch	44	GYRO ERECT Push Button	79	RADIO COMPASS Panel
13	FIRE-Combined Warning Lights and Selector Switches, LH, HYD, RH	45	EMERGENCY CANOPY OPENING Lever	80	J4 COMP - LAT Correction Controller
14	NAV BAIL OUT Warning Switch	46	Engine PRESSURE RATIO Gauges LH and RH	81	J4 COMP - NAG/DG Selector Switch
15	L.P. FUEL COCKS Switches and Guards	47	EXH TEMP Gauges LH and RH	82	J4 COMP - DECR/INCR/SET Switch
16	CROSSFEED, LH ONLY - NORMAL - RH ONLY Switch	48	CABIN PRESSURE ALTITUDE Gauge	83	J4 COMP - Hemisphere Selector Switch
17	ENGINE FUEL, EMERG-RESET Switches and Guards	49	PRESS TO RESET Push Button	84	J4 COMP - Synchronizing Indicator (Annunciator)
18	Parachute Brake, STREAM - JETTISON Selector Lever	50	DAY - NIGHT Switch	85	ENGINE START, START-OFF-RESET, LH an RH Switches
19	Throttle Levers, LH and RH	51	PRESS TO TEST Switch	86	MASTER ELEC ON-OFF Switch
20	Console Flood Light	52	ENG BLEED Air Conditioning Warning Lights	87	Warning Lights Panel
21	SPEED BRAKE, IN-OUT Switch	53	ENG BLEED AIR LH OFF-NORMAL- RH OFF Switch	88	Rudder PEDAL ADJUST Handle
22	ANTI-SKID, NORM-EMERG-OFF Switch	54	Map Light	89	RPM Indicators
23	LIGHTS LAND-TAXI-OFF Switch	55	OXYGEN Quantity Gauge	90	Altimeter
24	CANOPY CLOSE-OFF-OPEN Switch	56	Console Flood Lights (2)	91	Rudder Pedal Adjustment Label
25	ELEV TRIM DISENGAGE Switch	57	RAM AIR TURBINE Switch	92	Turn and Slip Indicator
26	Landing Gear Control Lever, UP-DN	58	NAV LIGHTS, FLASH-OFF-STEADY Switch	93	Rate of Climb Indicator
27	Landing Gear EMERGENCY EXTENSION Locking Latch Push-Button	59	ALTERNATORS RESET ON-OFF LH and RH Switches	94	Automatic Mode Disengage Switch
28	Parking Brake Handle	60	DC RESET Push Button	95	Elevator and Aileron Trim Button
29	LANDING GEAR POSITION Indicator	61	Console Light	96	Emergency Damping Engage Switch
30	SKIN TEMP Indicator	62	COCKPIT LIGHTING Panel	97	Nose Wheel Steering Selector
31	Mach/Airspeed Indicator	63	HIGH ALT LIGHTING ON-OFF Switch	98	Press-to-transmit Push Button
32	CHECK LIST, LANDING	64	MAIN PANEL OFF-BRIGHT Selector	99	Throttle Friction Damper
		65	CONSOLE PANELS OFF-BRIGHT Selector	100	Engine Relight Switch, LH and RH
		66	CONSOLE FLOOD OFF-BRIGHT Selector		
		67	AIR COND Panel		

PILOT'S COCKPIT LAYOUT




FIG 1-8 NAVIGATOR'S COCKPIT LAYOUT

NAVIGATOR'S COCKPIT

1. Console Flood Lights (3)
2. CANOPY, OPEN-OFF-CLOSE Switch
3. OXYGEN Quantity Gauge
4. Altimeter
5. Access Panel to Navigator's Canopy Locking Handle from Front Cockpit
6. Navigator's BAILOUT Warning Light
7. RADIO MAGNETIC INDICATOR
8. EMERGENCY CANOPY OPENING Lever
9. HIGH ALT LIGHTING, ON-OFF Switch (Non-operative)
10. PANEL LIGHTS OFF-BRIGHT Selector Switch
11. CONSOLE FLOOD OFF-BRIGHT Selector Switch
12. RADIO COMPASS Control Panel ARN-6
13. PRESS TO TALK Switch
14. IFF-TACAN ANTENNA SELECT Switch
15. UHF HOMER - TACAN RMI NEEDLE Selector
16. INTER, Interphone Mixing Switch
17. COMP, Radio Compass Mixing Switch
18. COMM, Command Receiver Mixing Switch
19. TACAN Mixing Switch
20. TEL, Telescrumble Mixing Switch
21. INTER Control Panel AIC-10
22. Console Flood Lights (2)
23. CALL, INTER, COMM, TEL Rotary Selector
24. Map and Emergency Light
25. Console Flood Light
26. Anti-g Suit Pressure Regulator Manual Override

Part 1

(This page intentionally left Blank)

PART 2

HANDLING

PRELIMINARIES

Before Entering the Aircraft

1. Check RCAF Form L14A for fuel, oil and oxygen quantities, and signatures completed throughout by tradesmen concerned. Note unserviceabilities, if any.
2. Compute engine pressure ratio for take-off.
3. Carry out the Exterior Inspection as shown on Fig. 2-1.

Solo Flying

4. If the aircraft is to be flown with the rear cockpit unoccupied, check in the rear cockpit:
 - (a) Harness secured.
 - (b) All loose articles of equipment removed and stowed.
 - (c) Safety pins in position in seat sear, canopy sear, drogue gun and alternate firing handle.
 - (d) Rear canopy locked.

Before Entering the Cockpits

5. Make the following checks (front and rear seat occupants as applicable):
 - (a) Check the emergency oxygen pressure gauge; a fully charged cylinder registers 1800 psi.
 - (b) Check that the drogue gun static lines are attached to the bracket on the ejection gun body.

After Entering the Cockpit

6. Make the following checks. (Front and rear seat occupants as applicable):




FIG 2-1 EXTERIOR INSPECTION

Nose (View A-B-C)

- (1) Probe secure and cover removed.
- (2) Radome secure.
- (3) Radar access doors (three) secure.
- (4) Nose U/C door undamaged.
- (5) Nose wheel well.
 - (a) Emergency nitrogen bottle pressure - 5000 psi minimum.
 - (b) Circuit breakers set.
- (6) Landing and taxi lights undamaged.
- (7) Tires for cuts and creep, nose wheel aligned fore and aft.
- (8) Shock absorber strut extension normal.
- (9) Condition of nose U/C leg door.
- (10) No hydraulic leaks.
- (11) Nose wheel ground locking pin removed.

Underside of Aircraft (View A)

- (12) Air conditioning equipment access panel secure.
- (13) (a) Electronic equipment access door secure.
- (b) Circuit breakers set (visual through inspection port).
- (14) LH and RH electronic equipment access doors secure.
- (15) Instrument pack for damage. Check for security.
- (16) Electrical equipment access doors secure.
- (17) LH and RH speed brakes for damage.
- (18) Master refuelling/test panel door. closed.
- (19) Pressure refuelling LH and RH access doors secured. (On the first aircraft check the manually operated gate valves are set to FLIGHT POSITION VALVE OPEN).
- (20) Hydraulic equipment access panel secure.
- (21) LH and RH engine access doors secured.
- (22) Service panel No. 1, gearbox panel and service panel No. 2 secured.
- (23) Engine access doors secured.
- (24) Compensator removal panel secure.
- (25) "Blow-in" air inlet doors closed.
- (26) Service panels No. 3 and No. 4 secure.

- (27) LH and RH engine removal doors secure.

Rear of Aircraft (View A-B-C)

- (28) Jet pipe exhaust covers removed. Jet pipes undamaged. Check for fuel, oil, water or ice accumulation.
- (29) (a) Parabrake doors closed.
- (b) Red indicator NOT protruding. (Denoting 'chute' installed).

LH Side of Aircraft (View C)

- (30) Pitot covers removed.
- (31) Fin and rudder surfaces, navigation lights, access panels for security and damage.
- (32) Aileron and elevators for damage and control support removed.
- (33) Underside of skin for fuel leaks or damage. Leading edge undamaged.
- (34) "Blow-in" air inlet doors closed.
- (35) (a) Check for red crank pointer touching recuperator body. (Nitrogen pressure indicator).
- (b) Check recuperator oil level.
- (c) Leg extension normal.
- (d) Tires for cuts and creep.
- (e) No hydraulic leaks.
- (36) Main wheel ground lock on side stay removed.
- (37) (a) U/C fairings undamaged.
- (b) Check lower spring housing locking cams on fairings.
- (38) Access doors secure.
- (39) (a) LH Engine intake cover removed.
- (b) De-icing boots on intake and ramp undamaged.
- (40) Air conditioning ram air inlet cover removed.

RH Side of Aircraft (View B)

Check as for LH side, items 31 to 40.

- (41) Emergency canopy opening panel secure.

Upper Surfaces of Aircraft

Visually inspect the upper surfaces (including windscreen and canopies) for damage and security of panels prior to entering the cockpit.

- (42) Ensure that the air conditioning outlet duct cover is removed.

Part 2

- (a) Check that the ejection seat manual override control lever is locked fully forward.
- (b) Fasten and adjust the parachute/safety harness and the leg restraint straps.
- (c) Adjust the seat height in order to position the head correctly in relation to the headrest and adjust the rudder pedals for reach. Check the rudder pedals for correct adjustment.
- (d) Plug in the radio, oxygen and anti-g suit connections to the composite leads disconnect fitting.
- (e) Check that the ground crew remove and stow the safety pins from the sears of the ejection gun, drogue gun and the canopy. The alternative firing handle safety pin can only be removed by the seat occupant, and it should be stowed by the ground crew.
- (f) Check that all individual electrical switches are OFF.

NOTE

The ALTERNATOR switches, LP COCK and DAMPER POWER switches may normally be left on.

- (g) Check that the U/C selector lever is down, and that the position of the speed brakes selector corresponds to the speed brakes position before energizing the electrical system.
- (h) Signal the ground crew to plug the ground starter cart and the external AC power supply into the aircraft receptacles.
- (j) Switch the Master Electrics switch - ON.

NOTE

When the Master Electrics switch is switched on the FUEL PROP and FUEL LOW warning lights may illuminate momentarily.

- (k) Check that the AC FAIL and DC FAIL warning lights are out. On the first flights of the first aircraft the BATT USE light will remain on until an engine is started. The battery is not isolated when the DC supply is plugged in.

- (m) AIC-10 switches (as required).
INTER mixing switch ON.
COMM mixing switch ON.
Rotary selector - COMM.
- (n) ARC-34 transmitter-receiver (as required).
Function selector switch - BOTH.
Operational mode push selector - PRESET.
Frequency selector switch to the desired channel.
- (p) J4 COMPASS (as required).
MAG - DG switch to MAG.
NORMAL/AEROBATICS switch to NORMAL.
- (q) IFF selector switch to STANDBY.
- (4) Air conditioning -
AIR SUPPLY switch to NORM.
CABIN PRESS/DUMP switch to CABIN PRESS.
DEFOG switch - as required.
Cabin TEMP-COOL/WARM rheostat switch mid position.
TEMP CONTROL switch - normal position (Upright).

NOTE

With the external air supply plugged into the aircraft, the above air conditioning switches will be inoperative. However, selections made at this time will be operative when the external air supply is disconnected, and full air supply will be available when the landing gear is raised after take-off.

- (s) Operate the PRESS-TO-TEST switch on the warning light panel and check that the warning lights illuminate. Release the switch and check that the lights go out. OIL PRESS and ENG FUEL PRESS warning lights will remain on, and the hydraulic pressure warning lights may remain on.
- (t) Landing and taxi lights - check operation. Switch OFF. (Landing and taxi lights are not fitted for the first flights of the first aircraft).

Part 2

- (u) Landing Gear - Lever in the DOWN position, warning light in handle not illuminated, and gear indicator showing landing gear locked down.
- (v) Fuel Contents - Registered correctly.
- (w) Check ENGINE FUEL switch at NORMAL.
- (y) Check A.S.I. limiting speed pointer is set.
- (z) Operate the NAV BAIL OUT switch. Check that the NAV BAIL OUT green light in the front cockpit illuminates. Check with the navigator that the red BAIL OUT light illuminates and that the warning buzzer sounds. Return the switch to off.
- (aa) Throttle levers in the cut-off position.
- (ab) DAMPER POWER switch - check ON.
- (ac) Artificial horizon erected. If necessary press gyro ERECTION button after gyro has run up for 30 seconds. OFF indicator not visible.
- (ad) Turn and bank indicator erected. OFF indicator not visible.
- (ae) Check oxygen mask for fit and test for flow. Check quantity.
- (af) Front and rear cockpit canopies closed and fully locked.

CAUTION

Check that the canopy lever is in the extreme forward position and not in the detent position. In the detent position the canopy will lock, but the seals will not inflate, and the lever will not be free of the latch mechanism. The lever is nearly horizontal when locked fully forward.

STARTING PROCEDURE

Preliminaries

7. If starting one engine at a time, always start the RH engine first to check functioning of the RH pumps on the flying control and utility systems. The LH pumps may be checked on engine shut down




FIG 2-2 JET WAKE AND INTAKE DANGER AREAS

Part 2

by stopping the RH engine first.

WARNING

All personnel must be kept clear of both intake and jet pipe. (See Fig. 2-2 JET WAKE diagram).

Procedure for starting

8. Adopt the following sequence:

- (a) Check with ground crew as follows:
 - (1) Intercom functions satisfactorily.
 - (2) Cockpit access stand clear of aircraft.
 - (3) Fire extinguisher in position.
- (b) Parking brake ON.
- (c) Check that the master electrical switch is ON.
- (d) Throttles - Cut-off position.
- (e) Check fuel:
 - (1) CROSSFEED - NORMAL
 - (2) LP cocks ON.
- (f) On receipt of the "ready to start signal" from the ground engine start operator, advance the appropriate throttle lever to the IDLE position and immediately pulse the appropriate ENGINE START switch to START.
- (g) Check turbine outlet temperature. A temperature rise within 10-15 seconds indicates engine "light-up". On the first aircraft the turbine outlet temperature gauge is operated by external AC supply, which must be plugged in to obtain a reading. On later aircraft the gauge will be supplied with AC power from the starter cart.

NOTE

The engine will accelerate to approximately

55% rpm. Turbine outlet temperature should not exceed 600°C, except momentarily, during the transition period to idle rpm. At idle rpm the turbine outlet temperature should drop to 340°C or below.

- (h) Check OIL PRESS and FUEL PRESS warning lights out. Check hydraulic pressure warning lights out, if they were illuminated before starting.
- (j) Check ENGINE EMERG FUEL light out.
- (k) Repeat the starting procedure for the other engine.
- (m) Check that the ALTERNATOR switches are on.

NOTE

When the AC ground power supply is disconnected, the aircraft alternators will automatically take over. Upon disconnection, check that the AC FAIL and DC FAIL warning lights remain out.

CAUTION

If the engines have been cold-soaked to a temperature of -35°C or below, allow the engines to idle for five minutes in order to warm up.

Engine at Idle

9. Check with the ground crew by means of the intercom that the engine overboard bleed valve is in the "open" position, that the air ejector nozzle is operating (indicated by visual overboard discharge) and that the spring loaded air inlet doors to the engine bay are in the "open" position.

Wet Start

10. If, during the normal starting sequence, no rise in temperature is observed within 20 seconds of opening the throttle lever to the idle position, a wet start has occurred and the following procedure should be carried out:

Part 2

- (a) Bring the throttle lever back to the cut-off position.
- (b) Hold the engine start switch to RESET for a period of 30 seconds only, then release the switch and carry out the normal starting procedure.
- (c) Should another wet start occur, bring the throttle lever back to cut-off position.
- (d) Switch the master electrics switch OFF.
- (e) Investigate the cause of failure to light up.

Hot Start

11. If, during the normal starting sequence, the turbine discharge temperature rises above 600°C for more than five seconds, the engine must be stopped immediately by placing the throttle to cut-off. The engine start switch should be selected to RESET momentarily; this will break the ignition circuit and shut off the ground starter air supply. Investigate the cause of the hot start before attempting a relight.

NOTE

All hot starts where a temperature of 600°C is exceeded must be recorded on Form L14A.

CAUTION

A maximum of three starting runs in 10 minutes is permissible. Two of these runs may be of 30 seconds duration and run consecutively.

FLYING CONTROLS CHECK - To be issued later.

TAXIING PROCEDURE

General

12. When the chocks have been removed and the brakes released, only a very small increase in engine power is necessary to start the aircraft moving. When taxiing, idle thrust is sufficient to keep the aircraft moving at a speed of approximately 25-50 mph.

Nose Wheel Steering

13. Nose wheel steering is engaged by aligning the rudder pedals to the corresponding nose wheel position and depressing the nose wheel steering push button located at the bottom left of the control column hand grip. The button must be maintained depressed during steering operations. The aircraft is steered by slowly moving the rudder pedals in the required turn direction.

NOTE

Movement of the nose wheel is governed to a maximum turning rate of 190 per second. Rapid movement of the rudder pedals or increased pressure on them will not affect the rate of turn of the nose wheel.

14. Steering is disengaged by releasing the button on the control column, when normal castoring action of the nose wheel is restored.

CAUTION

Use of brakes when nose wheel steering is in operation is still under investigation. If brakes are used at all, they must be applied carefully and at low speed only.

TAKE-OFF PROCEDURE)
ACTIONS AFTER TAKE-OFF) To be issued later.
FLYING CHARACTERISTICS)
LANDING PROCEDURE)

ENGINE HANDLING

Engine Pressure Ratio During Afterburning

15. When the afterburners are turned on, the engine pressure ratio may increase or decrease slightly. The acceptable variation will be published when available.

Low Pressure Compressor Overspeed Warning Light

16. When the afterburners are turned on, the LH and RH ROTOR O'SPEED lights may illuminate momentarily. This condition is normal and serves as an indication that the compressor overspeed light and mechanism are functioning normally.

Part 2

Engine Fuel System Failure

17. When operating on the EMERG fuel system, do not return the ENGINE FUEL switch to NORMAL for the remainder of the flight. This may result in engine flame-out. If checking the system in the air, the transfer back to NORMAL must be carried out with the power lever at idle to avoid a pressure surge in the fuel system.

18. The procedure for returning the fuel system to NORMAL, after ground checks or in the air is as follows:

- (a) Power lever of affected engine to IDLE.
- (b) Select ENGINE FUEL switch to RESET and hold for approximately 3 to 5 seconds after the EMERG FUEL warning light goes out.
- (c) Allow the switch to return to NORMAL.

Thrust Overshoot

19. When using engine pressure ratio to check engine power prior to take-off, a thrust overshoot may be noted when the power lever is advanced from idle to military thrust on a cold engine. This thrust overshoot will gradually diminish to the specified or computer value within five minutes or less. The condition is considered to be normal; however, it must not be relied upon for added performance during take-off.

END OF FLIGHT PROCEDURE

Stopping the Engines

20. Whenever the engines have been operated at high power settings for an appreciable length of time, they must be allowed to idle for up to five minutes prior to shutdown.

21. Stop the RH engine first by moving the RH power lever to the cut-off position. Operate the flying controls and check that the utility hydraulics and the flying control hydraulic warning lights do not illuminate. Stop the LH engine by moving the LH power lever to the cut-off position.

Action Before Leaving the Aircraft

22. Proceed as follows:

- (a) Master electrics switch OFF.

- (b) Centralize the control column and rudder pedals.
- (c) Parking brake ON.

23. With the flying controls in neutral, the control surfaces will be streamlined and locked against adverse wind forces. However, in a short time, full aileron and elevator "droop" will occur. If the aircraft is to be on the ground for any length of time, the hydraulic system pressure should be dissipated. Hold the control column central and move the rudder pedals slightly until no further movement of the rudder surface takes place. When this operation has been performed, the ground crew must fit the special aileron and elevator supports to the control surfaces to support their weight and prevent strain on the control linkages.

Part 2

(This page intentionally left Blank)

PART 3

EMERGENCY HANDLING

ENGINE FAILURE PROCEDURE

Engine Failure During Take-off - To be issued later.

One Engine Failure in Flight

1. If an engine fails in flight proceed as follows:
 - (a) Immediately close the throttle to idle and attempt to relight the engine.
 - (b) If the engine will not relight after one attempt, proceed as follows:
 - (1) Close the relevant throttle to cut-off position.
 - (2) Follow the relight procedure in para 5.
 - (c) If relight is inadvisable, adjust the trim for asymmetric flight.
 - (d) Select fuel crossfeed as required to balance fuel load.

Two-Engine Failure in Flight

2. If fuel is still available and the aircraft has sufficient altitude, and if there are no apparent mechanical defects in the engines, proceed as follows:
 - (a)
 - (1) Maintain airspeed above 250 knots EAS to provide pressure for the flying control hydraulics.
 - OR, (if the ram air turbine is fitted)
 - (2) If the speed is below 350 knots EAS select RAM AIR TURBINE switch ON.
 - (b) Carry out the relight procedure for one engine. If unsuccessful attempt to relight the other engine (See para 4 and 5).

NOTE

Do not use speed brakes unless absolutely necessary as they require pressure from the utility hydraulic system. This system




FIG 3-1 J75 RELIGHT CHART

WFL 10053-1
FORM 36-60

is, in the above emergency, driving the emergency alternator.

EMERGENCY RELIGHT IN THE AIR

General

3. The J-75 engine will relight at any combination of airspeed and altitude which falls within the "Normal Windmilling Start Range" indicated on Fig. 3-1. The "Probable Start Range" represents those combinations of airspeed and altitude at which engine relights may frequently, but not always, be made. For best results, when operating above the maximum altitude and airspeed combinations indicated in the "Normal Windmilling Start Range", reduce either the airspeed, the altitude or both until they are within the ranges shown on the chart.

Relight Procedure

4. Relights may sometimes be obtained at very high altitudes provided the relight is accomplished before the compressor rpm has decreased appreciably. In the event of a flame out at airspeeds and altitudes above the "Probable Start Region" on the chart, the following procedure should be tried immediately a flame-out at high altitude occurs:

- (a) Close the appropriate throttle to the idle position.
- (b) Press the relight button for 20 seconds and watch for an increase in turbine outlet temperature which indicates a relight.

5. If the above procedure is unsuccessful proceed as follows:

- (a) Throttle lever to cut-off.
- (b) Windmill the engine for 20-30 seconds to dry out surplus fuel.
- (c) Fuel Control Selector - NORM (EMERG if a primary fuel system failure is suspected).
- (d) Adjust the IAS and altitude to within the "Normal Windmilling Start Range" (Fig. 3-1).
- (e) Advance throttle lever to idle and at the same time press and hold the relight button for 20 seconds.
- (f) Watch for an increase in turbine outlet temperature which indicates a relight.

Part 3

(g) When turbine outlet temperature has settled down, open the throttle lever to the desired position and resume normal flight.

FLYING CONTROLS - EMERGENCY PROCEDURES

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber plus Left Hand LFY CONT HYD warning light. Plus EMERG DAMP and R/P AXIS OUT	Loss of hydraulic pressure in 'B' system	Reduce speed	Land as soon as possible	
Master amber Right Hand FLY CONT HYD warning light.	Loss of hydraulic press in 'A' system	Ensure mode of flying control remains in NORMAL. Land as soon as possible.		
TWO ENGINE FAIL (at least one engine windmilling). Master RED and AMBER plus LH and RH FLY CONT HYD. (Provided airspeed is less than Mach .4 @ S/L or .85 @ 55,000'). EMERG DAMP, R/P AXIS OUT		(1) Maintain air-speed above 250 knots EAS. or Select RAM AIR TURBINE switch ON (Speed below 350 knots) if fitted. (2) Check that the emergency alternator is operating (i.e. emerg damp system, J4 Comp., artificial horizon, IFF).	Proceed to relight one engine.	

FLYING CONTROLS - EMERGENCY PROCEDURES (Cont'd)

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber plus EMERG DAMP plus R/P AXIS OUT	Flight Limits Exceeded (a) Sideslip in excess of 10° and/or (b) Excessive transverse acceleration	Reduce manoeuvre	Re-engage normal mode when manoeuvre completed	
Master amber plus R/P AXIS OUT.	Flight Limits Exceeded (a) Roll rate in excess of 159°/sec. OR (b) Pitch 'g' in excess of 4-1/2 g to 5 g. OR Both (a) and (b) combined	Reduce manoeuvre	Re-engage normal mode when manoeuvre completed. Check "R/P AXIS OUT" light goes out.	
Master amber plus DAMP OUT plus EMERG DAMP and R/P AXIS OUT	(a) Change over was made to EMERGENCY mode, but the 'A' hydraulic system was unserviceable. OR (b) Damper power switch is OFF (c) Damping not engaged.	(a) Re-engage normal mode if possible. (b) Select damper power ON. (c) Engage normal damping.	(a) Land as soon as possible. (b) and (c) NIL.	Loss of stability in yaw at high speeds. Controllable at low speeds with no damping.

FLYING CONTROLS - EMERGENCY PROCEDURES (Cont'd)

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Considerable force required to move control column	Seized elevator trim unit or seized parallel servo	Overcome fault by force on stick. Select Disengage on stick button, if not effective, select ELEV TRIM DISENGAGE	Reduce speed. If selecting ELEV TRIM DISENGAGE cured the condition, pilot may re-engage into normal mode. Land as soon as possible.	
Any unusual elevator movement not commanded by pilot in NORM or EMERG mode	Runaway elevator trim motor or runaway parallel servo	Overcome fault by force on stick. Select Disengage on stick button. If not effective, select ELEV TRIM DISENGAGE	Reduce speed. If selecting ELEV TRIM DISENGAGE cured the condition, pilot may re-engage into normal mode.	

Part 3

[illegible]

ELECTRICAL SYSTEM EMERGENCY PROCEDURES (Cont'd)

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber plus LH and RH ALTERNATOR FAIL lights. (Will be accompanied by the DC FAIL light and BATT USE light.)	(1) Flame-out of both engines (2) Failure of both electrical-generating systems	(1) Refer to two-engine flame-out procedure, para 3-2. (2) Move both ALTERNATOR switches to RESET and back to ON.	(2) Refer to one alternator failure above. BATT USE light will go out when DC is reset.	Emergency AC power will automatically be supplied by the emergency alternator. The battery will supply emergency DC power.
Master amber plus DC FAIL	Failure of one TRU	Press DC RESET button.	If DC FAIL light goes out (master amber will also go out) - No further action required. If DC FAIL light does not go out PRESS TO RESET master amber. The other TRU will maintain the DC services less the landing and taxi lights	

ELECTRICAL SYSTEM EMERGENCY PROCEDURES (Cont'd)

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber plus DC FAIL and BATT USE	Failure of both TRUs	Press DC RESET button	If one TRU resets, the BATT USE light will go out - PRESS TO RESET master amber. If both TRUs reset, the DC FAIL, BATT USE and master amber light will go out. If all lights remain) on - PRESS TO RESET) master amber. Land as) soon as possible.)	<u>CAUTION</u> (Limited DC loads (are now taken (from the aircraft (battery.

FUEL SYSTEM - EMERGENCY PROCEDURES

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber, plus LH or RH ENG FUEL PRESS warning light	Relevant booster pump inoperative (Pressure has dropped below 18 psi)	NONE. Tank pressurization will maintain sufficient fuel delivery to the engine pumps to maintain military rating.	Throttle back affected engine until light goes out. PRESS-TO-RESET master amber.	Excessive engine operation in this condition is detrimental to engine pumps, particularly after high speed operations, due to temperature effects. Crossfeed from the side with most fuel, when one sub-system is empty.
Master amber plus FUEL PROP warning light. In flight). (FUEL LOW light NOT on).	Inoperative fuselage transfer pump OR A transfer pump has lost its prime	Climb the aircraft above 100 nose-up for 15 seconds. If it occurs on a descent, open up the engines momentarily to military rating.	If the light goes out, no further action. If light remains on, avoid sustained operation at high altitudes. Fuselage tank fuel may not be used in proportion to other tanks, particularly at high altitudes. PRESS-TO-RESET master amber.	Fuel quantity should be closely monitored. When fuel quantity on one side reaches approximately 2300 lb., the remaining fuselage tank contents may not be usable at the altitude of operation. However, it will be usable at sea level.

FUEL SYSTEM - EMERGENCY PROCEDURES

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber plus FUEL PROP warning light. (LH or RH FUEL LOW warning light on temporarily.	Relevant fuel flow proportioner seized.	NONE Automatic control of the fuel C of G has ceased.	Avoid violent manoeuvres. PRESS-TO-RESET master amber.	
Master amber plus LH or RH FUEL LOW warning light plus FUEL PROP warning light.	Aircraft fuel supply low on that side. (Light illuminates when fuel is down to 740 lb on that side). OR Stalled flow proportioner.	Prepare to land at nearest airfield. Throttle back affected engine until light goes out.	(1) Cross check fuel supply with content gauges. (2) Crossfeed when one sub-system is empty. PRESS-TO-RESET master amber.	
One engine failure (Engine will not relight).		Carry out engine fail procedure (See para 3-1). Throttle lever of failed engine to cut-off.	Maintain fuel weight on each side approximately equal by alternating the fuel CROSSFEED between NORMAL and the failed engine side during the flight.	Adequate aileron control is available to maintain flying control with an unbalanced fuel condition. It is preferable however, to maintain the fuel quantity in each side approximately equal, due to shift in C of G which may occur.

FUEL SYSTEM - EMERGENCY PROCEDURES (Cont'd)

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
<u>ON GROUND</u> Master amber plus FUEL PROP warning light.	(1)Refuelling access doors not properly closed or defective access door micro- switch. (2)Master refuelling switch inadvertently left on. (3) A seized fuel flow proportioner (If engines are running).	Inform ground crew.		

AIR CONDITIONING AND PRESSURIZATION EMERGENCY PROCEDURES

100

Part 1

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master Amber plus AIR COND FAIL warning light	<u>On Ground</u> (1) Low engine rpm on hot day taxi. <u>In Air</u> (2) Cooling turbine outlet air exceeds 80°F. (3) Lack of water in air-to-water heat exchanger. (4) Seized Turbine.	<u>On Ground</u> (1) Increase engine rpm <u>In Air</u> Reduce power - if light does not go out then:- Speed below Mach 1.2 Select AIR SUPPLY switch - EMERG	<u>In Air</u> Reduce altitude. Land as soon as possible. PRESS TO RESET master amber	
Master amber plus CABIN PRESSURE warning light. (Check with cabin pressure gauge).	Cabin pressure has reached the equivalent of 31,000 feet, ±1800 feet or higher. (1) Failure of the canopy seal. (2) Cabin pressure switch on DUMP. (3) Air supply switch on EMERG or OFF. (4) Sticking open of cabin pressure safety valve or controller failed. (5) See below.			

AIR CONDITIONING AND PRESSURIZATION EMERGENCY PROCEDURES (Cont'd)

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber plus CABIN PRESSURE Warning light. (Check with cabin pressure gauge).	(5) Sticking open of outflow valve or controller.			
LH or RH ENG BLEED warning light (RED) (No master warning light indication).	(1) Leaking of hot engine bleed air occurring OR (2) Failure of pressure reducing valve.	Select LH OFF or RH OFF, depending on which light illuminates) on the ENG BLEED AIR toggle switch.	Warning light will go out when condition is relieved. Switch must be maintained in the LH OFF or RH OFF position while air-borne.	
Master amber plus EQUIP O'HEAT warning light.	Equipment area temperature has exceeded 100°F.	If light on for short period - NONE. If light remains on select TEMP CONTROL switch to EMERG OFF.	PRESS-TO-RESET master amber.	Light should go out, as the hot air is automatically shut off until the equipment area temperature has reduced to 60°F.
Cabin uncomfortably hot.	Cabin temperature control valve failed.	Select TEMP CONTROL switch to EMERG OFF.		

ENGINES - EMERGENCY PROCEDURES

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
Master amber plus LH or RH ROTOR O'SPEED warning light on momentarily	Temporary over-speeding of a low pressure compressor.	NONE		Occurs when the afterburner is lit or shut down.
Master amber plus LH or RH ROTOR O'SPEED warning light on steadily.	Malfunction of a low pressure compressor overspeed limiter.	Reduce engine power until light goes out.	Maintain warning light out by reduced power and speed.	
Master amber plus LH or RH FUEL PRESS warning light.	See FUEL SYSTEM EMERGENCIES			
Low turbine discharge temperature.	Afterburner nozzle remaining open after closing down afterburner.	Retard throttle lever out of after-burner range on quadrant.		
Low turbine discharge temperature	Afterburner fails to light up, but nozzle opens.	Retard throttle lever out of afterburner range on quadrant.		
Master amber plus ICE warning light.	Ice detectors icing and de-icing.	If engines are operating at relatively high thrust - no further action. If descending or engines are operating at relatively low (See below)	Further action depends upon icing conditions.	(The interval between the lights going on and off will denote the severity of the icing conditions. Short interval will denote severe icing.

ENGINES - EMERGENCY PROCEDURES (Cont'd)

PILOT INDICATION	PROBABLE CAUSE	IMMEDIATE ACTION	FURTHER ACTION	REMARKS
		thrust, open up engines occasionally to provide additional heat	See EO 05-1-1 Pilot's Operating Instructions-General	
One engine flame-out occurring for no apparent cause.	Malfunction of hydro-mechanical fuel flow control unit.	Select ENG FUEL switch to EMERG.	Carry out engine re-light procedure.	Complete the flight in EMERG fuel. Ensure turbine discharge temperature does not exceed limits.
Rapid rise in turbine discharge temperature for no apparent cause.	Malfunction of hydro-mechanical fuel flow control unit.	Select ENG FUEL switch to EMERG.	Check that the EMERG selection corrects the condition.	Check that the EMERG selection corrects the condition.
Rough engine operation	Malfunction of hydro-mechanical fuel flow control unit.	Select ENG FUEL switch to EMERG.	Check that the EMERG selection corrects the condition.	Complete the flight in EMERG fuel. Ensure turbine discharge temp. does not exceed limits.
One engine or two engine flame out. (Possibly through excessive manoeuvring causing interrupted air flow to engine inlet).	Compressor stall.	Throttle to idle and attempt an immediate relight of one engine.		See Part 3, para 2).
Master amber plus LH or RH OIL PRESS warning light.	Engine oil pressure has reduced to 25 psi or below.	Shut down affected engine.	Reduce speed in order to lower windmilling rpm of affected engine. PRESS TO RESET Master amber.	

Part 3

EMERGENCY LANDINGS

6. All emergency landings, either on prepared or unprepared surfaces, should be made with the landing gear down. The extended gear, even on reasonably rough terrain, helps to absorb the initial shock. The inherent nose high landing attitude will result in a severe "slap" into the ground if the tail section is permitted to take the initial shock of a wheels up landing.

LANDING GEAR EMERGENCY PROCEDURES

General

7. The procedure to be adopted is dependent upon the indications given by the UTIL HYD warning light and the landing gear position indicator. It should be noted that once the emergency nitrogen system has been used, the landing gear cannot be reselected up, therefore the following procedure should be carried out in the sequence given.

Hydraulic Pressure Normal

8. If the UTIL HYD warning light is not illuminated, there should be sufficient hydraulic pressure to open the doors and unlock the landing gear.

9. If, after a normal down selection the indicators show that the gear is still locked up, a fault in the selection circuit is indicated. In this case, proceed as follows:

- (a) Re-select UP and DOWN a number of times.

NOTE

If the BATT USE light is illuminated, the landing gear selector valve is inoperative. (See Part 1, para 44 NOTE). In this case the action in sub-para (a) above will have no effect and is unnecessary.

- (b) If this fails, push the thumb latch button and move the landing gear handle fully down to the EMERGENCY EXTENSION position.

10. If, after a normal down selection, the indicators show a between-locks indication for one or more of the legs, an indicator fault or a mechanical fault is indicated. In this case, proceed as follows:

- (a) Attempt to lock the gear down by yawing to the left and right to open the doors and shake the legs down by applying positive 'g' in the pitching plane. Wagging the wings and accelerating the aircraft to 250 knots EAS

may also help to lock the gear down.

(b) If this does not obtain a locked down indication, check with the control tower to see if the gear appears to be locked down.

(c) If the gear is not locked down, re-select UP and make a wheels-up landing.

Insufficient Hydraulic Pressure

11. If the UTIL HYD warning light is illuminated there will probably be insufficient hydraulic pressure to unlock the doors and landing gear locks. (See para 12). In this case use the EMERGENCY EXTENSION selection.

BRAKE EMERGENCY PROCEDURES

Emergency Operation of the Brakes

12. Two accumulators in the utility hydraulic system supply emergency brake pressure automatically upon failure of the normal supply. Indication that the normal supply has failed (pressure reduced to 1000 psi or less) is given by the illumination of the UTIL HYD warning light. (See para 11).

13. When a landing after a utility system failure the brakes should be applied sparingly, pumping should be avoided, and every effort should be made to complete the landing run with as few applications of the brakes as is possible.

CAUTION

After completion of the landing run do not taxi the aircraft, even though brake pressure may still be available. Shut down the engines.

14. Should the pressure in the accumulators fall below 1600 psi, the light on the warning panel marked EMERG BRAKE HYD will illuminate. This light warns the pilot that the aircraft brakes will be ineffective upon landing.

Engine Thrust at Idle RPM

15. Engine thrust at idle rpm is comparatively high. In a case of brake failure, the engines should be stopped as soon as possible.

Part 3

AIRFRAME AND ENGINE ICING

General

16. The anti-icing and de-icing systems are entirely automatic. No manual controls are provided. If the automatic functions fail during icing conditions the aircraft should be operated as laid down in Pilot's Operating Instructions General EO 05-1-1.

Engine Anti-Icing

17. Only intermittent use of high rpm during descent under severe icing conditions is necessary. At the relatively high thrust setting used during climb or cruise, the hot air to the compressor inlet section of the engine is adequate to prevent ice formation.

ACTION IN THE EVENT OF FIRE

18. Should the master RED warning light on the instrument panel illuminate, carry out the following procedure:

- (a) Check the location of the fire on the FIRE panel by means of the illuminated bulb.
- (b) If an engine fire is indicated - retard the throttle lever of the appropriate engine to the cut-off position.
- (c) Switch off the appropriate LP cock.
- (d) Press the illuminated bulb on the FIRE panel.
- (e) If the fire is extinguished, the light on the warning panel will go out.
- (f) If the warning panel light does not go out, lift the guard and select the SECOND SHOT switch on.

NOTE

The toggle switch is used only to give a second shot to the same compartment. If two separate fires occur, pressing the appropriate two warning lights will provide one shot to each compartment.

ABANDONING THE AIRCRAFT

General

19. The aircraft may be abandoned by means of the ejection seats at a minimum airspeed of 80 knots IAS at ground level.

Pilot Preliminaries

20. If it becomes necessary to abandon the aircraft, the following procedure should be adopted:

- (a) Reduce the aircraft speed, if possible.
- (b) Order the navigator to eject or, if intercommunication has failed, operate the NAV BAIL OUT signal switch. Check that the green NAV BAIL OUT light illuminates.

Navigator

21. After receiving the verbal order to eject, or if the BAIL OUT warning light illuminates and the signal horn sounds during intercommunication failure, proceed as follows:

- (a) Acknowledge a verbal order.
- (b) Ensure that the head is correctly located on the headrest, and lean fully back.
- (c) Grasp the overhead firing handle in both hands, ensuring that the palms of the hands face to the rear.
- (d) Maintain the head hard back against the headrest and the arms and hands close to the chest, then pull the firing handle and face screen firmly down over the face. The canopy will open immediately. Seat ejection will take place as soon as the canopy is fully open.

CAUTION

The overhead firing handle must be pulled straight down over the face and not outwards away from the face.

- (e) Should the canopy fail to open, pull the EMERGENCY CANOPY OPEN lever fully to the rear. Replace the hand in its previous position with relation to the face blind as rapidly as possible. Ejection will

Part 3

occur immediately the canopy is in the emergency-open position, which provides very little time to return the hand to the face blind.

NOTE

If, for any reason, the overhead firing handle cannot be operated, pull the alternate firing handle (located between the knees) fully upwards by grasping it with both hands, one hand over the other.

Pilot

22. After the navigator has left the aircraft (indicated by the green NAV BAIL OUT light being extinguished) proceed as follows:

- (a) Ensure that the head is correctly located on the headrest, and lean fully back.
- (b) Grasp the overhead firing handle with both hands ensuring that the palms of the hands face to the rear.
- (c) Maintain the head hard back against the headrest and the arms and hands close to the chest, then pull the firing handle and face screen firmly down over the face. The canopy will open immediately. Seat ejection will take place as soon as the canopy is fully open.

CAUTION

The overhead firing handle must be pulled down straight over the face and not outwards away from the face.

- (e) Should the canopy fail to open, pull the EMERGENCY CANOPY OPEN lever fully to the rear. Replace the hand in its previous position with relation to the face blind as rapidly as possible. Ejection will occur immediately the canopy is in the emergency-open position, which provides very little time to return the hand to the face blind.

NOTE

If, for any reason, the overhead firing handle cannot be operated, pull the alternative firing handle (located between the knees) fully upwards by grasping it with both hands, one hand over the other.

Manual Release

23. If, for any reason, the seat does not eject or, when ejected, the automatic parachute opening gear does not function, provision is made to disconnect the parachute and parachute harness from the seat and enable the occupant to operate the parachute manually as follows:

- (a) Pull on the outer 'D' ring.
- (b) Release the spring catch on the manual override lever on the RH side of the seat pan and move the lever fully to the rear.
- (c) Leave the aircraft or seat.
- (d) Pull the ripcord 'D' ring.

EMERGENCY CANOPY OPENING ON THE GROUND

From Inside the Cockpit

24. In the event that either canopy cannot be opened by the normal method and an emergency exists, the lever marked EMERGENCY CANOPY OPEN, located on the RH side of each cockpit, should be pulled fully back.

From Outside the Cockpit

25. In an emergency, should either crew member be unable to operate his emergency canopy opening handle, provision is made for these handles to be operated from outside the aircraft. A door, located on the RH side of the aircraft below the pilot's cockpit, is marked in red letters EMERGENCY CANOPY OPENING - PUSH TO OPEN - STAND BACK - PULL HANDLE. When the toggle handle attached to the lanyard is pulled, both canopies will be opened by cartridge firing.

WARNING

The canopies will be forced open very rapidly. Therefore all personnel should stand clear of the canopies when the lanyard is pulled.

Part 3

(This Page Intentionally Left Blank)

PART 4
OPERATING DATA
ENGINE LIMITATIONS

Principal Limitations

1. The principal limitations of the Pratt and Whitney J-75 P3 engines are:

Condition	Maximum Observed Turbine Discharge Temp °C	Time Limit (Minutes)
MAXIMUM (With A/B)	610	Fifteen
MILITARY	610	Thirty
NORMAL RATED	540	UNRESTRICTED
CRUISE		
90% NORMAL RATED	540 (max) 500 (normal)	UNRESTRICTED
80% NORMAL RATED	540 (max) 460 (normal)	UNRESTRICTED
70% NORMAL RATED	540 (max) 410 (normal)	UNRESTRICTED
IDLE	340	UNRESTRICTED
STARTING	600	MOMENTARY
TRANSIENT	625	One

Part 4

FLYING LIMITATIONS

2. The following speeds and limitations apply to the ARROW 1 aircraft when fully cleared to its design specification. Until such clearance is obtained, the applicable aircraft design certificate must be studied prior to flight to obtain the overriding limitations to those given below:

(a) Maximum Permissible Speeds

Maximum Design Speed	-	700 Knots EAS or Mach 2.0 (Lowest limit to apply)
----------------------	---	--

Extending or Retracting Landing Gear	-	250 Knots EAS
---	---	---------------

Extending Speed Brakes	-	No Limit
------------------------	---	----------

Parabrake Selection	-	185 Knots EAS (All wheels in ground contact)
---------------------	---	---

Cross-wind component	-	30 Knots
----------------------	---	----------

(b) Crew Ejection

Maximum Speed	-	No structural limit
---------------	---	---------------------

Minimum Speed	-	80 Knots at ground level
---------------	---	--------------------------

(c) Angle of Attack

Maximum Indicated Angle	-	15° (in level flight) 1/2° less for each incremental 'g' imposed
-------------------------	---	--

(d) Weights

Maximum Take-off	-	69,000 lbs. (approx)
------------------	---	----------------------

Maximum Landing	-	65,000 lb. (approx)
-----------------	---	---------------------

(e) 'G' Limits

'G' Limits are shown on Figs 4-1, 4-2 and 4-3

The maximum load factor in a rolling pull-out is two-thirds of the maximum allowable 'g' at that time.




FIG 4-1 FLIGHT ENVELOPE - SEA LEVEL




FIG 4-2 FLIGHT ENVELOPE - 30,000 FT






FIG 4-3 FLIGHT ENVELOPE - 50,000 FT

Part 4






FIG. 4-5 RECOMMENDED APPROACH SPEEDS




FIG. 4-6 RECOMMENDED TOUCH-DOWN SPEEDS

Part 4

AIRCRAFT ARROW 1		TAKE-OFF DISTANCES FEET (AT SEA LEVEL)				ENGINES J 75 - P 3	
A/C WEIGHT AT START OF T.O. (LB)	STANDARD DAY 15°C A/B ON		HOT DAY 38°C A/B ON		STANDARD DAY 15°C NO A/B		
	GROUND RUN	CLEAR 50'	GROUND RUN	CLEAR 50'	GROUND RUN	CLEAR 50'	
50,000	1450	2585	1750	3540	2450	5250	
55,000	1600	2900	2050	4180	2720	6210	
60,000	1780	3260	2250	4775	3100	7480	
65,000	2120	3990	2950	6230	3800	9950	
(70,000)	2630	4965	3530	7800	4450	13210	

DATA AS OF: March 1958 (71/PERF/3)

BASED ON: Estimated Data

BASED ON: J P 4 FUEL

FIGURES HAVE NOT BEEN FLIGHT CHECKED.

INITIAL FLIGHT TESTS INDICATE THAT THE

DISTANCES MAY BE PESSIMISTIC.

FIG 4-7 TAKE-OFF DISTANCE CHART

AIRCRAFT ARROW		CLIMB CHART (At 527 KTS. T.A.S.) NO AFTERBURNER			ENGINES J75 - P 3
MILITARY THRUST - ENGINE START GROSS WT. - 60,000 LB.					
PRESSURE ALT.	TRUE A/S (KNOTS)	APPROPRIATE VALUES			RATE CLIMB
		FROM SEA LEVEL			
		FUEL (LB)	TIME (MIN)	DIST. (N.M.)	
Sea Level	527	0	0	0	10,500
5,000	527	236	0.48	4.3	10,500
10,000	527	471	1.02	8.8	8,850
15,000	527	706	1.63	14.2	7,550
20,000	527	940	2.32	20.4	6,200
25,000	527	1192	3.22	28.0	4,750
30,000	527	1480	4.43	38.7	3,200
35,000	527	1917	6.58	58.0	1,400
Start, Take -off and Accelerate to Climb Allowance		817	2.1	7.9	
DATA AS OF: Oct. 1957 (71/PERF/3) BASED ON: Estimated Data BASED ON: J P 4 Fuel FIGURES HAVE NOT BEEN FLIGHT CHECKED					

FIG. 4-8 CLIMB CHART (NO A/B) - 60,000 LB

Part 4

AIRCRAFT ARROW 1		CLIMB CHART (At 527 KTS. T.A.S.) NO AFTERBURNER			ENGINES J 75 - P 3
MILITARY THRUST - ENGINE START GROSS WT. - 68,765 LB.					
PRESSURE ALT.	TRUE A/S (KNOTS)	APPROXIMATE VALUES			RATE OF CLIMB
		FROM SEA LEVEL			
		FUEL (LB)	TIME (MIN)	DIST (N.M.)	
Sea Level	527	0	0	0	9,100
5,000	527	273	.57	5.0	8,600
10,000	527	546	1.18	10.2	7,450
15,000	527	827	1.88	16.5	6,300
20,000	527	1108	2.74	24.0	5,100
25,000	527	1403	3.81	33.4	3,850
30,000	527	1752	5.29	46.5	2,400
35,000	527	2360	8.29	73.4	500
Start, Take-off and Accelerate to Climb Allowance		946	2.5	9.9	

DATA AS OF: Oct. 1957 (71/PERF/3)

BASED ON: Estimated Data

BASED ON: J P 4 Fuel

FIGURES HAVE NOT BEEN FLIGHT CHECKED

FIG 4-9 CLIMB CHART (NO A/B) - 68,765

AIRCRAFT ARROW 1		CLIMB CHART WITH AFTERBURNERS						ENGINES J 75 - P 3		
MAXIMUM THRUST - ENGINE START GROSS WT. - 60,000 LB.										
PRESSURE ALT.	MACH NO.		APPROXIMATE VALUES						RATE OF CLIMB	
	HIGH SPEED CLIMB	COMBAT CLIMB	FROM SEA LEVEL							
			FUEL (LB)		TIME (MIN)		DISTANCE (N.M.)			
Sea Level	.92	.92	0		0		0		37,000	
5,000	.92	.92	280		.16		1.0		35,000	
10,000	.92	.92	500		.30		2.5		32,000	
15,000	.92	.92	750		.45		4.0		28,000	
20,000	.92	.92	1000		.64		5.5		24,000	
25,000	.92	.92	1200		.86		7.0		20,000	
30,000	.92	.92	1450		1.10		9.5		16,000	
30,000	-	1.5 (accel)	-	3150	-	2.7	-	30.0	-	
35,000	.92	1.5	1700	3470	1.5	3.0	12.5	33.5	11,000	
40,000	.92	1.5	2000	3750	2.0	3.2	17.0	38.0	7,000	
45,000	.92	1.5	2500	4150	3.0	3.8	26.0	46.0	3,000	
47,000	-	1.5	-	4450	-	4.2	-	51.0	-	
50,000	-	1.5	-	4950	-	5.2	-	66.0	-	
51,000	-	1.5	-	5450	-	5.9	-	76.0	-	
Start, Take-off and Accelerate to Climb Allowance			1643		1.39		4.47			
DATA AS OF: Oct. 1057 (71/PERF/3) BASED ON: Estimated Data BASED ON: J P 4 Fuel FIGURES HAVE NOT BEEN FLIGHT CHECKED										

FIG 4-10 CLIMB CHART (WITH A/B) - 60,000 LB

Part 4

AIRCRAFT ARROW 1		GROSS WT. 68,765 LB.		CLIMB CHART WITH AFTERBURNERS				MAX. THRUST		ENGINES J 75 - P 3g119	
PRESSURE ALT.	MACH NO.		APPROXIMATE VALUES						RATE OF CLIMB		
	HIGH SPEED CLIMB	COMBAT CLIMB	FROM SEA LEVEL								
			FUEL (LB)		TIME (MIN)		DISTANCE (N.M.)				
Sea Level	.92	.92	0		0		0		32,000		
5,000	.92	.92	300		.15		1.5		30,500		
10,000	.92	.92	600		.35		2.5		28,000		
15,000	.92	.92	860		.50		4.5		24,800		
20,000	.92	.92	1100		.75		6.5		21,000		
25,000	.92	.92	1400		1.0		8.5		17,400		
30,000	.92	.92	1700		1.3		11.0		13,600		
30,000	-	1.5 (accel)	-	3500	-	3.0	-	31.5	-	NIL	
35,000	.92	1.5	2000	3900	1.75	3.3	15.0	36.0	10,000	9,500	
40,000	.92	1.5	2300	4250	2.4	3.7	21.0	40.5	5,200	4,500	
45,000	.92	1.5	3100	4800	4.0	4.4	35.0	50.0	1,000	2,700	
47,000	-	1.5	-	5100	-	4.9	-	58.0	-	900	
49,000	-	1.5	-	5750	-	5.9	-	72.0	-		
Start-Take-off and Accelerate to Climb Allowance			1879		1.529		5.303				
DATA AS OF: Oct. 1957 (71/PERF/3) BASED ON: Estimated Data BASED ON: J P 4 Fuel											

FIG 4-11 CLIMB CHART (WITH A/B) - 68,765 LB.


Part 4

AIRCRAFT ARROW 1		LANDING DISTANCE FEET (WITH PARABRAKE AND DIVEBRAKES)		ENGINES J 75 - P 3	
GROSS WT. LB.	APPROACH E.A.S. KNOTS	HARD SURFACE RUNWAY - NO WIND - TEMP 15oC - ENGINES IDLE			
		AT SEA LEVEL			
		GROUND RUN		CLEAR 50'	
50,000	180	4,850		7,500	
55,000	180	5,100		7,680	
60,000	180	5,500		8,040	
65,000	187	6,100		8,680	
70,000	194	6,780		9,420	
Data as of: March 1958 (71/PERF/3) Notes: (1) Parabrake and Brakes Effective at 90% of Touch-down Speed.					
Based on: Estimated Data					
Based on: J P 4 Fuel (2) Without Anti-Skid Units					
FIGURES HAVE NOT BEEN FLIGHT CHECKED INITIAL FLIGHT TESTS INDICATE THAT THE DISTANCES MAY BE PESSIMISTIC.					

FIG 4-13 LANDING DISTANCE CHART - WITH PARABRAKE

AIRCRAFT		LANDING DISTANCE		ENGINES	
ARROW 1		FEET		J 75 -P 3	
(NO PARABRAKE-WITH DIVEBRAKES)					
GROSS WT. LB.	APPROACH E.A.S. KNOTS	BRAKING SPEED E.A.S. KNOTS	HARD SURFACE RUNWAY NO WIND - TEMP 15°C ENGINES IDLE		
			AT SEA LEVEL		
			GROUND RUN	CLEAR 50'	
50,000	180	144	7,600	10,250	
55,000	180	144	7,880	10,460	
60,000	180	136	8,530	11,070	
65,000	187	127	10,470	13,050	
70,000	194	120	12,850	15,490	
Data as of:		March 1958 (71/PERF/11)		NOTES: (1) Brakes effective	
Based on:		Estimated Data		at 90% of Touch-	
Based on:		J P 4 Fuel		down Speed except	
				above 55,000 lb.,	
				where Braking is	
				shown above to	
				avoid exceeding	
				the Brake Energy	
				Limitation	
				(2) Without anti-skid	
				units.	
FIGURES HAVE NOT BEEN FLIGHT CHECKED					
INITIAL FLIGHT TESTS INDICATE THAT THE					
DISTANCES MAY BE PESSIMISTIC.					

FIG 4-14 LANDING DISTANCE CHART - WITHOUT PARABRAKES.



CF-105 @ RCAF Station Trenton