


PRICE LIST OF PARTS

FOR THE

Stanley

STEAM CAR



Price List of Parts for STANLEY STEAM CARS

Order for parts must be accompanied by cash. We will not send parts C.O.D. unless we receive sufficient funds to cover transportation charges both ways

Orders for small parts, accompanied by the price and amount required for postage, may be sent by mail.

All prices are subject to change without notice.

In ordering parts for STANLEY CARS, be sure to give the number and name of the part wanted, as these numbers and names are listed in this price list of parts. Also, give the model and number of the car as on the name plate at the rear of the body. For parts of cars more than one year old, it is advisable, when possible, to send the old parts as samples. For parts that connect two other parts, give dimensions. For tubing, give outside diameter and length required. Otherwise, on account of changes which are made from time to time, we would be uncertain as to what was required. Careful attention to these suggestions will assist us materially in filling orders promptly and correctly.

Cable Address: STANLEYCAR, BOSTON

CODE	TELEGRAPH CODE
<i>Rabble</i>	Send by mail
<i>Racer</i>	Send by express
<i>Racking</i>	Ship by freight
<i>Raccoon</i>	Ship by freight, draft with bill of lading
<i>Radical</i>	Ship by next boat
<i>Ragman</i>	Have sent by mail
<i>Rainbow</i>	Have sent by express
<i>Rambler</i>	Have sent by express C.O.D.
<i>Ramrod</i>	Have shipped by freight
<i>Ransack</i>	Have shipped by freight, draft with bill of lading
<i>Rapture</i>	Have shipped by boat

STANLEY MOTOR CARRIAGE CO. - - - Newton, Mass.




Plate 20

See Explanation on Page 36

RUNNING GEAR AND MUD GUARDS

3

	Models B and C Axle Tubing, 1½" diameter		Model EX Axle Tubing, 1¾" diameter		Model F Axle Tubing, 2¼" diameter		Model 60 Axle Tubing, 2" diameter		Model 70 Axle Tubing, 2¼" diameter	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
REAR AXLE FRAME COMPLETE	01	\$25.00	10-01	\$35.00	20-01	\$43.00	60-01	\$46.00	70-01	\$62.00
Rear axle frame, right half	1	10.00	10-1	14.00	20-1	18.00	60-1	22.00	70-1	29.00
" " left	2	10.00	10-2	14.00	20-2	18.00	60-2	22.00	70-2	29.00
" " top yoke	3	1.25	10-3	1.50	20-3	2.00				
" " frame yoke, top screw	3A	---	10-3A	---	20-3A	---	60-3A	.10	70-3A	.15
" " " " nut	3B	---	10-3B	---	20-3B	---	60-3B	.05	70-3B	.05
" " top yoke nut, right	4	.25	10-4	.25	20-4	.25				
" " " left	5	.25	10-5	.25	20-5	.25				
" " bottom yoke	6	1.25	10-6	1.50	20-6	2.00				
" " frame yoke, bottom screw	6A	---	10-6A	---	20-6A	---	60-6A	.10	70-6A	.15
" " " " nut	6B	---	10-6B	---	20-6B	---	60-6B	.05	70-6B	.05
" " truss rod	7	.65	10-7	.65	20-7	.75	60-7	.75	70-7	1.25
" " " nut	8	.25	10-8	.30	20-8	.50				
" " " sleeve	8A	---	10-8A	---	20-8A	---	60-8A	.30	70-8A	.45
" " " " lock nut	8B	---	10-8B	---	20-8B	---	60-8B	.05	70-8B	.05
REAR AXLE COMP., Nos. 1 to 20 inc.	09	60.00	10-09	90.00	20-09	110.00	60-09	100.00	70-09	125.00
Differential	9	22.00	10-9	22.00	20-9	27.00	60-9	25.00	70-9	27.00
" spider	9A	7.20	10-9A	7.00	20-9A	10.00	60-9A	9.00	70-9A	10.00
" pinion	9C	1.00	10-9C	1.00	20-9C	1.00	60-9C	1.00	70-9C	1.00
" stud	9D	.15	10-9D	.15	20-9D	.20	60-9D	.20	70-9D	.20
" rivets	9E	.03	10-9E	.03	20-9E	.03	60-9E	.03	70-9E	.03
One-half driving shaft complete	10	4.50	10-10	9.00	20-10	10.50	60-10	7.00	70-10	8.00
" " only	10A	2.00	10-10A	2.25	20-10A	2.50	60-10A	2.50	70-10A	3.25
Driving shaft bevel gear	10B	2.25	10-10B	3.00	20-10B	4.00	60-10B	4.00	70-10B	4.00
" " pin	10C	.03	10-10C	.03	20-10C	.03	60-10C	.03	70-10C	.03
" " brake drum, cast iron	10D	---	10-10D	3.00	20-10D	3.50				
" " rivets	10E	---	10-10E	.03	20-10E	.03				
Rear axle inside cup	11	.50	10-11	.75	20-11	.75	60-11	.75	70-11	.75
" " outside cup complete	12	.75	10-12	1.25	20-12	1.50	60-12	1.50	70-12	1.50
" " inside cone	13	.35	10-13	1.25	20-13	2.25	60-13	1.50	70-13	2.25
" " outside ball track	14	.35	10-14	1.25	20-14	2.25	60-14	1.50	70-14	2.25
" " " key	14B	---	10-14B	.05	20-14B	.05	60-14B	.05	70-14B	.05
" " wheel lock nut	15	.25	10-15	.15	20-15	.15	60-15	.15	70-15	.15
" " inside ball	See Ball list, page 15									
" " outside ball										
" " ball retainer, thin	18A	.05	10-18A	.05	20-18A	.05	60-18A	.05	70-18A	.05
" " " thick	18B	.05	10-18B	.05	20-18B	.05	60-18B	.05	70-18B	.05
" " felt washer, small	19A	---	10-19A	.03	20-19A	.03	60-19A	.03	70-19A	.03
" " " large	19B	.03	10-19B	.03	20-19B	.03	60-19B	.03	70-19B	.03
" " leather washer	20	.03	10-20	.03	20-20	.03	60-20	.03	70-20	.03
Rear axle brace rod	21	.75	10-21	.75	20-21	1.25	60-21	1.00	70-21	1.25
" " " lock nut, rear	21C	.05	10-21C	.05	20-21C	.05	60-21C	.05	70-21C	.05
" " " " forward	21D	.05	10-21D	.05	20-21D	.05	60-21D	.05	70-21D	.05
Perch brace rod	22	.50	10-22	.75	20-22	1.00	60-22	.75	70-22	1.00
" " " right thread lock nut	22C	---	10-22C	---	20-22C	---	60-22C	.05	70-22C	.05
" " " left	22D	---	10-22D	---	20-22D	---	60-22D	.05	70-22D	.05

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model




Plate 21

See Explanation on Page 36

RUNNING GEAR AND MUD GUARDS

5

	Models B and C Axle Tubing, 1 1/2" diameter		Model EX Axle Tubing, 1 3/4" diameter		Model F Axle Tubing, 2 1/4" diameter		Model 60 Axle Tubing, 2" diameter		Model 70 Axle Tubing, 2 1/4" diameter	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
Right PERCH.....	23R	\$6.00	10-23R	\$6.00	20-23R	\$8.00	60-23R	\$6.00	70-23R	\$8.00
Left ".....	23L	6.00	10-23L	6.00	20-23L	8.00	60-23L	6.00	70-23L	8.00
Perch end.....	23T	.75	10-23T	.75	20-23T	1.00	60-23T	.75	70-23T	1.00
" wood.....	23D	2.00	10-23D	2.00	20-23D	2.50	60-23D	2.00	70-23D	2.50
" chafing clip.....	23F	.15	10-23F	.15	20-23F	.15	60-23F	.15	70-23F	.15
" bolt.....	24	.50	10-24	.50	20-24	.60	60-24	.50	70-24	.60
REAR WHEEL COMP., without tire.....	025	7.00	10-025	12.00	20-025	15.00	60-025	15.00	70-025	20.00
Rear wire wheel hub.....	25	1.50								
" " rim.....	26	2.75								
Wire spoke with nipple.....	27	.04								
Rear wheel BRAKE DRUM (cast iron).....	25A	---	10-25A	3.00	20-25A	3.75				
" " outside flange.....	25B	---	10-25B	1.75	20-25B	2.25	60-25B	1.75	70-25B	2.50
" " thimble.....	25C	---	10-25C	.15	20-25C	.20	60-25C	.15	70-25C	.20
" " hub bolt.....	25D	---	10-25D	.10	20-25D	.10	60-25D	.10	70-25D	.10
" " inside flange.....	25E	---	10-25E	---	20-25E	---	60-25E	1.75	70-25E	2.50
" " double brake drum (pr's'd steel).....	25F	---	10-25F	---	20-25F	---	60-25F	3.00	70-25F	4.00
" " " oil plug.....	25P	---	10-25P	---	20-25P	---	60-25P	.05	70-25P	.05
FRONT AXLE COMPLETE, including Nos. 28, 29, 30, 31, 32, 34, 220.....	028	26.00	10-028	32.00	20-028	40.00	60-028	40.00	70-028	52.00
Front axle frame.....	28	12.00	10-28	15.00	20-28	18.00	60-28	18.00	70-28	23.00
" spindle.....	29	2.00	10-29	2.00	20-29	3.00	60-29 & 30	3.50		
" " lever.....	30	1.50	10-30	1.50	20-30	2.25				
" " taper pin.....	31	.05	10-31	.05	20-31	.05	60-31	.05		
Front axle spindle, right.....	29AR	---	10-29AR	---	20-29AR	---	62-29AR	2.75	70-29AR	3.25
" " left.....	29AL	---	10-29AL	---	20-29AL	---	62-29AL	2.75	70-29AL	3.25
" " lever right.....	29BR	---	10-29BR	---	20-29BR	---	62-29BR	1.75	70-29BR	2.25
" " " left.....	29BL	---	10-29BL	---	20-29BL	---	62-29BL	1.75	70-29BL	2.25
" " " nut.....	29C	---	10-29C	---	20-29C	---	62-29C	.10	70-29C	.10
" " " washer.....	29D	---	10-29D	---	20-29D	---	62-29D	.05	70-29D	.05
" " " bushing.....	29E	---	10-29E	---	20-29E	---	62-29E	.50	70-29E	.50
" " " thrust washer.....	29W	---	10-29W	---	20-29W	---	62-29W	.05	70-29W	.05
" " " stud.....	30A	---	10-30A	---	20-30A	---	60-30A	.50	70-30A	.50
" " " top cone.....	30B	---	10-30B	---	20-30B	---	60-30B	.40	70-30B	.40
" " " " knurled w'h'r.....	30C	---	10-30C	---	20-30C	---	60-30C	.25	70-30C	.25
" " " " cap lock nut.....	30D	---	10-30D	---	20-30D	---	60-30D	.35	70-30D	.35
" " " bearing felt washer.....	30E	---	10-30E	---	20-30E	---	60-30E	.03	70-30E	.03
" " " bottom cone.....	30F	---	10-30F	---	20-30F	---	60-30F	.40	70-30F	.40
" " " " knurled w'h'r.....	30G	---	10-30G	---	20-30G	---	60-30G	.25	70-30G	.25
" " " " cap lock nut.....	30H	---	10-30H	---	20-30H	---	60-30H	.35	70-30H	.35
Spindle lever connecting rod.....	32	3.50	10-32	4.00	20-32	5.00	60-32	4.50	70-32	5.00
" " end lip.....	32D	.35	10-32D	.35	20-32D	.50	60-32D	.50	70-32D	.50
" " " lug bushing.....	32E	---	10-32E	---	20-32E	---	62-32E	.35	70-32E	.35
" " " castle nut.....	32F	---	10-32F	---	20-32F	---	60-32F	.10	70-32F	.10
Steering gear screw, short.....	220A	.10	10-220A	.10	20-220A	---	60-220A	.10		
" " long.....	220B	.10	10-220B	.10	20-220B	.10	60-220B	.10	70-220B	.10
" " nut.....	220C	.02	10-220C	.02	20-220C	.02				
" " castle nut.....	220C	---	10-220C	---	20-220C	---	60-220C	.02	70-220C	.02

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model

RUNNING GEAR AND MUD GUARDS

	Models B and C Axle Tubing, 1 1/2" diameter		Model EX Axle Tubing, 1 3/4" diameter		Model F Axle Tubing, 2 1/4" diameter		Model 60 Axle Tubing, 2" diameter		Model 70 Axle Tubing, 2 1/4" diameter	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
Front wheel cup	33	\$0.35	10-33	\$0.75	20-33	\$0.75	60-33	\$0.75	70-33	\$0.75
" " inside cone	34	.35	10-34	.75	20-34	1.00	60-34	.75	70-34	1.00
" " outside cone	35	.35	10-35	.75	20-35	1.00	60-35	.75	70-35	1.00
Front wheel knurled washer	36	.10	10-36	.20	20-36	.20	60-36	.20	70-36	.25
" " lock nut	37	.10	10-37	.15	20-37	.20	60-37	.15	70-37	.20
FRONT WHEEL COMP., without tire	038wire	7.00	10-038	11.00	20-038	12.50	60-038	12.50	70-038	16.00
Front wire wheel hub	38	1.50								
" wheel inside flange	38A	---	10-38A	1.75	20-38A	2.25	60-38A	1.75	70-38A	2.50
" " outside	38B	---	10-38B	1.75	20-38B	2.25	60-38B	1.75	70-38B	2.50
" " thimble	38C	---	10-38C	.15	20-38C	.20	60-38C	.15	70-38C	.20
" " bolt	38D	---	10-38D	.10	20-38D	.10	60-38D	.10	70-38D	.10
Wheel dust nut	39	.35	10-39	1.00	20-39	1.25	60-39	1.00	70-39	1.25
Front wheel ball retainer	40	.05	10-40	.05	20-40	.05	60-40	.05	70-40	.05
" " felt washer	41	.03	10-41	.03	20-41	.03	60-41	.03	70-41	.03
" " inside dust washer	42	.10	10-42	.05	20-42	.05	60-42	.05	70-42	.05
" " ball } See Ball list, page 15										
" " }										
Brake lever	43A	1.15	10-43A	1.15	20-43A	1.50				
" " screw	43B	---	10-43B	.03	20-43B	.03				
" " washer	43C	---	10-43C	.03	20-43C	.03				
" " ferrule	43D	---	10-43D	.03	20-43D	.03				
External hub brake lever	43E	---	10-43E	---	20-43E	---	60-43E	.60	70-43E	.60
" " fulcrum shaft	43F	---	10-43F	---	20-43F	---	60-43F	.50	70-43F	.50
" " " " nut	43G	---	10-43G	---	20-43G	---	60-43G	.05	70-43G	.05
Brake fulcrum	44	.85	10-44	.85	20-44	1.00				
External hub brake fulcrum	44E	---	10-44E	---	20-44E	---	60-44E	1.00	70-44E	1.00
" " " " key	44F	---	10-44F	---	20-44F	---	60-44F	.05	70-44F	.05
" " " " band inside link and bushing, right	44GR	---	10-44GR	---	20-44GR	---	60-44GR	.75	70-44GR	.75
External hub brake band inside link and bushing, left	44GL	---	10-44GL	---	20-44GL	---	60-44GL	.75	70-44GL	.75
External hub brake band outside link	44H	---	10-44H	---	20-44H	---	60-44H	.25	70-44H	.25
" " " " link screws	44J	---	10-44J	---	20-44J	---	60-44J	.05	70-44J	.05
" " " " " " lock nut	44K	---	10-44K	---	20-44K	---	60-44K	.03	70-44K	.03
Brake fulcrum screw	45	.05	10-45	.05	20-45	.05	60-45	---	70-45	---
External hub brake fulcrum screws	45B	---	10-45B	---	20-45B	---	60-45B	.05	70-45B	.05
" " " " " " lock nut	45C	---	10-45C	---	20-45C	---	60-45C	.03	70-45C	.03
BRAKE BAND	46	2.50	10-46	2.50	20-46	2.75				
External hub brake band	46	---	10-46	---	20-46	---	60-46	3.25	70-46	3.75
Brake band lining	46B	.75	10-46B	.75	20-46B	.75				
External hub brake band lining	46B	---	10-46B	---	20-46B	---	60-46B	.75	70-46B	1.00
Brake band rivets, per doz.	46C	.05	10-46C	.05	20-46C	.05	60-46C	.05	70-46C	.05
" " log	46D	.30	10-46D	.30	20-46D	.30	60-46D	.30	70-46D	.30
" " adjusting screw	46E	.30	10-46E	.30	20-46E	.30	60-46E	.30	70-46E	.30
" " " " nuts	46F	---	10-46F	.05	20-46F	.05	60-46F	.05	70-46F	.05

When writing us, always give model and NUMBER of car

RUNNING GEAR AND MUD GUARDS

7

	Models B and C Axle Tubing, 1½" diameter		Model EX Axle Tubing, 1¾" diameter		Model F Axle Tubing, 2¼" diameter		Model 60 Axle Tubing, 2" diameter		Model 70 Axle Tubing, 2¾" diameter	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
External hub brake band guide pin.....	46Q	----	10-46Q	----	20-46Q	----	60-46Q	\$0.05	70-46Q	\$0.05
" " " " " " " " nuts	46R	----	10-46R	----	20-46R	----	60-46R	.02	70-46R	.02
" " " " " " " " spring	46S	----	10-46S	----	20-46S	----	60-46S	.10	70-46S	.10
" " " " " " " " bracket	46T	----	10-46T	----	20-46T	----	60-46T	.25	70-46T	.25
" " " " " " " " nuts	46U	----	10-46U	----	20-46U	----	60-46U	.03	70-46U	.03
External hub brake band guide pin bracket washer	46W	----	10-46W	----	20-46W	----	60-46W	.01	70-46W	.01
SET ALUMINUM MUD GUARDS comp.	47	\$12.00								
Right front aluminum mud guard.....	47A	3.00								
Left " " " " " " " "	47B	3.00								
Rear aluminum mud guard.....	47C	3.00								
Mud guard nut.....	48	.05								
Front top mud guard nut nicked	49	.05								
SET MUD GUARDS AND RUNNING BOARD complete less curtains.....	47	----	10-47	\$37.00	20-47	\$40.00	60-47	37.00	70-47	40.00
Right front fender.....	47A	----	10-47A	5.00	20-47A	5.00	60-47A	5.00	70-47A	5.00
Left " " " " " " " "	47B	----	10-47B	5.00	20-47B	5.00	60-47B	5.00	70-47B	5.00
Right rear fender.....	47C-R	----	10-47C-R	5.00	20-47C-R	5.00	60-47C-R	5.00	70-47C-R	5.00
Left " " " " " " " "	47C-L	----	10-47C-L	5.00	20-47C-L	5.00	60-47C-L	5.00	70-47C-L	5.00
Front fender bottom bolt and nut.....	47D	----	10-47D	.05	20-47D	----	60-47D	.05	70-47D	.05
" " " " " " " " screws	47D	----	10-47D	----	20-47D	.02				
Rear " " " " " " " " bolt and nut	47E	----	10-47E	.02	20-47E	.02				
" " " " " " " " strap	47F	----	10-47F	.15	20-47F	.15	60-47E	.05	70-47E	.05
Fender top screw and nut.....	47G	----	10-47G	.10	20-47G	.10	60-47G	.05	70-47G	.05
Front fender apron screws and washers.....	47H	----	10-47H	----	20-47H	----	60-47H	.01	70-47H	.01
" " " " " " " " right fender hanger.....	48A	----	10-48A	1.25	20-48A	1.25	60-48A	1.25	70-48A	1.25
" " " " " " " " left " " " "	48B	----	10-48B	1.25	20-48B	1.25	60-48B	1.25	70-48B	1.25
Rear right " " " " " " " "	48C	----	10-48C	1.25	20-48C	1.25	60-48C	1.25	70-48C	1.25
" " " " " " " " left " " " "	48D	----	10-48D	1.25	20-48D	1.25	60-48D	1.25	70-48D	1.25
Running board hanger.....	48E	----	10-48E	1.25	20-48E	1.25	60-48E	1.25	70-48E	1.25
Running board.....	49A	----	10-49A	1.00	20-49A	1.00	60-49A	1.00	70-49A	1.00
" " " " " " " " rubber mat.....	49B	----	10-49B	1.25	20-49B	1.50	60-49B	1.25	70-49B	1.50
Rubber mat tacks, per doz.....	49C	----	10-49C	.05	20-49C	.05	60-49C	.05	70-49C	.05
Running board bolt and nut.....	49D	----	10-49D	.05	20-49D	.05	60-49D	.05	70-49D	.05
" " " " " " " " U bolt.....	49E	----	10-49E	.05	20-49E	.05	60-49E	.05	70-49E	.05
" " " " " " " " nut.....	49F	----	10-49F	.01	20-49F	.01	60-49F	.01	70-49F	.01
Rear fender hanger bolt and nut.....	49G	----	10-49G	.05	20-49G	.05	60-49G	.05	70-49G	.05
Mud guard hanger coach screw.....	49H	----	10-49H	.03	20-49H	.03	60-49H	.03	70-49H	.03
Running board hanger coach screw.....	49I	----	10-49I	.03	20-49I	.03	60-49I	.03	70-49I	.03
" " " " " " " " mud curtain, each.....	49M	----	10-49M	----	20-49M	----	60-49M	2.50	70-49M	3.00

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model

RUNNING GEAR AND MUD GUARDS

	Models B and C Axle Tubing, 1 3/4" diameter		Model EX Axle Tubing, 1 3/4" diameter		Model F Axle Tubing, 2 1/4" diameter		Model 60 Axle Tubing, 2" diameter		Model 70 Axle Tubing, 2 1/4" diameter	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
SPRING	50	---	10-50	\$5.00	20-50	\$7.00	60-50	---	70-50	\$7.00
" 3-leaf	50	\$3.00								
" 4- "	51	3.50								
" 5- "	52	4.00								
Rubber bumper	50R	---	10-50R	.45	20-50R	.45	60-50R	.45	70-50R	.45
" strap	50S	---	10-50S	.15	20-50S	.15	60-50S	.15		
Spring clip with nuts	53	.10	10-53	.10	20-53	.15	60-53	.10	70-53	.15
Special heavy spring clip for headlight bracket	53F	---	10-53F	---	20-53F	.20	60-53F	.20	70-53F	.20
Spring clip yoke	54	.20								
Spring clip bar	54B	.10	10-54B	.10	20-54B	.10	60-54B	.10	70-54B	.10
Special heavy spring clip bar for headlight bracket	54F	---	10-54F	---	20-54F	1.00	60-54F	---	70-54F	.10
Right front body spring hanger	55A	.75	10-55A	.75	20-55A	.50	60-55A	.50	70-55A	.50
Left " " "	55B	.75	10-55B	.75	20-55B	.50	60-55B	.50	70-55B	.50
Rear right " " "	55CR	.75	10-55CR	.75	20-55CR	.50	60-55CR	.50	70-55CR	.50
" left " " "	55CL	.75	10-55CL	.75	20-55CL	.50	60-55CL	.50	70-55CL	.50
Body hanger bolt with nut	56	.05	10-56	.05	20-56	.05	60-56	.05	70-56	.05
" " screw	57	.03	10-57	.03	20-57	.03	60-57	.03	70-57	.03
Front step	58	.75								
Tire (See Tire price list)	59	---								
Rear axle yoke shim	60	.01	10-60	.01	20-60	.01	60-60	.01	70-60	.01
Hub brake bracket	61	---	10-61	1.50	20-61	2.00				
Rear axle oil cup	62	.15	10-62	.15	20-62	.15	60-62	.15	70-62	.15
Hub brake bracket nut	63	---	10-63	.05	20-63	.05				
" " band stop	64	---	10-64	.30	20-64	.30				
Internal hub brake band stop, bolt	64A	---	10-64A	---	20-64A	---	60-64A	.25	70-64A	.25
" " " " nut	64B	---	10-64B	---	20-64B	---	60-64B	.05	70-64B	.05
" " " " washer	64C	---	10-64C	---	20-64C	---	60-64C	.03	70-64C	.03
Hub brake expanding ring	65	---	10-65	5.00	20-65	6.00				
INTERNAL HUB BRAKE expanding ring, lined	65	---	10-65	---	20-65	---	60-65	5.50	70-65	7.50
Internal hub brake expanding ring, lining	65B	---	10-65B	---	20-65B	---	60-65B	.75	70-65B	1.00
" " lever	66	---	10-66	.60	20-66	.60	60-66	.60	70-66	.60
" " cam bolt	67	---	10-67	1.00	20-67	1.00	60-67	1.00	70-67	1.00
" " " " collar bushing	67B	---	10-67B	---	20-67B	---	60-67B	.50	70-67B	.50
" " " " washer	68	---	10-68	.10	20-68	.10				
" " " " nut	69	---	10-69	.05	20-69	.05	60-69	.05	70-69	.05
" " " ring spring	70	---	10-70	.15	20-70	.15	60-70	.15	70-70	.15
Winkley oil cup	71A	---	10-71A	.15	20-71A	.15	60-71A	.15	70-71A	.15
Mite grease cup	71C	---	10-71C	---	20-71C	---	60-71C	.25	70-71C	.25
Hub drum covers	72	---	10-72	1.50	20-72	2.00	60-72	.75	70-72	.75
Gear case thrust washer	73A	---	10-73A	---	20-73A	---	60-73A	.10	70-73A	.15
" " " " set screw	73B	---	10-73B	---	20-73B	---	60-73B	.03	70-73B	.03
" " " " " lock nut	73C	---	10-73C	---	20-73C	---	60-73C	.02	70-73C	.02

When writing us, always give model and NUMBER of car

ENGINE PARTS

9

	No. 1 Engine 2 1/2" diameter 3 1/2" stroke		No. 2 Engine 3" diameter 4" stroke		No. 3 Engine 3 1/2" diameter 5" stroke		No. 6 Engine 3 1/2" diameter 4 1/4" stroke		No. 7 Engine 4" diameter 5" stroke	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
ENGINE COMPLETE	100	\$90.00	10-100	\$110.00	20-100	\$180.00	60-100	\$180.00	70-100	\$250.00
Cylinders with heads, steam chest cover, pistons, piston rods, slide valves and stems, stuffing boxes, glands and nuts complete assembled	0101	33.00	10-0101	47.00	20-0101	63.50	60-0101	55.00	70-0101	78.50
ENGINE CYLINDER	101	15.00	10-101	25.00	20-101	35.00	60-101	25.00	70-101	35.00
" " top head	102	.75	10-102	.75	20-102	1.00	60-102	1.00	70-102	1.25
" " bottom head	103	1.00	10-103	1.00	20-103	1.25	60-103	1.25	70-103	1.75
Steam chest cover	104	.75	10-104	.75	20-104	1.00	60-104	1.00	70-104	1.25
Engine frame	105	7.50	10-105	10.00	20-105	15.00	60-105	15.00	70-105	20.00
" " adjusting screw	105E	.10	10-105E	.10	20-105E	.10	60-105E	.10	70-105E	.15
" " " nut	105G	.03	10-105G	.03	20-105G	.03	60-105G	.03	70-105G	.03
" " rod diaphragm bushing nut	105K	---	10-105K	---	20-105K	---	60-105K	.10	70-105K	.15
Slide valve stem guide	106A	.75	10-106A	.75	20-106A	1.50	60-106A	2.00	70-106A	2.50
" " " screw	106B	.10	10-106B	.15	20-106B	.15	60-106B	.15	70-106B	.15
" " " hex. nut	106D	.05	10-106D	.05	20-106D	.05	60-106D	.05	70-106D	.05
" " " diaphragm nut	106E	---	10-106E	---	20-106E	---	60-106E	.10	70-106E	.15
Crosshead guides	107	.40	10-107	.50	20-107	.75	60-107	.75	70-107	1.00
" " screws	107B	.05	10-107B	.05	20-107B	.05	60-107B	.05	70-107B	.05
" " screw nut	107C	.02	10-107C	.02	20-107C	.03	60-107C	.03	70-107C	.03
Engine reverse rocker	108	.75	10-108	.75	20-108	1.50	---	---	---	---
Reverse shaft adjusting screw	108B	---	10-108B	---	20-108B	.05	---	---	---	---
" " rocker screw " nut	108C	---	10-108C	---	20-108C	.02	---	---	---	---
" " shaft inside nut	109	.10	10-109	.10	---	---	---	---	---	---
" " outside nut	109A	---	10-109A	---	20-109A	.05	---	---	---	---
Pump rocker stud	110	.35	10-110	.35	20-110	.85	---	---	---	---
ENGINE MAIN BEARING CLAMP	111	1.25	10-111	4.00	20-111	7.00	60-111	7.00	70-111	9.00
" " shim	111S	---	10-111S	.01	20-111S	.01	60-111S	.01	70-111S	.01
Main bearing cup	112	.75	---	---	---	---	---	---	---	---
Frame extension rod	113	.60	---	---	---	---	---	---	---	---
Extension frame nut, round	113B	---	10-113	.15	20-113	.15	---	---	---	---
" " acorn	113B	---	10-113B	.25	20-113B	---	60-113B	.35	70-113B	.35
Frame nut, hex.	114	.05	10-114	.06	20-114	.10	60-114	.10	70-114	.10
" " stop	114S	---	10-114S	.05	20-114S	.05	60-114S	.05	70-114S	.05
" " washer	114W	---	10-114W	.03	20-114W	.03	60-114W	.03	70-114W	.03
Brass hanger strap	115	2.00	10-115	2.00	20-115	3.50	---	---	---	---
ECCENTRIC ROD	116	1.50	10-116	1.75	20-116	3.00	60-116	3.00	70-116	3.50
" " shim	116S	.01	10-116S	.01	20-116S	.01	60-116S	.01	70-116S	.01
" " strap screw	117A	.05	10-117A	.06	20-117A	.10	60-117A	.10	70-117A	.15
" " " lock nut	117B	---	10-117B	---	20-117B	---	60-117B	.03	70-117B	.03
" " pin	118A	.07	10-118A	.07	20-118A	.10	60-118A	.10	70-118A	.10
" " nut	118B	.03	10-118B	.03	20-118B	.03	60-118B	.03	70-118B	.03
SLIDE VALVE	119	1.00	10-119	1.00	20-119	1.50	60-119	1.00	70-119	1.50
" " stem	120	.25	10-120	.25	20-120	.25	60-120	.25	70-120	.25
" " lock nut	121	.05	10-121	.05	20-121	.05	60-121	.05	70-121	.05
Slide valve stem stuffing box	122	.50	10-122	.50	20-122	.50	60-122	.50	70-122	.50
" " bushing	122B	---	10-122B	---	20-122B	---	60-122B	.05	70-122B	.05

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model




Plate 22

ENGINE PARTS

11

	No. 1 Engine 2 1/2" diameter 3 1/2" stroke	No. 2 Engine 3" diameter 4" stroke	No. 3 Engine 3 3/4" diameter 5" stroke	No. 6 Engine 3 1/2" diameter 4 1/2" stroke	No. 7 Engine 4" diameter 5" stroke
Slide valve stem stuffing box gland	No. 123 Price \$0.05	No. 10-123 Price \$0.05	No. 20-123 Price \$0.05	No. 60-123 Price \$0.05	No. 70-123 Price \$0.05
" " " jaw " nut	124 .20	10-124 .20	20-124 .30	60-124 .30	70-124 .35
" " " " " "	125 .50	10-125 .50	20-125 .60	60-125 .75	70-125 1.00
Link block pin	126A .07	10-126A .07	20-126A .10	60-126A .10	70-126A .10
" " " " " "	126B .03	10-126B .03	20-126B .03	60-126B .03	70-126B .03
ENGINE LINK	127 1.50	10-127 1.50	20-127 1.50	60-127 1.50	70-127 2.00
Link pin	128 .05	10-128 .05	20-128 .05	60-128 .05	70-128 .05
" block	129 .25	10-129 .25	20-129 .40	60-129 .40	70-129 .50
" hanger rod	130 .30	10-130 .30	20-130 .45	60-130 .75	70-130 .75
" " " nut	130B ---	10-130B ---	20-130B ---	60-130B .05	70-130B .05
" " " pin	131A .10	10-131A .10	20-131A .10	60-131A .10	70-131A .10
" " " nut	131B ---	10-131B ---	20-131B ---	60-131B .05	70-131B .05
ENGINE PISTON with rings	132 2.00	10-132 2.50	20-132 4.00	60-132 3.00	70-132 5.00
" " " top head	132A .60	10-132A .75	20-132A 1.20	60-132A .80	70-132A 1.50
" " " bottom head	132B .60	10-132B .75	20-132B 1.20	60-132B .80	70-132B 1.50
" " " ring, each	132C .40	10-132C .50	20-132C .80	60-132C .70	70-132C 1.00
Piston rod stuffing box gland	133 .15	10-133 .15	20-133 .15	60-133 .15	70-133 .15
" " " " nut	134 .25	10-134 .25	20-134 .35	60-134 .35	70-134 .50
" " " " spring	135 .01	10-135 .01	20-135 .01	60-135 .01	70-135 .01
WRIST PIN, right long	136 .10	10-136 .25	20-136 .25	60-136 .60	70-136 .70
" " " adjusting cone	136B ---	10-136B ---	20-136B ---	60-136B .25	70-136B .25
" " " lock nut	136C ---	10-136C .05	20-136C .05	60-136C .05	70-136C .05
" " " adjusting shims	136S ---	10-136S ---	20-136S ---	60-136S .01	70-136S .01
" " " left short	137 .10	10-137 .10	20-137 .15	60-137 .25	70-137 .30
" " " nut	138 .05	10-138 .05	20-138 .05	60-138 .05	70-138 .05
CROSSHEAD and piston rod	139 1.50	10-139 2.50	20-139 3.00	60-139 4.00	70-139 7.00
CONNECTING ROD complete, right	140R 2.00	10-140R 2.50	20-140R 4.00	60-140R 4.00	70-140R 8.00
" " " left	140L 2.00	10-140L 2.50	20-140L 4.00	60-140L 4.00	70-140L 8.00
" " " screws	140B ---	10-140B .10	20-140B .10	60-140B .10	70-140B .10
Crank shaft complete assembled	0141 11.00	10-0141 17.00	20-0141 26.00	60-0141 27.50	70-0141 40.50
" " " only	141 .85	10-141 1.25	20-141 2.00	60-141 2.00	70-141 3.25
" " " key	141A .10	10-141A .10	20-141A .10	60-141A .10	70-141A .10
ENGINE GEAR	142 ---	10-142 5.50	20-142 8.50	60-142 7.50	70-142 11.50
" " " 32-teeth, 8-pitch, 3/4" face	142A 3.00	10-142A ---	20-142A ---	60-142A ---	70-142A ---
" " " 40- " 8- " 3/4" "	--- ---	10- --- 5.50	20- --- 8.50	60- --- 7.50	70- --- 11.50
" " " 48- " 8- " 3/4" "	--- ---	10- --- 5.50	20- --- 8.50	60- --- 7.50	70- --- 11.50
" " " 42- " 7- " 3/4" "	--- ---	10- --- 5.50	20- --- 8.50	60- --- 7.50	70- --- 11.50
" " " 43- " 6- " 3/4" "	--- ---	10- --- 5.50	20- --- 8.50	60- --- 7.50	70- --- 11.50
" " " 40- " 6- " 3/4" "	--- ---	10- --- 5.50	20- --- 8.50	60- --- 7.50	70- --- 11.50
" " " 48- " 6- " 1" "	--- ---	10- --- 5.50	20- --- 8.50	60- --- 7.50	70- --- 11.50
Eccentric	143 .40	10-143 .60	20-143 1.00	60-143 1.25	70-143 1.75
Engine crank	144 1.25	10-144 1.75	20-144 3.00	60-144 2.50	70-144 3.50
Crank pin ball track	144B ---	10-144B .50	20-144B .75	60-144B .75	70-144B .75
" " " lock nut	144C ---	10-144C .15	20-144C .15	60-144C .15	70-144C .15
ENGINE MAIN BEAR'G BALL TRACK	145 .50	10-145 1.50	20-145 2.25	60-145 2.25	70-145 4.00
Crank pin inside cone	146 .35	10-146 ---	20-146 ---	60-146 1.00	70-146 1.25
" " " shims	146B ---	10-146B ---	20-146B ---	60-146B .01	70-146B .01
" " " outside adjusting cone	147 .35	10-147 ---	20-147 ---	60-147 1.25	70-147 1.50

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model




Plate 23

ENGINE PARTS

13

	No. 1 Engine 2 1/4" diameter 3 1/2" stroke	No. 2 Engine 3" diameter 4" stroke	No. 3 Engine 3 1/2" diameter 5" stroke	No. 6 Engine 3 1/2" diameter 4 1/4" stroke	No. 7 Engine 4" diameter 5" stroke
Crank pin knurled washer	No. 148 Price \$0.15	No. 149 Price 1.50	No. 150 Price 1.50	No. 151 Price 1.50	No. 152 Price 1.50
" " adjusting cone lock nut	149 .15	10-149 .15	20-149 .15	60-149 .15	70-149 .15
Engine pump rocker	151 1.50	10-151 \$1.50	20-151 \$1.50		
" " " inside link	152 .25	10-152 .25	20-152 .40		
" " " outside	153 .25	10-153 .25	20-153 .40		
" " " link, screw and nut	154 .05	10-154 .05	20-154 .12		
" " " inside cone	146 .35	10-146 .35	20-146 .35		
" " " outside adjusting cone	147 .35	10-147 .35	20-147 .35		
" " " knurled washer	148 .15	10-148 .15	20-148 .15		
" " " adjusting cone lock nut	149 .15	10-149 .15	20-149 .15		
EXHAUST FITTING	155 1.00	10-155 1.00	20-155 1.75	60-155 1.75	70-155 2.25
" " " screw	156 .05	10-156 .05	20-156 .05	60-156 .05	70-156 .05
" " " gasket	157 .05	10-157 .05	20-157 .05	60-157 .10	70-157 .15
" " " nipple	158 .25	10-158 .25	20-158 .25	60-158 .25	70-158 .35
" " " elbow	159 .25	10-159 .25	20-159 .25	60-159 .25	70-159 .35
Exhaust hose nipple	161 .25	10-161 .25	20-161 .25	60-161 .25	70-161 .35
Steam ball joint	162 1.50	10-162 1.50	20-162 1.50		
" " " elbow	163 .10	10-163 .10	20-163 .15		
" " " chest nipple	164 .25	10-164 .25	20-164 .30		
Engine cylinder stud for hanger strap	164A ---	10-164A ---	20-164A ---	60-164A .50	70-164A .50
" " " cup nut	164B ---	10-164B ---	20-164B ---	60-164B .10	70-164B .10
" " " castle nut	164C ---	10-164C ---	20-164C ---	60-164C .20	70-164C .20
" " " hanger strap	165 .50	10-165 .50	20-165 .50	60-165 .50	70-165 .50
ENGINE CYLINDER CASE complete	167 3.00	10-167 { 3.60 8.00	20-167 { 6.00 10.00	60-167 10.00	70-167 11.00
" " " " extension screw	167C ---	10-167C .01	20-167C .01	60-167C .01	70-167C .01
" " " " nut	167D ---	10-167D .01	20-167D .01	60-167D .01	70-167D .01
" " " " screw and nut	168 .02	10-168 .02	20-168 .02	60-168 .02	70-168 .02
" " " center case complete	169 6.00	10-169 7.20	20-169 12.00	60-169 3.00	70-169 3.00
" " " " blocks, plain	169B .05	10-169B .05	20-169B .05	60-169B .05	70-169B .05
" " " " threaded	169C .05	10-169C .05	20-169C .05	60-169C .05	70-169C .05
" " " " knob	169E .10	10-169E .10	20-169E .10		
Engine center case screw	171 .03	10-171 .03	20-171 .03	60-171 .03	70-171 .03
" " " rear case	172 1.50	10-172 2.00	20-172 3.50		
" " " stuffing box case complete	172 ---	10-172 ---	20-172 ---	60-172 1.30	70-172 1.30
Front gear case sheet copper	173 1.50	10-173 2.00	20-173 3.50		
Rear " " " "	174 1.75	10-174 2.00	20-174 2.50		
Front " " " cast aluminum	173 ---	10-173 { 20.00	20-173 ---	60-173 { 20.00	70-173 { 30.00
Rear " " " " "	174 ---	10-174 { 20.00	20-174 ---	60-174 { 20.00	70-174 { 30.00
" " " " drain plug	174P ---	10-174P ---	20-174P ---	60-174P .10	70-174P .10
Gear case screw	175 .05	10-175 .05	20-175 .05	60-175 ---	70-175 ---
" " " gasket	176 ---	10-176 ---	20-176 ---	60-176 .03	70-176 .03
" " " dog	176 .02	10-176 .02	20-176 .02		
Hair felt	177 .25	10-177 .35	20-177 .40	60-177 .40	70-177 .50
Steam chest drip elbow	178 .30	10-178 .30	20-178 .30	60-178 .30	70-178 .30
" " " valve with extension	179 1.90	10-179 1.90	20-179 1.90	60-179 1.90	70-179 1.90
Reverse lever shaft	182A ---	10-182A 2.25	20-182A 2.25	60-182A 2.25	70-182A 3.00
" " " " nut	182B ---	10-182B .05	20-182B .05	60-182B .05	70-182B .05

*With no extension.

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model




Plate 24

ENGINE PARTS

15

	No. 1 Engine 2 1/4" diameter 3 1/2" stroke	No. 2 Engine 3" diameter 4" stroke	No. 3 Engine 3 3/4" diameter 5" stroke	No. 6 Engine 3 1/2" diameter 4 1/2" stroke	No. 7 Engine 4" diameter 5" stroke
Reverse lever dog	183	10-183	20-183	60-183	70-183
" " " screw	184	10-184	20-184	60-184	70-184
" " " nut	185	10-185	20-185	60-185	70-185
PACKED STEAM SWIVEL JOINT	186*	10-186	20-186	60-186	70-186
" " " body	186A	10-186A	20-186A	60-186A	70-186A
" " " p'k'g tube	186B	10-186B	20-186B	60-186B	70-186B
" " " gland	186C	10-186C	20-186C	60-186C	70-186C
" " " p'k'g nut	186D	10-186D	20-186D	60-186D	70-186D
" " " lock	186E	10-186E	20-186E	60-186E	70-186E
" " " p'k'g 1/8"					
Vulcanizing cord, per yd.	186F	10-186F	20-186F	60-186F	70-186F
Reverse lever shaft arm	187A	10-187A	20-187A	60-187A	70-187A
" " " woodruff key	187B	10-187B	20-187B	60-187B	70-187B
" " " set screw	187C	10-187C	20-187C	60-187C	70-187C
Engine frame rod spring	189	10-189	20-189	60-189	70-189
" case diaphragm	190A	10-190A	20-190A	60-190A	70-190A
" " stuffing box	190B	10-190B	20-190B	60-190B	70-190B
" " " lock nut	190C	10-190C	20-190C	60-190C	70-190C
" " " p'k'g nut	190D	10-190D	20-190D	60-190D	70-190D
" rear case felt band	191A	10-191A	20-191A	60-191A	70-191A
" diaphragm felt band	191B	10-191B	20-191B	60-191B	70-191B
" cylinder case felt band	191C	10-191C	20-191C	60-191C	70-191C

BALL LIST

MODEL EX

MODEL 60

1/4" Ball	Price	1/4" Ball	Price	5/16" Ball	Price
1/4" Ball	.005	1/4" Ball pump rocker end bearing	29	5/16" Ball eccentric	(28 in each)
5/16" "	.01	5/16" " eccentric	29	5/16" " front wheel	(15 ")
3/8" "	.015	3/8" " pump rocker center	10	5/16" " crank pin	(10 ")
1/2" "	.025	3/8" " front wheel	15	5/16" " crosshead	(2 ")
1/2" "	.03	1/2" " crank pin	10	5/16" " rear axle, inside	(13 ")
5/8" "	.06	1/2" " crosshead	2	5/16" " " outside	(13 ")
3/4" "	.10	1 1/2" " rear axle, inside	13	5/16" " engine main bearing	(12 ")
3/4" "	.15	1 1/2" " " outside	14		
		5/8" " engine main bearing	12		
MODEL C					
1/4" Ball pump rocker end bearing	(8 in each)	MODEL F			
1/4" " eccentric	24	1/4" Ball pump rocker end	(10 in each)	MODEL 70	
3/8" " pump rocker center	10	5/16" " eccentric	28	5/16" Ball eccentric	(34 in each)
3/8" " crank pin	10	3/8" " pump rocker center	10	5/16" " crank pin	(10 ")
3/8" " front wheel	13	3/8" " crank pin	10	5/16" " front wheel	(15 ")
3/8" " rear axle, inside	16	5/8" " crosshead	2	5/16" " engine main bearing	(15 ")
1/2" " " outside	14	5/8" " front wheel	13	5/16" " crosshead	(2 ")
1/2" " crosshead	2	3/4" " rear axle, inside and outside	12	5/16" " rear axle, inside	(12 ")
1/2" " main bearing	12	3/4" " engine main bearing	12	5/16" " " outside	(12 ")

* Brass.

When writing us, always give model and NUMBER of car

	Models B & C		Model EX		Model F		Model 60		Model 70	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
BODY COMPLETE	200	---	10-200	\$150.00	20-200	\$400.00	60-200	\$150.00	70-200	\$400.00
Front seat with cushions	200A	---	10-200A	60.00	20-200A	115.00	60-200A	60.00	70-200A	115.00
" " cushion each	200B	---	10-200B	12.00	20-200B	10.00	60-200B	7.50	70-200B	10.00
Rear " with cushion	200C	---	10-200C	---	20-200C	130.00	---	---	70-200C	130.00
Toy tonneau seat cushion and doors	---	---	---	---	---	---	61-200	\$5.00	---	---
Rear seat with cushion	---	---	---	---	---	---	---	---	71-200C	115.00
" " cushion	200D	---	10-200D	---	20-200D	20.00	---	---	70-200D	20.00
MODEL B or BX BODY COMPLETE										
with panel seat	201	\$120.00	---	---	---	---	---	---	---	---
Panel seat with cushion	201A	50.00	---	---	---	---	---	---	---	---
Cushion	201B	10.00	---	---	---	---	---	---	---	---
MODEL C or CX BODY COMPLETE										
with PANEL SEAT and FOLDING FRONT	202	145.00	---	---	---	---	---	---	---	---
Boiler lug front and back	204	.10	---	---	---	---	---	---	---	---
" " side	204A	.10	---	---	---	---	---	---	---	---
" " screw	204B	.01	---	---	---	---	---	---	---	---
BOILER SUPPORT	204	---	10-204	3.50	20-204	5.00	60-204	3.50	70-204	5.00
" " bolts and nuts	204C	---	10-204C	.05	20-204C	.05	60-204C	.05	70-204C	.05
Sector gear brace rod bolt	204E	---	10-204E	.10	20-204E	.10	60-204E	.10	70-204E	.10
" " " nut	204F	---	10-204F	.03	20-204F	.03	60-204F	.03	70-204F	.03
Burner hanger bolt, nuts and washer	205	.05	---	---	---	---	---	---	---	---
Boiler anchor and burner hanger bolt	205A	---	10-205A	.15	20-205A	.15	60-205A	.15	70-205A	.15
Burner hanger bolt brass nut	205C	---	10-205C	.10	20-205C	.10	60-205C	.10	70-205C	.10
Boiler anchor bolt steel nut	205D	---	10-205D	.05	20-205D	.05	60-205D	.05	70-205D	.05
" " " square washer	205E	---	10-205E	.02	20-205E	.02	---	---	---	---
" " " band	205S	---	10-205S	.25	20-205S	.25	60-205S	.25	70-205S	.25
ENGINE HANGER STRAP BRACKET										
" " " " nut	206	.40	10-206	.40	20-206	.65	60-206	.75	70-206	.75
" " " " castle nut	207A	.05	10-207A	.05	20-207A	.10	60-207A	.10	70-207A	.10
" " " " bolt	207B	---	10-207B	---	20-207B	---	60-207B	.20	70-207B	.20
" " " " nut	208A } 208B }	.03	10-208A } 10-208B }	.03	20-208A } 20-208B }	.05	60-208A } 60-208B }	.05	70-208A } 70-208B }	.05
Steering head	209	1.25	---	---	---	---	---	---	---	---
" " screw	210	.05	---	---	---	---	---	---	---	---
" " bolt and nut	211	.02	---	---	---	---	---	---	---	---
" handle bar and post	212	4.50	---	---	---	---	---	---	---	---
" " " grip	213	.15	---	---	---	---	---	---	---	---
" drop	214	2.50	---	---	---	---	---	---	---	---
" " bolt and nut	215	.02	---	---	---	---	---	---	---	---
" handle bar connecting rod	217	2.00	---	---	---	---	---	---	---	---
" " " " screw and nut	218	.05	---	---	---	---	---	---	---	---

When writing us, always give model and NUMBER of car




Plate 25

WHEEL STEER AND BRAKE PARTS, Etc.

	Models B & C		Model EX		Model F		Model 60		Model 70	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
WHEEL STEER upper bracket	209A	---	10-209A	\$1.75	20-209A	\$1.75	60-209A	\$1.75	70-209A	\$1.75
" " lower	209B	---	10-209B	1.00	20-209B	1.00	60-209B	1.00	70-209B	1.00
Wheel steer, upper bracket set screw	209C	---	10-209C	.05	20-209C	.05	60-209C	.05	70-209C	.05
" " lower " " " nut	209D	---	10-209D	.05	20-209D	.05	60-209D	.05	70-209D	.05
" " " " " eccentric bush	209E	---	10-209E	.03	20-209E	.03	60-209E	.03	70-209E	.03
" " " " " plate	209F	---	10-209F	.50	20-209F	.50	60-209F	.50	70-209F	.50
Wheel steer, bracket stove bolts	209P	---	10-209P	.20	20-209P	.20	60-209P	.20	70-209P	.20
" " carriage bolts and nut	210A	---	10-210A	.02	20-210A	.02	60-210A	.02	70-210A	.02
" " " " " tube	210C	---	10-210C	.05	20-210C	.05	60-210C	.05	70-210C	.05
Wheel steer, outside tube	211	---	10-211	1.00	20-211	1.00	60-211	1.00	70-211	1.00
" " inside post with pinion	212A	---	10-212A	3.35	20-212A	3.35	60-212A	3.35	70-212A	3.35
" " pinion	212B	---	10-212B	.75	20-212B	.75	60-212B	.75	70-212B	.75
" " bottom nut	212C	---	10-212C	.10	20-212C	.10	60-212C	.10	70-212C	.10
" " top nut	212D	---	10-212D	.35	20-212D	.35	60-212D	.35	70-212D	.35
" " bottom bushing	212E	---	10-212E	.75	20-212E	.75	60-212E	.75	70-212E	.75
" " top bushing	212F	---	10-212F	.60	20-212F	.60	60-212F	.60	70-212F	.60
" " post inside tube key	212K	---	10-212K	.05	20-212K	.05	60-212K	.05	70-212K	.05
" " " " washer	212W	---	10-212W	.05	20-212W	.05	60-212W	.05	70-212W	.05
Steering wheel	213	---	10-213	5.00	20-213	5.00	60-213	5.00	70-213	5.00
STEERING SECTOR GEAR BRONZE	214A	---	10-214A	10.00	20-214A	10.00				
" " drop stud	214B	---	10-214B	1.50	20-214B	1.50	60-214B	1.50	70-214B	1.50
" " " " nut	214C	---	10-214C	.10	20-214C	.10	60-214C	.10	70-214C	.10
" " " " brace	214D	---	10-214D	.40	20-214D	.40	60-214D	.40	70-214D	.40
" " " " washer	214E	---	10-214E	.05	20-214E	.05	60-214E	.05	70-214E	.05
SECTOR GEAR STEEL	216	---	10-216	---	20-216	---	60-216	10.00	70-216	10.00
" " arm bushing	216D	---	10-216D	---	20-216D	---	60-216D	.35	70-216D	.35
" " " " castle nut	216E	---	10-216E	---	20-216E	---	60-216E	.10	70-216E	.10
" " top bushing	216F	---	10-216F	---	20-216F	---	60-216F	.45	70-216F	.45
" " bottom bushing	216G	---	10-216G	---	20-216G	---	60-216G	.45	70-216G	.45
Steering drop connecting rod	219	\$3.00	10-219	3.00	20-219	3.00	60-219	3.00	70-219	3.00
" " gear short screw	220A	.10	10-220A	.10	20-220A	---	60-220A	.10		
" " " " long	220B	.10	10-220B	.10	20-220B	.10	60-220B	.10	70-220B	.10
" " " " nut	220C	.02	10-220C	.02	20-220C	.02	60-220C	.02	70-220C	.02
" " knuckle lower	221	.40	10-221	.40	20-221	.75	60-221	.40	70-221	1.00
" " " " upper	221B	.40	10-221B	.75	20-221B	.75	60-221B	1.00	70-221B	1.00
HUB BRAKE ROCKER	222	---	10-222	3.25	20-222	3.25				
Double hub brake rocker	222	---	10-222X	5.00	20-222	---	60-222	5.00	70-222	5.00
Brake pedal	223A	1.25	10-223A	1.25	20-223A	1.25	60-223A	---	70-223A	---
Hub brake pedal	223B	---	10-223B	1.25	20-223B	1.25	60-223B	1.25	70-223B	1.25
Brake pedal hanger complete	224	.90	10-224	1.25	20-224	1.25	60-224	1.25	70-224	1.25
" " hanger screw	225	---	10-225	.01	20-225	.01	60-225	.01	70-225	.01
" " " " bolt and nut	225	.02	10-225	.02	20-225	.02	60-225	.02	70-225	.02
" " connecting rod with two jaws	226	.80	10-226	.80	20-226	.80	60-226	.80	70-226	.80
" " rod jaw plain	226B	.25	10-226B	.25	20-226B	.25	60-226B	.25	70-226B	.25
" " " " threaded	226C	.25	10-226C	.25	20-226C	.25	60-226C	.25	70-226C	.25
External hub brake side rod complete	227	---	10-227	.80	20-227	---	60-227	.80	70-227	.80
All brake rod jaw	---	.25	---	.25	---	.25	---	.25	---	.25
Brake rod jaw pin	228	.05	10-228	.05	20-228	.05	60-228	.05	70-228	.05
Otter pins, per doz., specify size required	229	.05	10-229	.05	20-229	.05	60-229	.05	70-229	.05

When writing us, always give model and NUMBER of car

BRAKE AND REVERSE PARTS, Etc.

19

	Models B & C		Model EX		Model F		Model 60		Model 70	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
Brake pedal spring	230	\$0.15	10-230	\$0.15	20-230	\$0.15	60-230	\$0.15	70-230	\$0.15
" " " screw eye	231	.01	10-231	.01	20-231	.10	60-231	.10	70-231	.10
" " " hook	232	---	10-232	---	20-232	---	60-232	10.00	70-232	10.00
EMERG'Y BRAKE HAND LEVER comp.	232A	---	10-232A	---	20-232A	---	60-232A	6.25	70-232A	6.25
" " " " latch	232B	---	10-232B	---	20-232B	---	60-232B	.75	70-232B	.75
" " " " bolt	232C	---	10-232C	---	20-232C	---	60-232C	.05	70-232C	.05
" " " " bolt nut	232D	---	10-232D	---	20-232D	---	60-232D	.05	70-232D	.05
" " " " locking	232E	---	10-232E	---	20-232E	---	60-232E	.10	70-232E	.10
catch draw rod	232F	---	10-232F	---	20-232F	---	60-232F	.15	70-232F	.15
Emergency brake hand lever locking catch	232G	---	10-232G	---	20-232G	---	60-232G	.05	70-232G	.05
draw rod lug	232H	---	10-232H	---	20-232H	---	60-232H	.15	70-232H	.15
Emergency brake hand lever locking catch	232J	---	10-232J	---	20-232J	---	60-232J	.01	70-232J	.01
draw rod lock nut	232K	---	10-232K	---	20-232K	---	60-232K	1.15	70-232K	1.15
Emergency brake hand lever locking catch	232L	---	10-232L	---	20-232L	---	60-232L	.15	70-232L	.15
" " " " " "	232M	---	10-232M	---	20-232M	---	60-232M	.05	70-232M	.05
Emergency brake hand lever locking catch	232N	---	10-232N	---	20-232N	---	60-232N	.50	70-232N	.50
bolt nut	232O	---	10-232O	---	20-232O	---	60-232O	.15	70-232O	.15
Emergency brake hand lever ratchet rack	232P	---	10-232P	---	20-232P	---	60-232P	.10	70-232P	.10
offset studs screw	232Q	---	10-232Q	---	20-232Q	---	60-232Q	.05	70-232Q	.05
Emergency brake hand lever ratchet rack	233	---	10-233	---	20-233	---	60-233	.20	70-233	.20
offset studs screw nuts	233A	---	10-233A	---	20-233A	---	60-233A	.10	70-233A	.10
Hub brake side-rod guide complete	233B	---	10-233B	---	20-233B	---	60-233B	.05	70-233B	.05
" " " " " leather	233C	---	10-233C	---	20-233C	---	60-233C	.05	70-233C	.05
" " " " " clip and nuts	234	---	10-234	.80	20-234	.80	60-234	.80	70-234	.80
" " " " " bar	235	.40	10-235	.40	20-235	.40	60-235	.40	70-235	.40
Internal hub brake side rod complete	236	.02	10-236	.02	20-236	.02	60-236	.02	70-236	.02
Reverse pedal brackets, each	237	.80	10-237	.80	20-237	3.00	60-237	3.00	70-237	3.00
" " " " " bolt and nut	238A	.25	10-238A	.25	20-238A	.25	60-238A	.25	70-238A	.25
rod with two jaws	238B	.25	10-238B	.25	20-238B	.25	60-238B	.25	70-238B	.25
REVERSE and hook-up rod complete	239	.15	10-239	.15	20-239	.15	60-239	.15	70-239	.15
" " " " " spring	239B	---	10-239B	---	20-239B	---	60-239B	.10	70-239B	.10
" " " " " and hook-up rod spring hook	239C	---	10-239C	---	20-239C	---	60-239C	.01	70-239C	.01
" " " " " " " screw	241	.02	10-241	.02	20-241	.02	60-241	1.25	70-241A	1.25
" " " " " " " rod spring screw eye	241B	1.25	10-241B	1.25	20-241B	1.25	60-241B	1.25	70-241B	1.25
Rear step	241C	---	10-241C	.15	20-241C	.15	60-241C	.15	70-241C	.15
REVERSE PEDAL	242	.03	10-242	.03	20-242	.03	60-242	.03	70-242	.03
" " " " " " " hook-up pedal	243	---	10-243	---	20-243	---	60-243	---	70-243	---
" " " " " " " shaft	244	---	10-244	---	20-244	---	60-244	---	70-244	---
Rear step screw	245	---	10-245	---	20-245	---	60-245	---	70-245	---

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model







Plate 26

TANK GLASS AND PUMP ROCKER PARTS, Etc.

21

	Models B & C		Model EX		Model F		Model 60		Model 70	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
Hub brake pedal pawl	2420	1.00	10-2420	\$1.25	20-2420	\$1.25				
" " catchet rack	2421	1.00	10-2421	.40	20-2421	.40				
" " " washer	2422	1.00	10-2422	.01	20-2422	.01				
" " " screw	2423	1.00	10-2423	.01	20-2423	.01				
" " " roller bracket rack	2424	1.00	10-2424	1.00	20-2424	1.00				
" " " " screw	2425	1.00	10-2425	.02	20-2425	.02	60-2425	\$0.50	70-2425	\$0.50
WATER TANK GLASS and fittings comp.										
Water tank glass	2426A	\$0.15	10-2426A	.15	20-2426A	.15	60-2426A	1.17	70-2426A	1.17
" " " top bracket	2426B	.25	10-2426B	.25	20-2426B	.25	60-2426B	.25	70-2426B	.25
" " " bottom bracket	2426C	.50	10-2426C	.50	20-2426C	.50	60-2426C	.50	70-2426C	.50
" " " rubber tube per foot	2426D	.35	10-2426D	.35	20-2426D	.35	60-2426D	.35	70-2426D	.35
" " " shut off cock	2426E	.35	10-2426E	.35	20-2426E	.35	60-2426E	.35	70-2426E	.35
" " " hose nipple	2426F	.15	10-2426F	.15	20-2426F	.15	60-2426F	.15	70-2426F	.15
" " " tank nipple	2426G	.10	10-2426G	.10	20-2426G	.10	60-2426G	.10	70-2426G	.10
" " " 3/8" elbow	2426H	.08	10-2426H	.08	20-2426H	.08	60-2426H	.08	70-2426H	.08
" " " 3/8" nipple	2426I	.10	10-2426I	.10	20-2426I	.10	60-2426I	.10	70-2426I	.10
Pump rocker connecting rod	2427	2.00	10-2427	2.50	20-2427	3.00				
" " " " " screw	2428	.04	10-2428	.04	20-2428	.10				
" " " " " nut	2500C	.04	10-2500C	.04	20-2500C	.04				
Stop sleeve	251	.35	10-251	.35	20-251	.35				
" " " screw	252	.04	10-252	.04	20-252	.04				
PUMP ROCKER SHAFT complete	253	3.00	10-253	3.00	20-253	3.00	60-253	3.00	70-253	3.00
" " " " " oil pump arm	253A	.15	10-253A	.15	20-253A	.15				
" " " " " nut	253B	.04	10-253B	.04	20-253B	.04				
" " " " " adjusting pin screw	253C	.04	10-253C	.04	20-253C	.10	60-253C	.10	70-253C	.10
" " " " " bracket plate base	253D	.02	10-253D	.02	20-253D	.02	60-253D	.02	70-253D	.02
" " " " " base per pair	254	1.50	10-254	1.50	20-254	1.50				
Bottom bearing pump rocker bracket complete	254B	2.50	10-254B	2.50	20-254B	2.50	60-254B	2.50	70-254B	2.50
Bottom bearing pump rocker bracket base	254A	1.50	10-254A	.75	20-254A	.75	60-254A	.75	70-254A	.75
" " " " " bushing	254B	.25	10-254B	.25	20-254B	.25	60-254B	.25	70-254B	.25
" " " " " roller	254C	.02	10-254C	.02	20-254C	.02	60-254C	.02	70-254C	.02
" " " " " washers, 1/2" hole	254D	.02	10-254D	.02	20-254D	.02	60-254D	.02	70-254D	.02
" " " " " 3/8" hole	254E	.02	10-254E	.02	20-254E	.02	60-254E	.02	70-254E	.02
" " " " " roller pin per ft.	254F	.02	10-254F	.02	20-254F	.02	60-254F	.02	70-254F	.02
Pump rocker bracket adjusting screw base	255	.02	10-255	.02	20-255	.02	60-255	.02	70-255	.02
" " " " " short bracket hole and nut	255A	.02	10-255A	.02	20-255A	.02	60-255A	.02	70-255A	.02
" " " " " base complete	255B	3.00	10-255B	3.00	20-255B	3.00	60-255B	3.00	70-255B	3.00
" " " " " tank plate, 2 1/2" long on center	255C	.20	10-255C	.20	20-255C	.20				
" " " " " bracketed, 2 1/2" long on center	255D	.20	10-255D	.20	20-255D	.20				
" " " " " 3/8" hole	255E	.04	10-255E	.04	20-255E	.04				
" " " " " nut	255F	.04	10-255F	.04	20-255F	.04				
Oil pump exit	256	.15	10-256	.15	20-256	.15				
" " " " " screw and nut	256B	.02	10-256B	.02	20-256B	.02				
" " " " " spring	256C	.02	10-256C	.02	20-256C	.02				
Water suction hose, per foot	257	.35	10-257	.35	20-257	.35	60-257	.35	70-257	.35

If not working on Model 60 use Model and NOT MODEL 70.

If not on price in given part is not used on that model.

GAUGES, HOODS, SUPPORTS, Etc.

	Models B & C		Model EX		Model F		Model G0		Model 70	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
Water suction hose nipple	263	\$0.15	10-263	\$0.15	20-263	\$0.15	60-263	\$0.15	70-263	\$0.15
Suction hose tee	263B	.25	10-263B	.25	20-263B	.25	60-263B	.25	70-263B	.25
" " elbow	263C	.15	10-263C	.15	20-263C	.15	60-264	.15	70-264	.15
Water by-pass nipple	264	.15	10-264	.15	20-264	.15	60-268	.30	70-268	.30
AIR CHECK WITH CAP	268	.30	10-268	.30	20-268	.30	60-268B	.05	70-268B	.05
" " cap	268B	.05	10-268B	.05	20-268B	.05	60-269	3.00	70-269	3.00
STEAM PRESSURE GAUGE, 2 3/4"	269	3.00	10-269	3.00	20-269	3.00	60-269	3.00	70-269	3.00
" " " 3"	269	---	10-269	---	20-269	---	60-270	3.00	70-270	3.00
Fuel " " " 2 3/4"	270	3.00	10-270	3.00	20-270	3.00	60-270	3.00	70-270	3.00
Fuel pressure gauge, 3"	270	---	10-270	---	20-270	---	60-271	2.50	70-271	2.50
SAFETY VALVE	271	2.50	10-271	2.50	20-271	2.50	60-271	1.50	70-271	1.50
" " spring	271D	.15	10-271	.15	20-271	.15	60-272	2.00	70-272	2.00
SIPHON with hose nipple	272	2.00	10-272	2.00	20-272	2.00	60-273	1.00	70-273	1.00
" " hose, 7 ft.	273	1.00	10-273	1.00	20-273	1.00	60-274	.50	70-274	.50
" " strainer	274	.50	10-274	.50	20-274	.50	60-274B	.20	70-274B	.20
" " nipple	274B	.20	10-274B	.20	20-274B	.20	60-275	---	70-275	---
" " screw hooks	275	.02	10-275	.20	20-275	.20	60-275	.20	70-275	.20
" " brackets	275	---	10-275	---	20-275	---	60-279	25.00	70-279	30.00
HOOD	279	---	10-279	25.00	20-279	30.00	60-279F	.01	70-279F	.01
" " hinge wood screw	279F	---	10-279F	.01	20-279F	.01	60-280	.65	70-280	.65
" " French catch	280	---	10-280	1.25	20-280	1.25	60-280E	.25	70-280E	.25
" " catch complete each	280	---	10-280	---	20-280	---	60-280G	.10	70-280G	.10
" " hook	280E	---	10-280E	---	20-280E	---	60-280H	.01	70-280H	.01
" " spring	280G	---	10-280G	---	20-280G	---	60-280J	.05	70-280J	.05
" " washer	280H	---	10-280H	---	20-280H	---	60-280K	.10	70-280K	.10
" " cotter pin, per doz.	280J	---	10-280J	---	20-280J	---	60-280L	.15	70-280L	.15
" " plate	280K	---	10-280K	---	20-280K	---	60-280M	.01	70-280M	.01
" " chafing plate	280L	---	10-280L	---	20-280L	---	60-280N	.01	70-280N	.01
" " " screw	280M	---	10-280M	---	20-280M	---	60-281	.10	70-281	.10
" " plate rivets	280N	---	10-280N	---	20-280N	---	60-281B	.01	70-281B	.01
Automatic valve bottom support	281A	.10	10-281A	.10	20-281A	.10	60-281C	.10	70-281C	.10
" " support screw	281B	.01	10-281B	.01	20-281B	.01	60-283	.10	70-283	.10
" " top support	281C	---	10-281C	---	20-281C	---	60-283B	.01	70-283B	.01
Relief valve support	283	.10	10-283	.10	20-283	.10	60-284	.10	70-284	.10
" " " screw	283B	.01	10-283B	.01	20-283B	.01	60-284B	.01	70-284B	.01
Gasolene tee check support	284	.10	10-284	.10	20-284	.10	60-285	.10	70-285	.10
" " " screw	284B	.01	10-284B	.01	20-284B	.01	60-285B	.01	70-285B	.01
Safety valve support	285	.10	10-285	.10	20-285	.10	60-286	.10	70-286	.10
" " " screw	285B	.01	10-285B	.01	20-285B	.01	60-286	.10	70-286	.10
Air check support	286	.10	10-286	.10	20-286	.10	60-287	.10	70-287	.10
" " " Model 71	286B	.01	10-286B	.01	20-286B	.01	60-287	.10	70-287	.10
" " " screw	287	.10	10-287	.10	20-287	.10	60-287B	.01	70-287B	.01
" " " Model 71	287B	.01	10-287B	.01	20-287B	.01	60-293	.35	70-293	.35
Siphon valve support	293	.35	10-293	.35	20-293	.35	60-293B	.01	70-293B	.01
Pressure tank support	293B	.01	10-293B	.01	20-293B	.01	60-298	.10	70-298	.10
" " " screw	298	.10	10-298	.10	20-298	.10	60-298B	.01	70-298B	.01
Blow-off tube support	298B	.01	10-298B	.01	20-298B	.01	60-298B	.01	70-298B	.01

When writing us, always give model and NUMBER of car

BURNERS

23

	Models B & C, 14"		Model EX, 18"		Model F, 23"		Model 60, 18"		Model 70, 23"	
BURNER	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
Burner casing pan	300	\$16.00	10-300	\$23.00	20-300	\$33.00	60-300	\$23.00	70-300	\$33.00
" " metal side lining	301A	1.50	10-301A	2.00	20-301A	2.50	60-301A	2.00	70-301A	2.50
" " asbestos side lining	301B	.20	10-301B	.35	20-301B	.45	60-301B	.35	70-301B	.45
" " bottom lining	301C	.15	10-301C	.20	20-301C	.25	60-301C	.20	70-301C	.25
" " peek hole cover	301D	.20	10-301D	.20	20-301D	.25	60-301D	.20	70-301D	.25
" " " " screw and nut	301E	.05	10-301E	.05	20-301E	.05	60-301E	.05	70-301E	.05
" " " " " " " " " " " "	301F	.01	10-301F	.01	20-301F	.01	60-301F	.01	70-301F	.01
" " lug	301G	.10	10-301G	.15	20-301G	.15	60-301G	.15	70-301G	.15
" " rivets, per doz.	301H	.05	10-301H	.05	20-301H	.05	60-301H	.05	70-301H	.05
Main burner casting complete	302	8.00	10-302	12.00	20-302	20.00	60-302	12.00	70-302	20.00
Pilot casting	302B	.75	10-302B	.75	20-302B	.75	60-302B	.75	70-302B	.75
Main burner casting bottom	302C	.30	10-302C	.50	20-302C	.60	60-302C	.50	70-302C	.60
Pilot " " screw	302G	---	10-302G	.03	20-302G	.03	60-302G	.03	70-302G	.03
Main mixing tube	303	.30	10-303	.30	20-303	.40	60-303	.30	70-303	.40
Pilot " " " "	304	.15	10-304	.15	20-304	.15	60-304	.15	70-304	.15
VAPORIZER	305	3.00	10-305	4.50	20-305	5.00	60-305	4.50	70-305	5.00
" pilot screw with wire	306	.10	10-306	.10	20-306	.10	60-306	.10	70-306	.10
" main " " "	307	.05	10-307	.05	20-307	.05	60-307	.05	70-307	.05
" clean-out screw	308	.05	10-308	.05	20-308	.05	60-308	.05	70-308	.05
" cable	309	.10	10-309	.15	20-309	.15	60-309	.15	70-309	.15

	Models BX and CX			Models BX and CX	
BURNER, 16"	No.	Price		No.	Price
Burner casing	300X	\$18.00	Pilot casting	302XB	\$0.75
" " metal side lining	301XA	1.75	Main burner casting bottom	302XC	.35
" " asbestos side lining	301XB	.25	Pilot " " screw	302XG	.03
" " bottom lining	301XC	.20	Main mixing tube	303X	.30
" " peek hole cover	301XD	.20	Pilot " " " "	304X	.15
" " " " " " " " " " " "	301XE	.05	VAPORIZER	305X	3.25
" " " " " " " " " " " "	301XF	.01	" pilot screw with wire	306	.10
" " lug	301XG	.10	" main " " "	307	.05
" " rivet, per doz.	301XH	.05	" clean-out screw	308	.05
Main burner casting complete	302X	10.00	" wire cable	309X	.15

BOILERS

	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
BOILER COMPLETE	310	\$65.00	10-310	\$100.00	20-310	\$160.00	60-310	\$100.00	70-310	\$160.00
Boiler asbestos covering	310F	2.50	10-310F	3.25	20-310F	4.25	60-310F	3.25	70-310F	4.25
" tubes	311	.15	10-311	.15	20-311	.15	60-311	.15	70-311	.15
" bushings	311B	.01	10-311B	.01	20-311B	.01	60-311B	.01	70-311B	.01
" superheater tubes	312	.30	10-312	.30	20-312	.30	60-312	.30	70-312	.30
Fusible fitting	313	1.00	10-313	1.00	20-313	1.00	60-313	1.00	70-313	1.00
Short boiler tube for fusible fitting	314	.06	10-314	.06	20-314	.06	60-314	.06	70-314	.06
Long " " " " " " " " " "	315	.10	10-315	.10	20-315	.10	60-315	.10	70-315	.10
Boiler feed stub with extension pipe	315F	---	10-315F	.50	20-315F	.50	60-315F	.50	70-315F	.50

When writing us, always give model and NUMBER of car

Where no price is given part is not used on that model

BOILER FITTINGS, TANKS, Etc.

	Models B & C		Model EX		Model F		Model 60		Model 70	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
FUSIBLE PLUG TUBE	316	\$0.15	10-316	\$0.15	20-316	\$0.15	60-316	\$0.15	70-316	\$0.15
" lead plug	317	.01	10-317	.01	20-317	.01	60-317	.01	70-317	.01
Exhaust hose	318	.60	10-318	.60	20-318	1.00	60-318	1.00	70-318	1.00
" clamps	318E	.10	10-318E	.10	20-318E	.10	60-318E	.10	70-318E	.15
EXHAUST MUFFLER	319	2.50	10-319	5.00	20-319	7.00	60-319	5.00	70-319	7.00
" elbow	320	.25	10-320	.25	20-320	.35	60-320	.25	70-320	.35
" hose nipple	321	.25	10-321	.25	20-321	.35	60-321	.25	70-321	.35
" inside washer	322A	---	10-322A	.35	20-322A	.50	60-322A	.35	70-322A	.50
" outside "	322B	---	10-322B	.35	20-322B	.50	60-322B	.35	70-322B	.50
Smoke bonnet	323A	1.75	10-323A	4.00	20-323A	4.50	60-323A	4.00	70-323A	4.50
" down draft	323B	---	10-323B	.35	20-323B	.40	60-323B	.35	70-323B	.40
" elbow	323C	---	10-323C	1.00	20-323C	1.00				
" flue and elbow	324	---	10-324	3.75	20-324	3.75	60-324	4.00	70-324	5.00
" wood screws	325A	---	10-325A	.01	20-325A	.01	60-325A	.01	70-325A	.01
" screw	325B	---	10-325B	.01	20-325B	.01	60-325B	.01	70-325B	.01
" nut	325C	---	10-325C	.01	20-325C	.01	60-325C	.01	70-325C	.01
PRESSURE TANK, per pair	328	7.50	10-328	7.50	20-328	7.50	60-328	7.50	70-328	7.50
" drip valve	330	.30	10-330	.65	20-330	.65	60-330	.65	70-330	.65
Water tank	331	20.00	10-331	20.00	20-331	25.00	60-331	20.00	70-331	25.00
" cover	332	.50	10-332	.50	20-332	.50	60-332	.50	70-332	.50
Gasolene tank complete	333	16.00	10-333	16.00	20-333	18.00	60-333	16.00	70-333	18.00
" filler cap	333E	.15	10-333E	.15	20-333E	.15	60-333E	.25	70-333E	.25
Steam boiler nipple	334A	.25	10-334A	.25	20-334A	.25				
" elbow	335A	.10	10-335A	.10	20-335A	.10				
" nipple and elbow combined	334	---	10-334	.50	20-334	.50	60-334	.50	70-334	.50
" throttle nipple	336	.15	10-336	.40	20-336	.50	60-336	.40	70-336	.50
THROTTLE VALVE	337	5.00	10-337	5.00	20-337	5.00	60-337	5.00	70-337	5.00
" body	338	3.25	10-338	3.25	20-338	3.25	60-338	3.25	70-338	3.25
" stem	339	1.00	10-339	1.00	20-339	1.00	60-339	1.00	70-339	1.00
" nut	340	.03	10-340	.03	20-340	.03	60-340	.03	70-340	.03
" jaw	341	.25	10-341	.25	20-341	.25	60-341	.25	70-341	.25
" pin	342	.05	10-342	.05	20-342	.05	60-342	.05	70-342	.05
" stuffing box gland	343	.05	10-343	.05	20-343	.05	60-343	.05	70-343	.05
" stem stuffing box nut	344	.15	10-344	.15	20-344	.15	60-344	.15	70-344	.15
" brace rod	345	.10	10-345	.10	20-345	.10	60-345	.10	70-345	.10
" nut, washer,										
sleeve	346	.10	10-346	.10	20-346	.10	60-346	.10	70-346	.10
Brass union	350	.35								
" nipple	351	.15								
Auxiliary throttle	352	1.50	10-352	2.75	20-352	5.00				
Superheater elbow for auxiliary throttle	353A	.35								
" "	353B	.35	10-353B	.35	20-353B	.35	60-353B	.35	70-353B	.35
Inside bottom SUPERHEATER	354	1.50	10-354	1.60	20-354	1.80	60-354	1.60	70-354	1.80
Outside " "	355	1.60	10-355	1.80	20-355	2.00	60-355	1.80	70-355	2.00
Top connecting " "	356	1.25	10-356	1.25						
Throttle connecting superheater	357	---	10-357	1.25	20-357	2.50	60-357	2.25	70-357	2.50
MAIN STEAM PIPE not covered	359	2.25	10-359	2.50	20-359	4.00	60-359	3.75	70-359	4.00
" covered	359X	---	10-359X	4.00	20-359X	5.50	60-359X	5.25	70-359X	5.50
Oil check " "	360	.25	10-360	.50	20-360	.50	60-360	.50	70-360	.50

When writing us, always give model and NUMBER of car

BOILER FITTINGS, THROTTLE LEVER, Etc.

25


	Models B & C		Model EX		Model F		Model 60		Model 70	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
1/2" steel BOILER ELBOW short.....	361A	\$0.30	10-361A	\$0.30	20-361A	\$0.30	60-361A	\$0.30	70-361A	\$0.30
1/2" " " " medium.....	361B	.30	10-361B	.30	20-361B	.30	60-361B	.30	70-361B	.30
1/2" " " " long.....	361C	.30	10-361C	.30	20-361C	.30	60-361C	.30	70-361C	.30
3/4" " " " ".....	361D	.35	10-361D	.35	20-361D	.35	60-361D	.35	70-361D	.35
Main steam pipe cover complete.....	362	---	10-362	1.50	20-362	1.50	60-362	1.50	70-362	1.50
By-pass valve. See Valve list.										
Long stem for by-pass valve.....	363C	---	10-363C	.35	20-363C	.35	60-363C	.35	70-363C	.35
Lever for valve stem.....	363D	---	10-363D	.15	20-363D	.15	60-363D	.15	70-363D	.15
Nut.....	363E	---	10-363E	.10	20-363E	.10	60-363E	.10	70-363E	.10
Forward by-pass valve stem bracket.....	364	---	10-364	.75	20-364	.75	60-364	.75	70-364	.75
" " " " " set screw.....	364B	---	10-364B	.05	20-364B	.05	60-364B	.05	70-364B	.05
" " " " " support.....	364C	---	10-364C	.10	20-364C	.10	60-364C	.10	70-364C	.10
" " " " " screws.....	364D	---	10-364D	.01	20-364D	.01	60-364D	.01	70-364D	.01
" " " " " plug.....	364E	---	10-364E	.05	20-364E	.05	60-364E	.05	70-364E	.05
Throttle lever quadrant.....	366	---	10-366	2.50	20-366	2.50	60-366	2.50	70-366	2.50
" " " " " set screw.....	367	---	10-367	.10	20-367	.10	60-367	.10	70-367	.10
" " " " " locking screw.....	368	---	10-368	.10	20-368	.10	60-368	.10	70-368	.10
" " " " " grip.....	369A	.25	10-369A	.25	20-369A	.25	60-369A	.25	70-369A	.25
" " " " " nut.....	369B	.05	10-369B	.05	20-369B	.05	60-369B	.05	70-369B	.05
THROTTLE LEVER.....	370	2.50	10-370	.75	20-370	.75	60-370	.75	70-370	.75
" " " " " rod.....	371	---	10-371	1.25	20-371	1.25	60-371	1.25	70-371	1.25
" " " " " nut.....	372	---	10-372	.05	20-372	.05	60-372	.05	70-372	.05
" " " " " rocker with brackets.....	373	---	10-373	2.00	20-373	2.00	60-373	2.00	70-373	2.00
complete.....	374B	---	10-374B	.02	20-374B	.02	60-374B	.02	70-374B	.02
Throttle lever rocker bracket, screw and nut.....	375	---	10-375	.80	20-375	.80	60-375	.80	70-375	.80
" " " " " connecting rod, with 2 jaws.....	376	---	10-376	.25	20-376	.25	60-376	.25	70-376	.25
" " " " " " jaw.....	377	---	10-377	.05	20-377	.05	60-377	.05	70-377	.05
" " " " " jaw pin.....	377B	---	10-377B	.05	20-377B	.05	60-377B	.05	70-377B	.05
" " " " " cotter pin, per doz.....										

ALL SIZES OF BURNER, BOILER, AND BOTTOM SUPERHEATERS


	14-Inch		16-Inch		18-Inch		20-Inch		23-Inch		26-Inch	
	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price	No.	Price
Burner.....	---	\$16.00	---	\$18.00	---	\$23.00	---	\$30.00	---	\$33.00	---	\$40.00
Boiler.....	---	65.00	---	75.00	---	100.00	---	120.00	---	160.00	---	215.00
Inside bottom superheater.....	---	1.50	---	1.55	---	1.60	---	1.80	---	1.80	---	2.00
Outside " ".....	---	1.60	---	1.65	---	1.80	---	2.00	---	2.00	---	2.20

When writing us, always give model and NUMBER of car


Where no price is given part is not used on that model



337



460



430

Plate 27

INDICATORS, AUTOMATIC VALVES AND PUMPS

27

		No.	Price			No.	Price
*FLOAT WATER INDICATOR COMPLETE		400	\$10.00	GASOLINE RELIEF VALVE COMPLETE		460	\$4.00
Float water indicator body		401	5.25	Body		461	1.50
" " " bottom cap		402	.75	Base		462	1.00
" " " left nut		403	.30	Screw		463	.03
" " " right nut with steel seat		404	.50	Adjusting screw		464	.15
" " " spindle		405	.45	Diaphragm with valve stem		465	.50
" " " spring		406	.02	Paper gasket		465G	.01
" " " " block		407	.02	Spring		466	.25
" " " wheel segment		408	.35	Top button		467	.15
" " " chain		409	.05	Bottom button		468	.15
" " " float		410	.45	DIRECT DRIVE CYLINDER OIL PUMP		470	2.00
" " " pet cock		411	.25	Screw and nut		471	.02
" " " wheel		412	.40	Body		472	1.00
" " " " screw		413	.01	Check ball		473A	.01
" " " pointer		414	.20	" " spring		473B	.02
" " " " bearing		415	.25	" " " plug		473C	.05
" " " " screw		416	.01	Stub cap		473D	.15
" " " lead weight		417	.25	Stuffing box gland		473E	.05
" " " " case		418	.30	" " nut		473F	.15
" " " " screw		419	.01	Packing		473G	.05
" " " screw eye		420	.01	Plunger		474	.35
" " " wire link		421	.01	Lock nuts		474C	.02
* For Glass Water Level Indicator See No. 580.				Cylinder oil box		475	4.00
				" " " filler cap		475C	.25
				" " " screws		476	.01
				CYLINDER OIL SIGHT FEED		478	1.50
				Cylinder oil sight feed bracket		479	.10
				RATCHET CYLINDER OIL PUMP WITH-			
				OUT BOX		480	3.00
				Screw and nut		481A	.02
				" " "		481B	.01
				Oil box		482	2.00
				Body, top part		483A	.25
				" bottom part		483B	.40
				Stand		484	.75
				Plunger		485	.25
				Spring		486	.10
				" plug		487	.10
				Ratchet		488	.25
				Cam		489	.30
				Dog		490	.05
				Check ball		491	.01
				" " spring		492	.02
				" " lug		493	.02
				Ratchet spring, stop and screw		494	.02
				Dog stop		495	.05
				" " screw		496	.01
				Stuffing box gland		497	.05
				" " nut		498	.10
				Top screw		499	.03
STEAM AUTOMATIC VALVE COMPLETE		430	5.00				
Body		431	1.50				
Base		432	.80				
Screw		433	.03				
Adjusting screw		434	.15				
Diaphragm		435	.15				
Paper gasket		435G	.01				
Stuffing box		436	.15				
Lock nut		437	.05				
Stuffing box gland		438	.05				
" nut		439	.15				
" " set screw		439B	.03				
Top button		440	.15				
Bottom button		441	.15				
Head single		442	.25				
Spring		443	.50				
Valve stem		444	.10				
" tip		445	.15				
" ball		445B	.01				
Nipple		446	.10				
Double head only		447A	.35				
Stub cap		448	.15				
Wire gauge strainer		449	.03				

When writing us, always give model and NUMBER of car




Plate 28

INDICATORS, AUTOMATIC VALVES AND PUMPS

29

	No.	Price		No.	Price
TANDEM HAND GAS AND WATER PUMP	0500	\$9.00	PUMP DRIVE PARTS		
Hand gas pump	500	3.00	Power gasolene pump plunger guide	554	\$0.25
" " " bolt	501A }	.02	" " " " " screw	555	.01
" " " nut	501B }	.01	" " " " " pump crosshead	556	1.25
" " " washer	501C	.01	" " " " " drive rod	557	1.75
" " " body	502	1.50	Pump drive rod lock nut	557D	.05
*Tandem hand plunger connecting link, countersunk	504A	.20	Engine bent pump rod	558	2.00
*Tandem hand plunger connecting link, threaded	504B	.20	GASOLENE FILTER	559	.75
Tandem hand plunger link screw	529A	.04	DOUBLE POWER WATER PUMPS		
" " " nut	529B	.01	Power water pump complete, right suet., left del'y	560A	4.00
Hand gas pump plunger	505	.50	" " " " " left " right "	560B	4.00
" " " stuffing box gland	506	.15	" " " " " bolt	541A }	.02
" " " nut	507	.10	" " " " " nut	541B }	.01
Packing, $\frac{3}{8}$ " Vulcabestine, per yard	508	3.00	" " " " " washer	541C	.01
Hand water pump	520		Power water pump body, right suction, left del'y	561A	2.25
" " " bolt	521A }	.02	" " " " " left " right "	561B	2.25
" " " nut	521B	.01	†Single power water pump plunger with eye forging,	562	.35
" " " washers	521C	.15	$\frac{3}{8}$ " diameter, $3\frac{1}{2}$ " long		
" " " body	522	1.50	†Double power water pump gooseneck plunger, $\frac{9}{16}$ "	10-562	1.25
" " " plunger	523	.50	diameter, $18\frac{1}{4}$ " long over all		
" " " stuffing box gland	524	.15	†Double power water pump gooseneck plunger, $\frac{9}{16}$ "	20-562	1.25
" " " nut	525	.50	diameter, $16\frac{1}{4}$ " long over all	60-562	.25
Tandem hand pump lever bracket, each	526	.30	†Power water pump plunger, $\frac{9}{16}$ " diam., $4\frac{3}{4}$ " long	563	.15
" " " " " bolt	527A }	.02	" " " " " stuffing box gland	564	.35
" " " " " nut	527B }	.01	" " " " " nut	565	.01
" " " " " bolt washer	527C	.01	" " " " " " " spring stop	566	.01
" " " lever	530	.50	" " " " " " " " " screw	567	.05
" " " shaft	531	.10	Power water pump check ball	568	.25
*Tandem hand pump lever link, countersunk	532A	.20	" " " " " cap complete	568A	.25
*Tandem hand pump lever link, threaded	532B	.20	" " " " " crowfoot	568B	.25
" " " link screw	529A	.04	" " " " " with spring	569	.06
" " " nut	529B	.01	" " " " " packing	580	12.50
" " " lever handle	533	.60	GLASS WATER LEVEL INDICATOR COMP.		
Packing $\frac{3}{8}$ " Vulcabestine, per yard	534	.10	Body	581	3.50
POWER GASOLENE PUMP	540	2.50	Stand pipe	582	.50
" " " bolt	541A }	.02	Bottom stub	583	.10
" " " nut	541B }	.01	" " " bracket for glass	584A	.50
" " " washer	541C	.01	" " " lock nut	584B	.35
" " " body	542	1.15	Glass	585A	.05
†Power gasolene pump plunger with eye, $\frac{9}{16}$ " diam.	543	.25	Rubber packing	585B	.05
eter, $3\frac{3}{4}$ " long over all			Protector	585C	.05
†Power gasolene pump gooseneck plunger, $\frac{9}{16}$ "	10-543	.75	LOW WATER AUTOMATIC VALVE COMP.	590	3.50
diameter, $15\frac{1}{4}$ " long over all			Base	591	.50
†Power gasolene pump plunger, $\frac{9}{16}$ " diameter, $8\frac{3}{4}$ "	60-543	.25	Expansion tube	592A	.35
long			" " " cap	592B	.15
Power gasolene pump stuffing box gland	544	.05	" " " plug	592C	.05
" " " nut	545	.15	Diaphragm with valve stem	593	.50
" " " spring stop	546	.01	Head body	594A	.50
Power gasolene pump check ball	547	.01	" " " valve seat	594B	.35
" " " cap	548	.15	Rod	595A	.10
" " " packing ring	549	.01	Adjusting nuts	595B	.03
" " " leather washer	550	.01	Lock nuts	595C	.03

*When ordering pump links specify length required, that is, distance between center of holes

When writing us, always give model and NUMBER of car

†If plungers of different dimensions are required specify such dimensions



640



641-1



641-2



641-3



641-4



642



644-1



644-2



644-3

643



645-1



645-2



645-3



645-4



645-5

Plate 29

IRON PIPE SIZE BRASS PIPE AND FITTINGS

31

IRON PIPE SIZE BRASS PIPE AND FITTINGS	No.	Price		No.	Price
$\frac{1}{8}$ " brass nipple	600	---	$\frac{1}{8}$ " brass plug	605	\$0.05
(Specify length required)			$\frac{1}{8}$ " union	606	.35
$\frac{1}{8}$ " brass nipple, $\frac{1}{2}$ " to 2" long inclusive		\$0.05	$\frac{1}{8}$ " pipe, per foot	609	.15
$\frac{1}{8}$ " " " $\frac{1}{2}$ " to 5" " "		.10	$\frac{1}{8}$ " nipple	610	.10
$\frac{1}{8}$ " " " $\frac{1}{2}$ " to 10" " "		.15	$\frac{1}{8}$ " elbow	611	.12
$\frac{1}{8}$ " elbow	601	.08	$\frac{1}{8}$ " brass tee	612	.15
$\frac{1}{8}$ " tee	602	.10	$\frac{1}{8}$ " plug	615	.08
$\frac{1}{8}$ " brass cross	603	.20	$\frac{1}{8}$ " union	616	.40
$\frac{1}{8}$ " coupling	604	.05	$\frac{1}{8}$ " x $\frac{1}{8}$ " brass elbow	617	.15
			$\frac{1}{8}$ " x $\frac{1}{8}$ " bushing	618	.10
			$\frac{1}{8}$ " brass pipe, per foot	619	.25

TUBING, FITTINGS, Etc.

	No.	Price		No.	Price
Vaporizing coil, 12 ft. for Model B & C	621	\$1.75	DASHBOARD STUB (2 sizes)	641-4	---
" " 15 " " " EX	10-621	2.25	For tube outside diameter, $\frac{3}{16}$ " or $\frac{1}{4}$ "	---	\$0.15
" " 18 " " " F	20-621	2.75	" (Specify size required)	---	.15
" " 30 " " " M	30-621	4.50			
" " 18 " " " 70	60-621	2.75	DASHBOARD NIPPLE	642	.15
$\frac{3}{16}$ " brass tube for torch and headlights only,	70-621	4.50	" stub lock nut	643	.05
per foot	630	.15	" nipple lock nut	643	.05
$\frac{3}{16}$ " outside diameter copper tube, per foot	631	.15			
$\frac{1}{4}$ " " " " " " "	632	.15	COPPER TUBE UNION ELBOW STUBS		
$\frac{9}{32}$ " " " " " " "	633	.15	Elbow stub, Form 1 (1 size only)	644-1	.15
$\frac{7}{16}$ " " " " " " "	634	.15	For tube outside diameter, $\frac{9}{32}$ "		
Copper tube clip (Specify size required)	637	.20	Elbow stub, Form 2 (1 size only)	644-2	.30
			For tube outside diameter, $\frac{9}{32}$ "		
COPPER TUBE UNION STUB NUT (4 sizes)	640		Elbow stub, Form 3 (1 size only)	644-3	.30
For tube outside diameter, $\frac{3}{16}$ "		.07	For tube outside diameter, $\frac{9}{32}$ "		
" " " " $\frac{1}{4}$ "		.07			
" " " " $\frac{9}{32}$ "		.07	COPPER TUBE UNION TEE STUBS		
" " " " $\frac{7}{16}$ "		.08	Tee stub, Form 1 (1 size only)	645-1	.30
(Specify size required)			For tube outside diameter, $\frac{9}{32}$ "		
COPPER TUBE UNION STRAIGHT STUBS			Tee stub, Form 2 (1 size only)	645-2	.30
Straight stub Form 1 (3 sizes)	641-1		For tube outside diameter, $\frac{9}{32}$ "		
For tube outside diameter, $\frac{3}{16}$ " or $\frac{1}{4}$ "		.08	Tee stub, Form 3 (1 size only)	645-3	.30
" " " " $\frac{9}{32}$ "		.08	For tube outside diameter, $\frac{9}{32}$ "		
" " " " $\frac{7}{16}$ "		.12	Tee stub, Form 4 (1 size only)	645-4	.30
(Specify size required)			For tube outside diameter, $\frac{9}{32}$ "		
Straight stub, Form 2 (2 sizes)	641-2		Tee stub, Form 5 (1 size only)	645-5	.30
For tube outside diameter, $\frac{3}{16}$ " or $\frac{1}{4}$ "		.08	For tube outside diameter, $\frac{9}{32}$ " or $\frac{1}{4}$ "		
" " " " $\frac{9}{32}$ "		.08			
(Specify size required)					
Straight stub, Form 3 (2 sizes)	641-3				
For tube outside diameter, $\frac{3}{16}$ " or $\frac{1}{4}$ "		.08			
" " " " $\frac{9}{32}$ "		.08			
(Specify size required)					


When writing us, always give model and NUMBER of car



650-1




650-2




650-3



650-4




650-5




650-6




650-7




651-10




651-11



652-20



652-21



653



658



659



660

Plate 30

	No.	Price		No.	Price
NEEDLE VALVES WITH STEM COMPL.					
Plain needle valve, Form 1	650-1	\$0.65	Bicycle wrench	668	\$0.25
" " " " 2	650-2	.65	Fork wrench	669-1	---
" " " " 3	650-3	.65	Oil gun	670	.75
" " " " 4	650-4	.65	Boiler hose connection	671	.75
" " " " 5	650-5	.65	Tire repair kit	672	2.50
" " " " 6	650-6	.65	Air pump for tires	673	4.00
" " " " 7	650-7	.65	Ross emergency torches, per doz.	674	.75
Plain needle valve, packing nut	650B	.15	FIRING UP OUTFIT		
Needle valve, Form 10	651-10	1.00	" " torch	680	3.50
" " " " 11	651-11	1.00	Brass tubing $\frac{1}{16}$ " per foot	681	.15
Needle valve, packing nut	651B	.15	Prest-O-Lite motor cycle tank	682MC	10.00
" " " gland	651E	.05	" " Model E tank	682E	18.00
Needle valve, Form 20	652-20	1.50	Oil side lamp, right Model 60	60-683R	4.00
" " " " 21	652-21	1.50	" " " left " 60	60-683L	4.00
Needle valve, packing nut, nickel	652B	.20	Oil side lamp, right " 70	70-683R	5.00
" " " gland	652E	.05	" " " left " 70	70-683L	5.00
" " " lock nut, nickel	652F	.15	" " " bracket, right, each	60-684R	.35
" " " washer	652G	.15	" " " left " "	60-684L	.35
$\frac{1}{16}$ " needle valve stem with wheel (specify length required)	653	.25	" " " bolt and nut	60-684B	.02
BOILER CHECK VALVE, 2-WAY			Gauge lamp	685	3.00
" " " ball $\frac{1}{16}$ " bronze	658	.75	" " bracket complete	686	.25
" " " 3-way	658C	.05	Tail lamp	687	3.50
" " " ball, $\frac{1}{16}$ " bronze	659	.75	" " bracket	688	.25
GAS, T. BALL CHECK VALVE, 3-WAY	659C	.05	" " coach screw	688B	.01
" " " ball $\frac{1}{4}$ " steel	660	.75	Headlight. See headlight price list	689	---
Spindle lever boot	660C	.01	" rubber tubing, per foot	690	.10
Steering drop rod lower end boot	663A	.50	" bracket, each (specify size of lamps)	691	1.50
Sector gear end boot	663B	.50	" screws	691C	.03
Horn for Model 60	663C	.50	Auto. jack	692	2.00
" " " 70	60-664	5.00	Model C wire wheel puller	700	1.75
Tool box	70-664	5.00	" EX wheel puller	10-700	1.75
" " bolts and nuts	665	3.50	" F " "	20-700	1.75
Screw driver	665B	.05	" 60 " "	60-700	1.75
8" Stillson wrench	666	.25	" 70 " "	70-700	1.75
	667	1.00	Copper tube flange tool for flanging the ends of		
			$\frac{1}{16}$ - $\frac{1}{4}$ - $\frac{3}{16}$ - $\frac{1}{2}$ " copper tubing	701	1.75
			Boiler tube taper plugs	702	.05
			" " expander	703	1.75
			Superheater boiler tube expander	704	1.75
			Boiler tube bead tool	705	.50
			" " driving out punch	706	.50
			Pinch bar for removing superheaters	707	1.00

* $\frac{1}{16}$ " diameter is standard size valve stem on all cars built since January, 1909. We do not carry any other size in stock.

When writing us, always give model and NUMBER of car




Plate 31

LOW WATER AUTOMATIC VALVE

This is an expansion valve, and is designed to shut off the main burner when the water gets extremely low in the boiler. So long as the water level is above the point where it is connected into the water column (marked "Try-cock" in the cut) it will remain cool. When, however, the water level falls to this point, the expansion tube will fill with steam and the heat will expand the tube and close the valve, thus shutting off the supply of gas to the main burner.

When the Low Water Automatic Valve closes be sure that there is plenty of water in the tank and that both pumps are working. Close both by-pass valves and run the car as far as it will go. This will probably gain enough water in the boiler to cover the connection to the Low Water Automatic Valve, so that it will cool and the main fire come on again. If it does not, cool it by putting some cold water on to the expansion tube. If you cannot cool it, it indicates that the water is not above the connection. Then jack up the rear axle and run the engine, or pump some water by hand. When the water level is below the connection, the expansion tube cannot be cooled because it is full of steam; but when the water is above it, it can be.

Do not change the adjustment or attempt to set the Low Water Automatic Valve unless you are certain that you know how it should be done.

THREE-TUBE INDICATOR BODY

The Three-Tube Indicator Body is made up of three tubes brazed together. The middle one forms a part of the water column; water is pumped through the left one; and the right one is the standpipe connected to the glass.

So long as the water level is above it, it is kept cool by the water passing through it. When the water level falls below the top of it, some of the water in the standpipe will vaporize and raise the water in the glass. As the water level gets lower, more will vaporize, raising the water higher in the glass, thus indicating the water level through a range of about three inches.

Explanation

The individual parts of a made up part are numbered in the cuts individually, while in the list they are numbered as a whole. For instance, the rear axle frame right half, in the list No. 1, is made up of five parts brazed together, and is shown in the cut as follows:

1	Rear axle inside forging	.	.	.	.	.	No. 1A
1	" " outside "	.	.	.	.	.	" 1B
1	" " spring block	.	.	.	.	.	" 1C
1	" " brass rod lug	.	.	.	.	.	" 1D
1	" " tubing	.	.	.	.	.	" 1E

The differential, list No. 9 is made up as follows:

1	Differential spider	.	.	.	.	.	No. 9A
1	" gear ring	.	.	.	.	.	" 9B
3	" pinions	.	.	.	.	.	" 9C
3	" studs	.	.	.	.	.	" 9D
3	" rivets	.	.	.	.	.	" 9E

There is no such thing as a differential gear ring with the teeth cut. The ring is shrunk on to the spider, pinned and sweat on, then the teeth are cut, so as to insure a true running gear.



The Barca Press
Boston — New York