

PRICE LIST
OF PARTS

FOR THE

Stanley

STEAM
CAR

MODEL 735



Price List of Parts

STANLEY STEAM CAR

MODEL 735

Order for parts must be accompanied by cash. We will not send parts C. O. D. unless we receive sufficient funds to cover transportation charges both ways.

All prices are F. O. B. Factory and are subject to change without notice.

In ordering parts for STANLEY CARS, specify whether to ship by *Mail*, *Express* or *Freight*, and be sure to give the number and name of the part wanted, as these numbers and names are listed in this price list of parts. Also, give the model and number of the car. For parts of cars more than one year old, it is advisable, when possible, to send the old parts as samples. For parts that connect two other parts give dimensions. For tubing, give outside diameter and length required. Otherwise, on account of changes which are made from time to time, we would be uncertain as to what was required. Careful attention to these suggestions will assist us materially in filling orders promptly and correctly.

Cable Address: STANLEYCAR. BOSTON

TELEGRAPH CODE

<i>Rabble</i>		Send by mail
<i>Racer</i>		Send by express
<i>Racking</i>		Ship by freight
<i>Racoon</i>		Ship by freight, draft with bill of lading
<i>Radical</i>		Ship by next boat
<i>Ragman</i>		Have sent by mail
<i>Rainbow</i>		Have sent by express
<i>Rambler</i>		Have sent by express C. O. D.
<i>Ramrod</i>		Have shipped by freight
<i>Ransack</i>		Have shipped by freight, draft with bill of lading
<i>Rapture</i>		Have shipped by boat

Stanley Motor Carriage Co., Newton, Mass.

INDEX

	Page	Part No.
AXLES AND CONNECTING PARTS		
Rear Axle	6	1 to 20
Perches	7	23
Front Axle	7	028
Springs, Bumpers and Hangers ...	8	50 to 55
Axle Pump Drive Case and Fittings	9	80 to 86
AUTOMATIC VALVES		
Steam Automatic Valve	20	430
Fuel Relief Valve	21	460
Low Water Automatic Valve	23	590
Automatic Bypass Valve	23	596
Safety Valve	15	271
BRAKE PARTS		
Brake Parts on Axle	7	43 to 46 and 64 to 72
Brake Parts on Chassis	13	222 to 236 and 245
BODY	13	200
BURNER	16	300
BOILER	17	310
CHASSIS FRAME	13	201
ENGINE	10	100 to 199
ELECTRIC Dynamo Battery Wire and Switches	29	720 to 745
FENDERS AND RUNNING BOARDS ..	8	47 to 49
FEED WATER HEATER	17	319
FILTERS	23	571-2-3-4
GAUGES		
Steam Pressure Gauge	15	269
Fuel Pressure Gauge (Duplex) ...	15	270
Pilot Tank Quantity Gauge	17	329-G
Water Tank Quantity Gauge	17	331-M
Main Fuel Tank Quantity Gauge ..	17	333-G
HOOD	15	279
HOSE		
Water Suction Hose	15	262
Siphon Hose	15	273
Exhaust Hose	17	318
Radiator Hose	19	381S-382A-383A

INDEX

	Page	Part No.
INDICATOR—Boiler Water Level . . .	20	400
PUMPS	21	470 to 569
RADIATOR	19	380
REVERSE AND HOOK UP		
Rods	15	237 and 238
Pedals	15	241
SIPHON	15	272
STEERING GEAR	13	213
SMOKE BONNET	17	323A
SUPERHEATER	18	354
STEAMPIPE	18	358-359
TANKS		
Main Fuel Pressure Tank	17	328
Main Fuel Tank	17	333
Pilot Fuel Tank	17	329
Water Tank	17	331
THROTTLE VALVE	18	337
Throttle Lever Quadrant-Rod and Fittings	18	366 to 371
TUBING, PIPE AND FITTINGS		
Iron Pipe Size, Brass Pipe and Fittings	24	600 to 620
Brass and Copper Tubing and Union Fittings	24	631 to 649
VALVES		
Air Check Valve	15	268
Ball Check Valve 2 Way $\frac{1}{8}$ "	27	658
Emergency Boiler Check 2 Way $\frac{1}{4}$ "	27	658-5
Boiler Check Valve 3 Way $\frac{1}{4}$ "	27	659-4
Needle Valve $\frac{1}{8}$ "	25	650-1 to 652-23
Hand Bypass Valve $\frac{1}{4}$ "	26	652-30
VALVE STEMS	26	653

RUNNING GEAR AND MUD GUARDS

	No.	Price
RIGHT REAR AXLE HOUSING	735-1	\$85.00
Left rear axle housing.....	735-2	85.00
Rear axle housing screw.....	735-3A	.20
Rear axle housing screw nut.....	735-3B	.10
Rear axle housing cap.....	735-4	3.75
do. screw.....	735-4B	.10
do. gasket.....	735-4G	.05
Rear axle housing gasket.....	735-5	.15
Rear axle truss rod.....	735-7	3.50
do. turnbuckle.....	735-7C	.80
do. turnbuckle right hand nut.....	735-7D	.10
do. turnbuckle left hand nut.....	735-7E	.10
Rear axle truss rod bolt.....	735-7F	.20
do. nut.....	735-7G	.15
Rear axle complete, including parts 1 to 20 assembled....	735-09	330.00
DIFFERENTIAL	735-9	40.00
do. pinion.....	735-9C	4.00
do. pinion stud.....	735-9D	.35
do. thrust washer.....	735-9W	1.00
Right half driving shaft.....	735-10R	24.00
do. shaft only.....	735-10AR	12.00
do. bevel gear.....	735-10BR	11.00
do. gear key.....	735-10CR	.10
Right half driving shaft pump gear.....	735-10FR	4.00
do. key, No. 9 woodruff.....	735-10GR	.05
Left half driving shaft.....	735-10L	23.00
do. shaft only.....	735-10AL	11.00
do. bevel gear.....	735-10BL	11.00
Left half driving shaft gear key.....	735-10CL	.10
REAR AXLE BEARINGS		
Rear axle inside cup Timken No. 4320.....	735-11	2.85
Rear axle inside cone Timken No. 435.....	735-13	5.85
Rear axle outside bearing S.K.F. 2211.....	735-12	11.85
Rear wheel lock nut.....	735-15	.35
Rear axle outside cone sleeve.....	735-17A	2.25
do. nut.....	735-17B	.50
Rear axle outside bearing thrust washer.....	735-17C	.35
Rear axle outside dust washer.....	735-18B	2.25
Rear axle outside dust washer screw.....	735-18C	.10
Rear axle outside felt washer.....	735-19	.25
Inner felt washer for Rear Axle outside bearing.....	735-19-2	.10
RIGHT ENGINE BRACE ROD	735-21R	1.75
Left engine brace rod.....	735-21L	1.75
Engine brace rod rear lock nut.....	735-21C	.10
Engine brace rod front lock nut.....	735-21D	.10
Engine brace rod collar.....	735-21E	.10
Engine brace rod lock washer.....	735-21F	.01

	No.	Price
RIGHT PERCH	735-23R	\$11.00
Left perch	735-23L	11.00
Perch wood.....	735-23D	4.00
Perch end front.....	735-23TF	2.00
Perch end rear.....	735-23TR	2.00
Perch pins	735-23E	.10
Perch bolts	735-24	.90
REAR WHEEL COMPLETE (wood) less dem. rim.....	735-025	28.00
Rear wheel outside flange.....	735-25B	4.50
Rear wheel hub bolts.....	735-25D	.10
Rear wheel inside flange.....	735-25E	4.50
Rear wheel brake drum.....	735-25F	8.00
do. oil plug	735-25P	.10
Wire wheel spokes 9 3/8" long	735-W-25-S-1	.10
do. 10" long	735-W-25-S-2	.10
do. 11 7/16" long	735-W-25-S-3	.10
do. 12" long	735-W-25-S-4	.10
do. nipples	735-W-25-T	.05
Rear wheel hub cap for wood wheel.....	735-39R	2.40
Wire wheel hub cap left thread for right wheels.....	735-W-39-L	4.00
FRONT AXLE COMPLETE Timken No. 148B.....	735-028	80.00
FRONT WHEEL COMPLETE (wood).....	735-038	24.00
Front wheel hub cap for wood wheels.....	735-39F	2.40
Wire wheel hub cap right thread for left wheels.....	735-W-39-R	4.00
FRONT AXLE TIMKEN BEARINGS		
do. inside cup Timken No. 412.....	735-33A	2.25
do. inside cone and rollers Timken No. 415.....	735-34	5.65
do. inside cup Timken No. 312.....	735-33B	1.70
do. outside cone and rollers Timken No. 316.....	735-35	3.75
RIGHT EXTERNAL BRAKE LEVER	735-43ER	.75
LEFT EXTERNAL BRAKE LEVER	735-43EL	.75
External brake fulcrum shaft.....	735-43F	1.00
External brake fulcrum shaft nut.....	735-43G	.10
External brake fulcrum.....	735-44E	1.50
do. key No. 9 Woodruff.....	735-44F	.05
External brake inside link and bushing.....	735-44G	1.00
External brake band outside link.....	735-44H	.35
External brake band link screws.....	735-44J	.10
do. lock nut.....	735-44K	.05
External brake fulcrum screws.....	735-45B	.10
do. lock nut.....	735-45C	.05
External brake band.....	735-46	.50
do. lining	735-46B	1.85
External brake band lug.....	735-46D	.50
do. adjusting screw.....	735-46E	.50
do. adjusting nuts.....	735-46F	.05
do. guide pin nut.....	735-46R	.05
do. guide pin spring.....	735-46S	.10
do. guide bracket.....	735-46T	.40
External brake band guide bracket set screw.....	735-46T-2	.05
do. lock nut.....	735-46T-3	.03
External brake band guide bracket nut.....	735-46U	.15

	No.	Price
RIGHT FRONT FENDER	735-47A	\$11.00
Left front fender.....	735-47B	11.00
Right rear fender.....	735-47CR	8.00
Left rear fender.....	735-47CL	8.00
Right rear fender.....	735-47CR	8.00
Left rear fender.....	735-47CL	8.00
Front right fender hanger.....	735-48A	3.50
Model 735		
Model 736		
Front left fender hanger.....	735-48B	3.50
Left front running board hanger.....	735-48E-1	2.00
Running board hanger shim.....	735-48W	.50
Running board	735-49A	1.50
do. mat	735-49B	1.00
RUNNING BOARD SHIELD RIGHT	735-49MR	4.00
Running board shield left, with door.....	735-49ML	8.00
FRONT SPRING	735-50A	9.00
do. front bolt.....	735-50A-1	.75
do. rear bolt.....	735-50A-2	.75
do. bolt castle nut.....	735-50A-3	.15
do. shackle	735-50A-5	1.00
do. adjusting bushing.....	735-50A-6	.35
do. adjusting lock nut.....	735-50A-7	.15
Rear spring.....	735-50R	20.00
Rubber bumper, large.....	735-50R-1	.45
Rubber bumper, small.....	735-50R-2	.45
do. strap	735-50S	.20
Right rear spring seat.....	735-51A	12.00
Left rear spring seat.....	735-51C	12.00
Left front spring seat.....	735-52L	2.50
Right front spring seat.....	735-52R	2.50
Front bottom spring clip.....	735-53A	.40
Rear bottom spring clip.....	735-53B	.75
Rear top spring clip.....	735-53C	.40
Rear top spring clip bar.....	735-54B	.20
Right rear chassis spring hanger.....	735-055-C-R	5.00
Left rear chassis spring hanger.....	735-055C-L	5.00
Chassis spring hanger bolt with nut.....	735-56	.10
Tires	735-59	See Tire List
Internal brake band stop bolt.....	735-64A	.40
do. nut	735-64B	.15
do. nut washer	735-64C	.05
INTERNAL BRAKE expanding ring (lined)	735-65	14.00
Brake expanding ring lining.....	735-65B	1.85
Brake expanding ring rivets per doz.....	735-65C	.05
Brake expanding ring screw.....	735-65S	.01
Right internal brake lever.....	735-66R	.75
Left internal brake lever.....	735-66L	.75
do. cam bolt	735-67	1.50

	No.	Price
Internal brake collar and bushing.....	735-67B	.75
do. cam bolt nut.....	735-69	.10
do. ring spring	735-70	.20
Grease cup, large.....	735-71C	.50
do. small	735-71D	.25
Brake drum cover.....	735-72	1.50
Axle pump drive case.....	735-80	20.00
Axle pump drive case paper gasket.....	735-80E	.05
do. key, No. 9 Woodruff.....	735-80K	.05
do. rear cap clamp screw.....	735-80R	.15
do. case screw.....	735-80S	.15
Axle pump drive crank shaft bearing S.K.F. 1205.....	735-81	4.50
Axle pump drive crank shaft.....	735-82	1.50
Axle pump drive crank shaft key, No. 9 Woodruff.....	735-82B	.05
Axle pump drive gear.....	735-83	6.00
Axle pump drive crank.....	735-84	2.00
do. crank pin bearing lock nut.....	735-86	.40

ENGINE PARTS

	<i>No.</i>	<i>Price</i>
ENGINE	735-100	350.00
ENGINE CYLINDER ASSEMBLED	735-0101	108.00
Engine cylinder	735-101	50.00
do. top head	735-102	1.50
do. top head packing 31D per yd.....	736-102B	.20
do. bottom head	735-103	2.25
do. bottom head bushing.....	735-103B	.15
do. bottom head packing 31-D per yd.....	735-103C	.20
Steam chest cover.....	735-104	1.50
do. bushing	735-104B	.20
do. packing (31-D) per yd.....	735-104C	.20
Top engine frame.....	735-0105-1	14.00
Bottom engine frame.....	735-0105-2	11.00
Engine frame adjusting screw.....	735-105E	.20
do. nut	735-105G	.10
Engine frame rod diaphragm bushing nut.....	735-105K	.20
Slide valve stem guide.....	735-106A	4.50
do. screw	735-106B	.25
do. round nut	735-106C	.07
do. screw hexagon nut.....	735-106D	.07
do. screw cotter pin 5/8 x 5/64".....	735-106D-2	.01
do. diaphragm nut	735-106E	.20
Crosshead slide	735-107	3.00
do. screw	735-107B	.15
do. stud	735-107E	.15
do. shim	735-107S	.01
do. screw split washers.....	735-107W	.01
ENGINE MAIN BEARING CLAMP	735-111RB	12.00
Engine main bearing shim.....	735-111S	.02
Extension frame nut acorn.....	735-113B	.75
Frame nut, hex.....	735-114	.15
Frame nut, stop.....	735-114S	.10
Frame nut, washer.....	735-114W	.10
ECCENTRIC ROD	735-116	5.00
do. shim	735-116S	.01
do. strap screw.....	735-117A	.20
do. strap screw lock nut.....	735-117B	.05
do. pin cotter 1/2 x 5/64".....	735-117P	.01
do. pin	735-118A	.20
do. nut	735-118B	.05
SLIDE VALVE	735-119	1.50
do. stem	735-120A	.35
do. stem round nut.....	735-120B	.07
do. stem lock nut.....	735-121	.07
do. stem stuffing box.....	735-122	.75
do. stem stuffing box bushing.....	735-122B	.10
do. stem packing gland.....	735-123	.15
do. stem packing	735-123C	.20
do. stem packing nut.....	735-124	.50

ENGINE PARTS

11

	No.	Price
Slide valve stem jaw.....	735-125	1.25
Link block pin.....	735-126A	.20
Link block pin nut.....	735-126B	.05
ENGINE LINK.....	735-127	2.00
Link block	735-129	.90
Link hanger rod.....	735-130	.90
do. nut	735-130B	.07
do. pin	735-131A	.15
do. pin nut	735-131B	.07
Link hanger rod pin nut cotter pin 1/2 x 5/64".....	735-131P	.01
ENGINE PISTON with rings.....	735-132	5.00
Engine piston top head.....	735-132A	1.50
Engine piston bottom head.....	735-132B	1.50
do. ring	735-132C	1.00
do. lock nut.....	735-132D	.10
Piston rod packing gland.....	735-133	.25
do. packing	735-133C	.20
do. packing nut.....	735-134	.75
Piston rod packing nut spring stop.....	735-135	.02
WRIST PIN right.....	735-136	.75
Wrist pin left.....	735-137	.75
Wrist pin nut.....	735-138	.10
Wrist pin castle nut.....	735-138-2	.15
CROSSHEAD and piston rod.....	735-139	10.00
ENGINE CONNECTING ROD.....	735-140	14.00
Connecting rod bolt.....	735-140B	.70
do. nut	735-140B-1	.15
do. laminated shim	735 140C	.10
Connecting rod lip nut.....	735-140F	.15
Crank shaft complete assembled.....	735-0141	53.00
Crank shaft only.....	735-141	4.75
Crank shaft key.....	735-141B	.15
ENGINE GEAR	735-142	15.00
Eccentric	735-143	2.50
Engine crank.....	735-144	5.00
Main bearing roller.....	735-145B	.35
ENGINE MAIN BEARING ROLL TRACK.....	735-145RB	4.00
Crank pin inside washer.....	735-146RB	.75
Crank pin bearing roller.....	735-147B	.35
Crank pin roll track.....	735-147RB	2.50
Crank pin cone lock nut.....	735-149	.35
5/16 steel balls in eccentrics.....	735-150	.02
EXHAUST FITTING.....	735-155	2.25
do. screw	735-156	.10
do. gasket	735-157	.20
Exhaust hose nipple.....	735-161	.45
Engine hanger strap stud.....	735-164	1.00
do. cup nut.....	735-164B	.20
do. castle nut.....	735-164C	.30
Engine hanger strap.....	735-165	3.50

ENGINE PARTS

	No.	Price
ENGINE CYLINDER CASE	735-167	17.00
Cylinder case screw.....	735-168	.01
do. nut	735-168B	.01
ENGINE CENTER CASE	735-169	21.00
Center case blocks, threaded.....	735-169C	.10
do. screw	735-171	.05
ENGINE STUFFING BOX CASE	735-172	3.00
Steam chest drip elbow.....	735-177	.40
Steam chest drip valve without stem No. 651-12.....	735-0179	1.25
Steam chest drip valve stem complete.....	735-0179C	1.75
REVERSE LEVER SHAFT	735-182A	2.50
do. nut	735-182B	.10
Reverse lever hook-up dog.....	735-183A	1.50
do. lever	735-183B	.60
do. nut	735-185	.10
PACKED STEAM SWIVEL JOINT	735-186	4.50
Packed steam swivel joint body.....	735-186A	2.50
do. packing tube	735-186B	.65
do. gland	735-186C	.40
do. packing nut	735-186D	.65
do. packing nut stop	735-186D-1	.15
do. packing nut stop nut.....	735-186D-2	.05
Reverse lever shaft arm	735-187A	1.50
do. Woodruff key No. 9.....	735-187B	.05
do. set screw	735-187C	.15
Engine frame rod spring.....	735-189	.35
ENGINE CASE DIAPHRAGM	735-190A	8.00
do. stuffing box	735-190B	1.50
do. stuffing box lock nut.....	735-190C	.50
do. packing nut	735-190D	.50
Engine rear case felt band.....	735-191A	.90
Engine diaphragm felt band.....	735-191B	.55
Engine cylinder case felt band.....	735-191C	.35

BODY FITTINGS

13

	No.	Price
BODY	735-200	700.00
Body anchor bolt 3".....	735-200V-3	.10
do. nut	735-200V-4	
Body anchor bolt 2½" and nut.....	735-200V-6	.10
Chassis frame steel.....	735-201A	90.00
CHASSIS DASH complete.....	735-0201C	10.00
Hood rest, right.....	735-201JR	4.00
Hood rest, left.....	735-201JL	4.00
BOILER SUPPORT rear.....	735-204A	4.00
Front boiler lugs.....	735-204B-1F	.50
Boiler support tie rod.....	735-204D	.25
do. nuts	735-204D-1	.05
Boiler anchor bolt.....	735-205A	.25
Burner hanger bolt, right front and left rear.....	735-205B-2	.30
do. left front and right rear.....	735-205B-3	.30
Burner hanger bolt brass nut.....	735-205C	.10
Boiler anchor bolt brass nut.....	735-205E	.10
Boiler anchor bolt band.....	735-205S	.50
Boiler anchor bolt band screw.....	735-205T	.02
do. nut	735-205T-2	.01
ENGINE HANGER STRAP BRACKET	735-206	1.00
do. cup nut	735-207A	.15
do. castle nut	735-207B	.35
Steering post bottom bracket bolts and nuts.....	735-210D	.05
STEERING GEAR—WARNER	735-0213	50.00
Steering drag link.....	735-219	4.00
EMERGENCY BRAKE ROCKER SHAFT	735-222F	3.00
CONTROL BRAKE ROCKER SHAFT	735-222R	4.00
Brake rocker shaft anti-rattler spring.....	735-222S	.25
Brake rocker nut	735-222M	.10
BRAKE PEDAL	735-223	3.50
Brake pedal bracket plain.....	735-224A-P	.75
Brake pedal bracket threaded.....	735-224A-T	.75
Brake pedal bolt	735-224C	.35
Brake pedal bolt nut	735-224D	.10
Brake pedal bracket bolts.....	735-225A	.05
do. nuts	735-225B	
do. washers	735-225W	.01
Brake pedal connecting rod.....	735-226	1.65
Front jaw threaded.....	735-226B	.35
Jaw lock nut	735-226E	.05
Jaw pin	735-226F	.05
Adjusting sleeve	735-226G	.35
do. lock nut	735-226H	.05
EXTERNAL BRAKE SIDE ROD	735-227	1.65
Rear jaw threaded.....	735-227C	.35
Threaded jaw lock nut.....	735-227D	.05

	No.	Price
Adjusting sleeve	735-227E	.35
do lock nut	735-227F	.05
Brake rod jaw pin	735-228	.05
Brake pedal spring	735-230	.20
do. hook	735-231	.20
do. hook, bolt and nut	735-231B	.03
EMERGENCY BRAKE HAND LEVER	735-232	
do. lever only	735-232A	7.50
do. latch	735-232B	1.00
do. latch bolt	735-232C	.10
do. latch bolt nut	735-232D	.10
do. catch draw rod	735-232E	.15
do. catch draw rod lug	735-232F	.20
do. catch draw rod lug lock-nut	735-232G	.10
do. catch spring	735-232H	.15
do. catch spring collar	735-232J	.03
do. catch	735-232K	1.00
do. catch bolt	735-232L	.15
do. catch bolt nut	735-232M	.05
do. ratchet rack	735-232N	.75
do. ratchet rack bracket	735-232N-A	.35
do. ratchet rack bracket nut	735-232NC-2	.05
do. ratchet rack bracket bolt and nut	735-232ND	.05
do. ratchet rack offset stud	735-232-O	.15
do. ratchet rack offset stud bolt and nut	735-232P	.05
Hand brake lever bracket	735-232W	1.50
do. bolts and nuts	735-232W-2	.05
do. washer	735-232W-5	.05
Hand brake lever connecting rod	735-232V	1.25
do. jaw threaded	735-232V-3	.35
do. jaw lock nut	735-232V-5	.05
do. jaw pin	735-232V-6	.05
BRAKE SIDE ROD GUIDE	735-233	
do. leather	735-233A	.20
do. leather screw	735-233D	.01
do. do. nut	735-233D-2	.01
do. support	735-233S	.25
do. support bolt and nut	735-233T-1	.03
do. do. split washer	735-233T-3	.01
INTERNAL BRAKE SIDE ROD	735-234	1.65
do. jaw threaded	735-234B	.35
do. jaw lock nut	735-234D	.05
do. jaw pin	735-234E	.05
do. adjusting sleeve	735-234F	.35
do. adjusting sleeve lock nut	735-234G	.05
Reverse pedal brackets	735-235	.50
do. bolt	735-236A-1	.05

BODY FITTINGS

15

	No.	Price
Reverse and brake pedal bracket bolt.....	735-236A-2	.05
do. nut	735-236B	
do. washer	735-236C	
REVERSE AND HOOKUP ROD.....	735-0237	4.50
Reverse rod rear jaw screw.....	735-237E	.15
do. nut	735-237F	.05
Reverse rod front jaw.....	735-237G	.35
do. pin	735-237H	.05
do. lock nut	735-237J	.05
Hook-up rod rear jaw screw.....	735-238C	.15
do. nut	735-238D	.05
Hook-up rod front jaw.....	735-238E	.35
do. pin	735-238F	.05
Hook-up rod jaw lock nut.....	735-238G	.05
Reverse and hook-up rod spring.....	735-239	.25
do. hook	735-239B	.20
do. bolt and nut	735-239C	.03
do. split washer	735-239C-3	.01
Reverse and hook-up pedals.....	735-241	
Reverse pedal	735-241A	3.50
Reverse hook-up pedal	735-241B	3.50
Reverse pedal shaft	735-241C	.25
BRAKE ROCKER BEARING.....		
do. bushing	735-245A	.50
do. lock nut	735-245B	.20
Brake rocker shaft brace.....	735-245R	.80
do. screw	735-245S	.01
WATER SUCTION RUBBER HOSE.....	735-262	.70
Water suction hose nipple.....	735-263	.25
Suction hose tee.....	735-263B	1.50
do. union nuts	735-263B-2	.25
do. tubing	735-263B-3	.10
Suction hose elbow.....	735-263C	.15
AIR CHECK	735-268	.30
do. ball	735-268C	.03
STEAM PRESSURE GAUGE.....	735-269	9.00
Duplex fuel pressure gauge.....	735-270	11.00
SAFETY VALVE	735-271	3.50
Safety valve spring	735-271D	.25
SIPHON with hose nipple.....	735-272	2.00
Siphon hose, per ft.....	735-273	.20
do. strainer	735-274	.50
do. strainer nipple	735-274B	.30
HOOD	735-279	25.00
Hood hinge rod rear guide.....	735-279G	.25
do. nut	735-279G-2	.05
Hood lift	735-279R	.20
Hood catch	735-280	.75
Hood catch screw	735-280S	.01
do. nut	735-280S-2	.01

BURNERS

	No.	Price
BURNER complete	735-300	
Burner casing	735-301A	5.00
do. metal side lining	735-301B	1.00
do. asbestos side lining	735-301C	.70
do. asbestos bottom lining	735-301D	.70
do. peek hole cover	735-301E	.15
do. screw	735-301F	.01
do. nut	735-301F-2	.01
do. lug	735-301G	.15
Burner casing pilot plate	735-301J	1.50
Cement packing, per lb.	735-301P	.25
Main burner casting complete	735-302	26.00
Main mixing tube	735-303	.80
Pilot burner assembly	735-304	11.00
do. casting	735-304-A	3.00
do. do. clamp	735-304-A-2	.25
do. do. screw	735-304-A-3	.10
Pilot mix. tube	735-304B	1.00
Pilot vap. (electric)	735-304C	4.00
Pilot vap. elec. terminal extension	735-304D	.80
Pilot vap. elbow stub (use 644-12)	735-304E	.25
Pilot vap. detach nozzle	735-305LP	.15
Pilot screw with wire	735-306	.10
do. cleanout screw	735-308	.05
MAIN VAPORIZER	735-305	10.00
Main vaporizer calorized	735-305-2	20.00
Main detachable nozzle	735-305LM	.20
Vaporizer main screw	735-307	.05
Vaporizer cleanout screw	735-308	.05
Vap. cable 5 ft. 11 strands No. 18 annealed iron wire, per ft.	735-309	.05

	No.	Price
BOILER	735-310	320.00
Boiler asbestos cover, corrugated.....	735-310F	2.00
Boiler cover bands	735-310G	.40
Boiler tubes	735-311	.35
Boiler tube bushings	735-311B	.01
Boiler feed extension complete 3/8 I.P.S.....	735-315F	1.00
Exhaust hose	735-318	1.00
do. clamps	735-318E	.15
FEED WATER HEATER complete.....	735-319	25.00
do. water tubes	735-319C	6.00
Feed water heater 1/4 flanged elbow long.....	735-319D	.90
do. 1/4 flanged elbow short.....	735-319D-1	.80
do. do. lock nut	735-319D-2	.10
do. gasket	735-319D-3	.05
Feed water heater support bolt.....	735-319T	.15
Exhaust hose nipple.....	735-321	.45
SMOKE BONNET	735-323A	9.50
do. down draft and elbow.....	735-323B	5.00
MAIN FUEL PRESSURE TANKS , each.....	735-328	6.25
Fuel pressure tank 9/32 stub with extension tube 6".....	735-328K	.25
Pilot Fuel Tank	735-329	35.00
Pilot tank filler cap	735-329D	.75
do. gasket	735-329F	.05
Pilot tank gauge	735-329G	6.00
WATER TANK	735-331	70.00
Water tank suction strainer	735-331F	.75
Water tank quantity gauge	735-331M	6.00
Water tank support	735-331W	2.00
Water tank support long bolts	735-331W-4	.40
do. steel nut	735-331W-5	.05
Water tank support long bolt brass nut.....	735-331W-6	.10
MAIN FUEL TANK	735-333	40.00
Fuel tank gauge	735-333G	6.00
Fuel tank support strap, right.....	735-333S-1-R	2.00
Fuel tank support strap, left	735-333S-1-L	2.00
Fuel tank support rod	735-333S-3	1.00
do. loose collars	735-333S-4	.05
do. nuts	735-333S-6	.10
Fuel tank support bolts.....	735-333S-7	.20
do. steel nuts	735-333S-8	.05
do. brass nuts	735-333S-9	.10
Steam boiler elbow	735-334	.75
Throttle steam tube complete	735-336	1.50
Throttle elbow	735-336J	.85
Throttle steam tube stud	735-336S-1	.25
do. nut	735-336S-2	.10
do. strap	735-336S-3	.40
do. clamp bolt	735-336S-4	.10
do. nut	735-336S-5	.05

	No.	Price
THROTTLE VALVE	735-337	7.00
Throttle stem complete	735-339	1.25
Throttle stem rod	735-339A	.40
Throttle stem button	735-339B	.15
Throttle stem sleeve	735-339C	.60
Throttle valve stem nut	735-340	.05
Throttle stem link	735-341	.25
Throttle packing gland	735-343	.15
Throttle packing, per yd.	735-343B	.20
Throttle packing nut	735-344	.35
Throttle brace rod	735-345	.20
Throttle brace rod nut	735-346A	.05
Superheater front bracket support assembly.....	735-351A	1.00
Cap screw	735-351C	.15
Washer	735-351D	.01
Steampipe loop support body	735-352A	.35
Steampipe loop support clamp	735-352B	.35
Steampipe loop support stud	735-352C	.20
Steampipe loop support nuts	735-352D	.05
Superheater	735-354	15.00
Throttle connecting superheater	735-357	1.50
MAIN STEAM PIPE LOOP	735-358	4.00
MAIN STEAM PIPE	735-359	4.00
1/8" boiler elbow (medium)	735-361B	.35
1/4" boiler elbow	735-361D	.40
Main burner valve stem cowl bushing.....	735-364A	.20
Steering post cowl bracket.....	735-365A	1.25
do. screws	735-365B	.10
do. screw nut	735-365C	.05
do. plain washers	735-365C-2	.01
do. clamp screw	735-365D	.15
THROTTLE LEVER QUADRANT complete	735-0366	3.50
do. set screw	735-367	.10
do. locking screw	735-368	.15
Throttle lever grip	735-369A	.25
Throttle lever nut	735-369B	.10
Throttle lever	735-370	.75
do. rod	735-371	1.25
Washer at bottom	735-371B	.05
Throttle lever rod bottom arm	735-371C	.75
do. binding screw	735-371C-1	.10
do. nut	735-371C-2	.05
do. washer	735-371C-3	.01
Top nut	735-371D	.20
Throttle tension clamp bushing.....	735-371T-4	.10

RADIATOR

19

	No.	Price
RADIATOR	735-380	145.00
Radiator filler cap	735-380C	1.75
Radiator filler cap gasket	735-380C-2	.10
Radiator safety valve	735-381	5.00
Radiator safety valve hose, per foot	735-381S	.30
Radiator inlet connection hose	735-382A	.75
Radiator inlet connection clamps	735-382B	.15
Radiator inlet connection hose nipple	735-382C	.35
Radiator inlet connection horizontal tube	735-382D	2.00
Radiator inlet connection upright tube	735-382E	1.75
Radiator inlet connection elbow 1½ x 1½ I. P. S.....	735-382F	.40
Radiator inlet connection elbow 1½" street elbow.....	735-382G	.50
Radiator outlet hose	735-383A	.60
do. clamps	735-383B	.15
Radiator outlet tube	735-383C	1.00
Radiator brace rod complete	735-385	1.00
do. nuts	735-385C	.05
Radiator suspension bolt	735-385T	.15
do. nut	735-385T-2	.05
Radiator dust shield	735-386	2.00
do. rubber cushion	735-386D	.05

20 INDICATORS, AUTOMATIC VALVES AND PUMPS

	No.	Price
WATER LEVEL INDICATOR	735-400	60.00
do. body	735-401A	20.00
do. body bushing for try cock	735-401A2	.75
do. body extension	735-402A	12.00
do. do. gasket	735-403A	.10
do. do. bushing	735-404A	.20
do. do. screws	735-405A	.15
do. do. cap	735-406A	4.00
do. do. cap gasket	735-407A	.05
do. dial	735-408A	1.00
do. pointer	735-409A	.50
do. dial spacing ring	735-410A	.20
do. dial glass	735-411A	.25
do. bezel	735-412A	1.50
do. gasket	735-413A	.05
do. float assembly ball	735-414B	.50
do. do. arm	735-414C	.25
do. do. arm set screw	735-414D	.05
do. do. arm nuts	735-414E	.05
do. do. arm washer	735-414F	.01
do. do. hub	735-414G	.35
do. do. lead weight	735-414H	.25
do. do. shaft	735-414J	.35
do. magnet bar	735-415A	.75
Water level indicator bracket	735-420A	3.50
do. bracket to body screw	735-421A	.15
do. bracket to chassis screw	735-422A	.15
do. do. nut	735-422B	.05
do. do. lock washer	735-422C	.01
Water indicator extension support	735-425A	.25
do. screws	735-425B	.02
STEAM AUTOMATIC VALVE	735-430	9.00
do. body	735-431	3.00
do. base	735-432	1.50
do. screw	735-433	.05
do. adjusting screw	735-434	.25
do. diaphragm	735-435	.25
do. gasket	735-435G	.02
do. packing box	735-436	.25
do. packing box lock nut	735-437	.08
do. packing gland	735-438	.08
do. packing	735-438P	.05
do. packing nut	735-439	.20
do. locking screw	735-439B	.05
do. top button	735-440	.20
do. bottom button	735-441	.20
do. spring	735-443	.75
do. valve stem	735-444	.15
do. ball	735-445B	.01
do. nipple	735-446	.15
do. double head	735-447A	.50
do. head stub cap	735-448	.20

	No.	Price
FUEL AUTOMATIC RELIEF VALVE	735-460	6.00
do. body	735-461	1.50
do. base	735-462	2.00
do. base only	735-462A	1.50
do. seat bushing	735-462B	.20
do. steel seat	735-462B-2	.15
do. screw	735-463	.05
do. adjusting screw	735-464	.25
do. diaphragm	735-465	.35
do. valve stem	735-465B	.25
do. valve stem spring	735-465S	.15
do. gasket	735-465G	.02
do. spring	735-466	.40
do. top button	735-467	.25
do. bottom button	735-468	.25
 CYLINDER OIL PUMP	735-470	5.00
do. body	735-472A	1.50
do. check ball	735-473A	.01
do. deliver check stub cap.....	735-473D	.25
do. stub cap extension	735-473D-2	.20
do. check steel plunger	735-473D-4	.20
do. packing gland	735-473E	.08
do. packing nut	735-473F	.25
do. do. spring stop	735-473F-2	.02
do. do. spring stop screw	735-473F-3	.01
do. do. nut	735-473F-4	.01
do. do. washer	735-473F-5	.01
do. packing rings	735-473G	.04
do. leather washer	735-473G-2	.02
do. suction check cap	735-473S	.25
 Cylinder oil pump plunger.....	735-474	1.00
do. actuating arm leather washer	735-474G	.02
do. clamp	735-474H	.35
do. set screw	735-474H-2	.05
 Cylinder oil pump plunger guide	735-474S	.50
do. screws	735-474T-1	.01
do. nuts	735-474T-2	.01
 Plain washer	735-474T-3	.01
 Cylinder oil tank	735-475	7.50
Cylinder oil sight feed blinker	735-478	1.50
Cylinder oil sight feed plunger	735-478B	.25
Cylinder oil sight feed spring	735-478C	.10
Cylinder oil sight feed glass	735-478D	.15
Cylinder oil sight feed gaskets	735-478E	.01
Cylinder oil sight feed cap	735-478F	.25

22 INDICATORS, AUTOMATIC VALVES AND PUMPS

	No.	Price
HAND FUEL PUMP	735-500	4.00
do. body	735-502	2.00
do. plunger	735-505	.90
Hand pump packing gland	735-506	.25
Hand pump packing nut	735-507	.75
Hand pump packing 31-D vulcabestin	735-508	per yd. .20
Leather washer	735-508B	.03
Hand pump plunger crosshead	735-505H	1.00
Hand pump connecting	735-510	2.25
 HAND WATER PUMP	735-520	4.00
do. body	735-522	2.00
do. plunger	735-523	.90
do. packing gland	735-524	.25
do. packing	735-524P	per yd. .20
do. leather washer	735-524P-2	.03
do. packing nut	735-525	.75
Tandem hand pump lever brackets, each.....	735-526	.45
Hand pump lever	735-530	.75
do. handle	735-533	1.00
 POWER FUEL PUMP	735-540	5.00
do. body	735-542	2.50
do. body bushing	735-542B	.15
do. plunger	735-543	1.25
do. packing gland	735-544	.10
do. packing nut	735-545	.25
do. packing nut stop plate	735-546A	.10
do. packing nut stop set screw	735-546B	.05
do. check ball	735-547	.01
do. delivery cap	735-548	.25
do. long suction cap	735-548L	.25
do. packing rings	735-549	.03
do. leather washer	735-550	.02
 POWER PUMP CROSSHEAD		
do. forging	735-556A	2.25
do. oil plunger head	735-556F	.75
do. lock nut	735-556G	.10
do. extension rod	735-556J	1.00
do. extension arm	735-556K	.20
do. extension arm lock nut	735-556L	.15
do. set screws	735-556H	.03
Power pump drive rod	735-557	7.50
do. rear ball bearing S.K.F. No. 1202	735-557D	2.50
 PUMP DRIVE ROD CASE	735-558	3.75

INDICATORS, AUTOMATIC VALVES AND PUMPS 23

	No.	Price
POWER WATER PUMP	735-560	9.00
do. body	735-561	5.50
do. bushing	735-561C	.15
do. suction plug	735-561D	.10
do. plunger	735-562	.90
do. packing gland	735-563	.20
do. packing nut	735-564	.50
Packing nut stop wire	735-565A	.05
Packing nut stop set screw	735-565B	.02
Power water pump check ball with guide.....	735-567A	.20
Power water pump check cap	735-568	.35
Power water pump packing.....	735-569A	.05
do. leather washer	735-569B	.03
WATER FILTER	735-571	2.00
do. screen	735-571C	.05
Main fuel pressure filter	735-572	2.00
do. screen	735-572C	.05
Main fuel suction filter (Lunkenheimer)	735-573	1.25
Pilot fuel filler	735-574	2.00
do. screen	735-574C	.05
LOW WATER AUTOMATIC VALVE	735-590	6.00
do. base	735-591	.90
do. expansion tube	735-592A	.75
do. do. cap	735-592B	.35
do. diaphragm with valve stem	735-593	.75
Low water automatic valve head body.....	735-594A	.90
do. head valve seat	735-594B	.75
do. rods	735-595A	.15
do. adjusting nuts	735-595B	.05
do. lock nuts	735-595C	.05
do. low water auto. springs	735-595D	.15
do. do. adjusting nuts	735-595E	.05
AUTOMATIC BYPASS VALVE	735-596	9.00
do. base	735-597A	1.00
do. expansion tube	735-597B	1.00
do. crosshead	735-597C	1.00
do. valve body	735-598A	2.50
do. valve bushing	735-598B	.10
do. valve packing nut	735-598C	.35
do. stop	735-598C-1	.15
do. set screw	735-598C-2	.05
do. packing gland	735-598D	.15
do. valve stem and ball	735-598E	.50
do. packing	735-598H	.05
do. rods	735-599A	.20
do. nuts	735-599B	.05
do. spring	735-599C	.15

& F
per yd.

	No.	Price
1/8" BRASS NIPPLES	735-600	
do. 3/4" long	735-600	.10
do. 1"	735-600	.10
do. 1 1/4"	735-600	.12
do. 2"	735-600	.14
do. 3"	735-600	.17
do. 3 1/2" threaded on one end	735-600	.19
do. 3 3/4"	735-600	.20
do. 4 1/2" annealed	735-600	.22
1/4" STEEL NIPPLES	735-600S	
do. 1 1/4" long	735-600S	.12
do. 2"	735-600S	.14
1/4" brass street elbow	735-601B	.30
1/4" do. stock pattern	735-601B-2	.20
1/4" special brass tee with stud	735-602-2	.60
do. nut	735-602-2-B	.05
1/4" brass plug	735-605	.09
1/4" brass hollow plug	735-605-2	.10
1/4" brass double plug	735-605-3	.15
Socket part of 1/4" brass union	735-606B	.20
1/4" brass nipple	735-610	
do. 1" long	735-610	.15
do. 1 1/2" long	735-610	.20
1/4" heavy iron nipple	735-610S	
do. 2" long	735-610S	.20
do. 2 1/4" long	735-610S	.20
do. 3" long	735-610S	.25
do. 5" long	735-610S	.35
1/4 x 1/2 x 1/4" brass tee	735-612-3	.35
1/4" to 1/8" reducing coupling	735-614-2	.15
1/4" brass plug	735-615	.12
1/4" brass union	735-616	.60
3/16" copper tubing	735-631, per ft.	.15
9/32" brass tubing	735-633, per ft.	.20
7/16" copper tubing	735-634, per ft.	.25
9/32" copper tube clips	735-637C	.03
9/32" do. loop	735-637C-2	.05
9/32" clip screw	735-637S	.01
Clip screw nut	735-637S-2	.01
do. washer	735-637S-3	.01
COPPER TUBE UNIONS		
3/16" tube union stub nut	735-640-A	.12
9/32" tube union stub nut	735-640C	.12
7/16" tube union stub nut	735-640D-2	.15
3/4" x 3/16" tube union straight stub form 1-A	735-641-1A	.15
3/4" x 9/32" tube union straight stub form 1-C	735-641-1C	.15
3/4" x 3/16" tube union straight stub form 2-A	735-641-2A	.18
3/4" x 9/32" tube union straight stub form 2-C	735-641-2C	.18
3/4" x 9/32" partition straight stub	735-641-7	.25

	<i>No.</i>	<i>Price</i>
$\frac{1}{4}$ x 7/16" union straight stub	735-641-10	.25
$\frac{1}{4}$ x 7/16" partition straight stub	735-641-11	.35
$\frac{3}{8}$ " partition stub lock nut.....	735-643A	.08
$\frac{9}{32}$ " partition stub lock nut.....	735-643C	.08
$\frac{7}{16}$ " partition stub lock nut.....	735-643D-2	.10
$\frac{1}{8}$ x 9/32" copper tube elbow stub	735-644-1	.30
$\frac{1}{8}$ F x 9/32" elbow stub	735-644-4	.30
$\frac{1}{8}$ x 9/32" elbow stub x 9/32" stub side outlet.....	735-644-5	.45
$\frac{1}{4}$ " x 7/16" elbow stub.....	735-644-8	.45
$\frac{1}{8}$ x 3/16" elbow stub with bracket.....	735-644-11	.35
$\frac{1}{8}$ x 9/32" elbow stub with stud.....	735-644-12	.35
do. nut	735-644-12B	.05
$\frac{1}{8}$ F x 3/16" partition elbow stub.....	735-644-13	.45
$\frac{9}{32}$ x 9/32" partition elbow stub.....	735-644-14	.45
$\frac{1}{8}$ x 3/16" elbow stub	735-644-15	.45
$\frac{1}{8}$ x 9/32 x 9/32" copper tube union tee stub.....	735-645-1	.45
$\frac{9}{32}$ x 9/32 x $\frac{1}{8}$ " copper tube union tee stub.....	735-645-3	.45
$\frac{1}{8}$ F x 9/32 x 9/32" copper tube union tee stub.....	735-645-4	.45
$\frac{1}{8}$ M x $\frac{1}{8}$ F x 9/32" copper tube union tee stub.....	735-645-7	.45
$\frac{1}{8}$ F x 7/16 x 7/16" copper tube union Y stub.....	735-645-8	.50
$\frac{1}{8}$ M x 7/16 x $\frac{1}{8}$ F copper tube union T stub.....	735-645-10	.30
$\frac{1}{8}$ x 9/32 x 9/32" copper tube union tee stub with bushing.....	735-645-11	.50
$\frac{1}{8}$ x 9/32 x 9/32 copper tube union tee stub.....	735-645-1	.45
do. bushing	735-645-11B	.05
NEEDLE VALVE WITHOUT STEM	735-650-1	.75
Body	735-650-1A	.40
Packing nut	735-650-1B	.23
Lock nut	735-650-1N	.08
Packing	735-650-1P	.04
Needle valve without stem	735-650-2	.75
Body	735-650-2A	.40
Packing nut	735-650-2B	.23
Lock nut	735-650-2N	.08
Packing	735-650-2P	.04
Needle valve without stem	735-650-3	.75
Body	735-650-3A	.40
Packing nut	735-650-3B	.23
Lock nut	735-650-3N	.08
Packing	735-650-3P	.04
Needle valve without stem	735-650-4	.75
Body	735-650-4A	.40
Packing nut	735-650-4B	.23
Lock nut	735-650-4N	.08
Packing	735-650-4P	.04
Needle valve without stem	735-650-7	.50
Body	735-650-7A	.23
Packing nut	735-650-7B	.23
Packing	735-650-7P	.04

	No.	Price
Needle valve without stem	735-650-8	.75
Body	735-650-8A	.40
Packing nut	735-650-8B	.23
Lock nut	735-650-8N	.08
Packing	735-650-8P	.02
Needle valve without stem	735-651-11	1.25
Body	735-651-11A	.75
Packing nut	735-651-11B	.30
Gland	735-651-11E	.08
Needle valve without stem	735-651-12	1.25
Packing	735-651-11P	.06
Needle valve	735-651-12	1.25
Body	735-651-12A	.75
Packing nut	735-651-12B	.30
Gland	735-651-12E	.08
Packing	735-651-12P	.06
Needle valve without stem	735-652-23	1.75
Body	735-652-23A	1.25
Packing nut	735-652-23B	.30
Gland	735-652-23E	.08
Packing ring	735-652-23P-1	.01
Packing leather washer	735-652-23P-2	.01
Screws	735-652-23-S	.01

HAND BYPASS VALVE WITHOUT STEM	735-652-30	2.50
Body	735-652-30A	1.50
Packing box	735-652-30A-2	.50
Packing nut	735-652-30B	.30
Packing gland	735-652-30E	.08
Packing ring	735-652-30P-1	.01
Packing leather washer	735-652-30P-2	.01
Packing retainer washer	735-652-30P-3	.05
Screws	735-652-30S	.01
Hand bypass valve stem	735-653-30	.75
Stem	735-653-30A	.35
Ball	735-653-30B	.10
Wheel	735-653-30-C	.20

NEEDLE VALVE STEMS

STEM BLUNT POINT 60° WITH WHEEL	735-653-1	
(Specify length required)		
1¾" long		.35
2½" long		.40
3½" long		.45
6½" long		.55
8" long		.60
STEM BLUNT POINT 60° WITH LEVER	735-653-2	
(Specify length required)		
3½" long		.45
Lever	735-653-2D	.20

	No.	Price
STEM LONG POINT 30° WITH LEVER AND NUT ..735-653-23		
13 $\frac{5}{8}$ " long		.75
Lever	735-653-23D	.20
do. nut	735-653-23E	.12
CHECK VALVES		
$\frac{1}{8}$ " ball check valve 2-way	735-658	.90
Body	735-658A	.50
Cap	735-658B	.30
Ball 7/16" brass no corrode	735-658C	.08
Emergency boiler check	735-658-5	2.00
Body	735-658-5A	.75
Cap	735-658-5B	.35
Ball with guide	735-658-5C	.20
Stem	735-658-5D	.25
Gland	735-658-5E	.05
Packing nut	735-658-5F	.20
Packing	735-658-5G	.05
Boiler check valve 3-way	735-659-4	1.25
Body	735-659-4A	.65
Cap	735-659-4B	.35
Ball with guide	735-659-4C	.20
Fuel T. ball check valve	735-660	.90
Body	735-660A	.50
Cap	735-660B	.30
Spring	735-660B-2	.05
Ball 1/4" steel	735-660-C	.01
Fuel straight check valve	735-660-2	.50
Body	735-660-2A	.40
Ball	735-660-2B	.01
Spring	735-660-2C	.05
Pin	735-660-2D	.01
Oil check valve with 3/16" stub	735-661-3	.75
Body	735-661-3A	.25
Cap	735-661-3B	.20
Plunger	735-661-3C	.25

	No.	Price
STEERING DRAGLINK FORWARD END BOOT	735-663B	.50
do. rear end boot	735-663C	.70
HORN complete	735-664	5.00
Horn support	735-664S	1.25
do. screws	735-664S-2	.01
do. screw nut	735-664S-3	.01
do. screw split washer	735-664S-4	.01
Horn button screw	735-664T	.01
Screw driver	735-666	.30
8" Stillson wrench	735-667	1.50
Slip joint combination pliers	735-667-3	.40
Bicycle wrench	735-668	.40
8 in. adjustable wrench	735-668-2	.55
Fork wrench $\frac{3}{8}$ " and $\frac{1}{4}$ "	735-669-1	.35
do. $\frac{1}{2}$ " and $1\frac{1}{16}$ "	735-669-2	.35
do. $5/16$ " and $9/16$ "	735-669-3	.25
do. 1" and $1\frac{7}{16}$ "	735-669-4	.75
Spring bottom oiler	735-670-2	.35
Boiler hose connection	735-671	1.25
Boiler hose connection 606-A	735-671A	.20
do. 606-C $\frac{1}{4}$ " union nut	735-671B	.18
do. nipple	735-671C	.15
do. $\frac{1}{2}$ " hose union	735-671D	.25
do. round nut	735-671E	.40
Air pump for tires	735-673	6.00
Auto jack	735-674	4.00
36" 9/32 copper tube with nuts	735-675	.85
Socket wrench handle	735-676A	.35
do. socket 27/32" for water pump check cap.....	735-676B	.20
Spare demountable rim only	735-27A	5.40
Demountable rim wrench	735-27W	.85
Demountable rim tool	735-27W-2	1.25
GAUGE LAMP	735-685	2.00
do. screws	735-685B	
Tail lamp	735-687	1.25
do. bracket	735-688	.35
do. clamp screw	735-688B	.15
do. clamp screw nut	735-688C	.05
Head light	735-689	10.00
HEADLIGHT BRACKETS	735-691	1.50
do. nuts	735-691B	.10
do. split washer	735-691C	.02
do. tie rod	735-691R	.50
do. fork collar	735-691S	.05
Robe rail	735-693	5.00
do. screws	735-693B	
Foot rest	735-694	5.00
do. board covered	735-694A	1.25
do. board screws	735-694B	.03

	<i>No.</i>	<i>Price</i>
Foot rest right bracket	735-694-C	1.30
Foot rest left bracket	735-694-D	1.30
Foot rest bracket to footboard screw	735-694E	.03
TOP	735-695	130.00
Door curtain opener rod	735-695B	.90
do. socket	735-695C	.35
do. screw	735-695D	.01
Windshield	735-696	40.00
do. washers	735-696W	.05
SPEEDOMETER	735-697	50.00
Demountable rim and tire carrying brackets.....	735-698	
Right bracket, Model 735	735-698-AR	4.00
Left bracket, Model 735	735-698-AL	4.00
Bracket cradle nut	735-698B	.75
Split washer	735-698B-2	.03
Bracket bolt	735-698C	.05
do. nut	735-698D	
do. split washer	735-698D-2	.01
Bracket cradle	735-698E	1.50
do. straps	735-698F	.25
Bracket extension nut	735-698R	.75
Bracket tie rod 735	735-698S	1.00
Bracket tie rod 736	735-698S	1.00
Bracket tie rod nuts	735-698S-2	.25
do. split washer	735-698S-3	.03
For wire wheels only.		
DYNAMO	735-720	30.00
do. cover	735-720A	1.50
do. to cradle screw	735-720B	.10
do. do. lock washer	735-720C	.01
do. cradle	735-721	2.25
do. cradle strap	735-721B	1.00
do. key, No. 9 Woodruff.....	735-721K	.05
Dynamo Pinion Gear	735-722	4.00
do. lock nut	735-722A	.10
do. shaft key, No. 3 Woodruff	735-722B	.05
Dynamo coupling disc	735-723	.75
do. leather	735-724	.15
do. screws	735-724B	.01
do. washers	735-724C	.01
do. lock wire	735-724D	.01
Dynamo gear bearing S.K.F. No. 1205.....	735-725	4.50
Dynamo gear stuffing box	735-726	1.00
do. screws	735-726A	.05
do. packing gland	735-726B	.20
do. packing nut	735-726C	.50
do. lock nut	735-726D	.20
do. gasket	735-726G	.05
do. felt washers	735-726P	.02

	<i>No.</i>	<i>Price</i>
DYNAMO AUTOMATIC SWITCH	735-731	10.00
Lighting switch		2.50
STORAGE BATTERY	735-733	27.00
ELECTRIC PILOT STARTING SWITCH	735-0740	24.00
PILOT STARTING SWITCH thermostat	735-740E	3.00
PILOT STARTING SWITCH latch	735-742D	.75
DEMOUNTABLE RIM AND TIRE CARRYING BRACKETS		



