

SCHEMATIC OF THE **HEATHKIT®** SSB TRANSCEIVER MODEL SB-101

7. INDICATES HOOKUP WIRE NOT IN THE HARNESS.  ${\hbox{NOTE:}}$  Letter-number designations for resistors, capacitors, etc., have been PLACED in the following groups: 8. ( ) INDICATES COLOR CODE OF COAXIAL CABLE. " IF "
BANDPASS "
AUDIO "
RF-DRIVER "
CRYSTAL "
HETERODYNE OSCILLATOR "
DRIVER GRID "
DRIVER PLATE "
PARTS MOUNTED ON THE CHASSIS. 2. ALL CAPACITOR VALUES OVER 1 ARE IN pf UNLESS MARKED OTHERWISE. 3. REFER TO THE X-RAY AND CHASSIS VIEWS FOR PHYSICAL LOCATION OF PARTS. SEE THE VOLTAGE CHARTS (FOLD-OUT FROM PAGE 112) AND THE RESISTANCE CHART (FOLD-OUT FROM PAGE 113) FOR ALL MEASUREMENTS.

5. ALL SWITCHES ARE IN THE POSITION INDICATED BY THE KNOB POINTERS. 6. ARROW ( ) INDICATES CLOCKWISE ROTATION OF KNOB (VIEWED FROM KNOB END).

9. ALL RELAY CONTACTS SHOWN IN RECEIVE POSITION. 11. FOR GREATER CLARITY, RELAY SECTIONS ARE SHOWN CLOSEST TO THE CIRCUITS IN WHICH THEY ARE USED, ONE OF THE FOLLOWING MARKS IS USED TO IDENTIFY THE SEPARATED SECTION OF THE RELAYS: △ = PART OF RELAY RL1
□ = PART OF RELAY RL2 12. SWITCH WAFERS ARE IDENTIFIED AS IN THE FOLLOWING EXAMPLE:

F = FRONT SIDE OF THE WAFER. R = REAR SIDE OF THE WAFER.